

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [BUAIAHUG](#) /

› [BUAIAHUG BHG 45oz Automatic Nut and Soy Milk Maker \(Model bhg-01\) User Manual](#)

BUAIAHUG bhg-01

BUAIAHUG BHG 45oz Automatic Nut and Soy Milk Maker

Model: **bhg-01**

User Manual

1. INTRODUCTION

Thank you for choosing the BUAIAHUG BHG 45oz Automatic Nut and Soy Milk Maker. This appliance is designed to simplify the process of making fresh, plant-based milks, smoothies, soups, and more, right in your home. Featuring an intuitive LED touch screen, a powerful 14-blade grinder, and convenient functions like an 18-hour timer and self-cleaning, this machine offers versatility and ease of use. Please read this manual thoroughly before operating the appliance to ensure safe and efficient use.

2. IMPORTANT SAFEGUARDS

When using electrical appliances, basic safety precautions should always be followed to reduce the risk of fire, electric shock, and/or injury to persons, including the following:

- Read all instructions before using the appliance.
- Do not immerse the main unit (motor base) in water or other liquids. Only the pitcher interior is designed for liquid contact.
- Ensure the voltage indicated on the appliance corresponds to your local mains voltage before connecting.
- Close supervision is necessary when any appliance is used by or near children.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Avoid contact with moving parts.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been dropped or damaged in any manner.
- The use of attachments not recommended or sold by the manufacturer may cause fire, electric shock, or injury.

- Do not use outdoors.
- Do not let cord hang over edge of table or counter, or touch hot surfaces.
- Do not place on or near a hot gas or electric burner, or in a heated oven.
- Always attach plug to appliance first, then plug cord into the wall outlet. To disconnect, turn any control to 'off', then remove plug from wall outlet.
- Do not use appliance for other than intended use.
- Exercise extreme caution when moving an appliance containing hot liquid.
- Ensure the lid is properly aligned and secured before operation to prevent spills and ensure safety. An 'E2' error may display if the lid is not correctly placed.

3. PRODUCT OVERVIEW

The BUAIAHUG BHG Nut and Soy Milk Maker is designed for convenience and versatility. It features a 45oz capacity, a powerful 14-blade grinding system, and an intuitive LED touch screen with 11 preset functions.



Image 3.1: The BUAIAHUG BHG 45oz Automatic Nut and Soy Milk Maker, shown with a glass of freshly made milk and raw ingredients like soybeans and cashews.

3.1 Components

- **Main Unit:** Contains the motor, heating element, and control panel.
- **Pitcher:** Stainless steel interior with a 45oz capacity.
- **Lid:** Designed for secure fit and includes safety induction.
- **14-Blade Grinder:** Integrated into the pitcher for efficient blending.

3.2 Control Panel

The LED touch screen provides access to all functions and settings.



Image 3.2: A detailed view of the LED touch screen control panel, displaying various function icons such as Soy Milk, Oat Milk, Nut Milk, Smoothie, Soup, Hot Cereal, Juice, Sterilize, Auto Clean, Keep Warm, Timer, and Start/Stop buttons.

Functions include:

- **Soy Milk:** For making fresh soy milk.
- **Oat Milk:** For making fresh oat milk.
- **Nut Milk:** For making various nut milks (e.g., almond, cashew).
- **Smoothie:** For blending fruits and vegetables into smoothies.
- **Soup:** For preparing hot soups.
- **Hot Cereal:** For cooking hot cereals.
- **Juice:** For making fresh juices.
- **Sterilize:** For sanitizing the pitcher.
- **Auto Clean:** For quick internal cleaning.
- **Keep Warm:** Maintains the temperature of hot beverages.
- **Timer:** Allows scheduling operation up to 18 hours in advance.

4. SETUP

Before first use, ensure all packaging materials are removed. Clean the pitcher and lid according to the 'Cleaning and Maintenance' section.

4.1 Initial Assembly

1. Place the main unit on a stable, flat, and dry surface.
2. Ensure the pitcher is clean and dry before adding ingredients.
3. Carefully place the lid onto the pitcher, ensuring it is properly aligned and securely seated. The appliance will display an 'E2' error if the lid is not correctly positioned, indicating a safety measure.



Image 4.1: Proper lid alignment is crucial for operation. The display shows 'E2' if the lid is not correctly induced for safety.

5. OPERATING INSTRUCTIONS

The BHG Nut and Soy Milk Maker offers a simple three-step process for most functions.



Image 5.1: Visual guide for basic operation: Step 1: Add ingredients (e.g., soybeans). Step 2: Add 1-2 cups of water. Step 3: Select a mode and press Start/Stop.

5.1 General Operation Steps

1. **Add Ingredients:** Place your desired ingredients (e.g., soybeans, nuts, fruits) into the stainless steel pitcher.
2. **Add Water:** Pour the appropriate amount of water into the pitcher. Do not exceed the maximum fill line. The capacity is 45oz (approximately 6 cups).
3. **Secure Lid:** Place the lid firmly on the pitcher, ensuring it is correctly aligned.
4. **Select Function:** Press the 'Menu' button repeatedly to cycle through the available functions on the LED touch screen until your desired mode is selected.
5. **Start Operation:** Press the 'Start/Stop' button to begin the selected program.
6. **Completion:** The appliance will signal when the program is complete. Carefully remove the lid and pour the contents.

5.2 Using the Timer Function

The 18-hour timer allows you to schedule your beverage preparation in advance.



Image 5.2: The delay start timer allows you to set a future time for your beverage to be ready, up to 18 hours in advance.

1. Add ingredients and water as per the desired recipe.
2. Select your desired function using the 'Menu' button.
3. Press the 'Timer' button. Use the '+' and '-' buttons (if available, or cycle through 'Timer' button presses) to set the delay time.
4. Press 'Start/Stop' to confirm the timer setting. The appliance will begin operation after the set delay.

5.3 Keep Warm Function

After certain hot programs, the appliance can automatically enter a 'Keep Warm' mode to maintain the temperature of your beverage. This function has no time limit, ensuring your drink stays ready when you are.

5.4 Recipe Examples

Here are a few examples of recipes you can make with your BHG Nut and Soy Milk Maker:

Soy Milk



Ingredients: 1 tbsp yellow soybeans, 1 cup water, 1 tbsp maple syrup or honey, 1/4 tsp vanilla extract.

Almond Milk



Align upper cover induction for starting, or E2 displayed for safety.



Ingredients: 2 tbsp almonds, 1 pitted date, 1 cup water, 1/4 tsp vanilla extract, pinch of salt.

Maple Brown Sugar Oats

HOW TO USE



STEP1
Add almonds or soybeans



STEP2
Add 1-2 cup of water



STEP3
Select mode to start running

Ingredients: 1/3 cup rolled oats, 1 tbsp maple syrup, 800ml water, 1 tbsp brown sugar.

Broccoli Cheddar Soup



Ingredients: 1 cup chopped broccoli, 1/2 small onion, 3/4 cup milk or veggie broth, 1/4 cup shredded cheddar cheese.

Coconut Milk Coffee



Ingredients: 4 tbsp cashews, 1 cup water, 1.5 tsp cocoa powder, 1 tbsp coconut sugar.

6. CLEANING AND MAINTENANCE

Regular cleaning ensures the longevity and hygienic operation of your appliance.

6.1 Automatic Self-Cleaning

The appliance features a 120-second self-cleaning mode for quick and easy maintenance.



Image 6.1: The appliance's interior during the 120-second auto-clean cycle, showing water swirling to clean the blades and pitcher walls.

1. After use, empty the pitcher.
2. Add a small amount of water (and a drop of dish soap, if desired) to the pitcher.
3. Select the 'Auto Clean' function on the control panel.
4. Press 'Start/Stop'. The cycle will run for 120 seconds.
5. Once complete, rinse the pitcher thoroughly with clean water.

6.2 Manual Cleaning

- **Always unplug the appliance before cleaning.**
- **Pitcher and Lid:** These components are recommended for hand washing only. Use a soft brush or sponge with mild dish soap and warm water. Rinse thoroughly.
- **Main Unit:** Wipe the exterior of the main unit with a damp cloth. Do not immerse the main unit in water or any other liquid.
- Ensure all parts are completely dry before storing or next use.

7. TROUBLESHOOTING

If you encounter issues with your appliance, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Appliance does not turn on.	Not plugged in; power outlet issue; lid not properly secured.	Ensure the power cord is securely plugged into a working outlet. Check that the lid is correctly aligned and fully closed.
"E2" error displayed.	Lid is not properly aligned or secured.	Remove the lid and re-align it carefully until it is securely seated and the error disappears.
Milk/beverage is not smooth.	Insufficient grinding time; too many ingredients; not enough water.	Ensure ingredients are within recommended quantities. Add sufficient water. For tougher ingredients, consider soaking them beforehand or running the cycle again.
Unusual noise during operation.	Overfilling; foreign object in pitcher; appliance not on a stable surface.	Do not exceed the MAX fill line. Check for any foreign objects. Ensure the appliance is on a flat, stable surface.
Self-cleaning function not effective.	Heavy residue; insufficient water.	For heavy residue, pre-rinse the pitcher. Add a small amount of dish soap with water during the auto-clean cycle. Manual cleaning may be required for stubborn stains.

8. SPECIFICATIONS

Feature	Detail
---------	--------

Feature	Detail
Brand	BUAIAHUG
Model Name	bhg-01
Capacity	45 oz (approx. 1.3 Liters)
Material	Stainless Steel (interior)
Color	White
Item Weight	3.8 pounds
Package Dimensions	12.48 x 7.87 x 7.72 inches
Special Features	14-Blade Grinder, 11 Functions, LED Touch Screen, 18H Timer, Keep Warm, Self-Cleaning
Product Care	Hand Wash Only (pitcher and lid)
Included Components	Lid

9. WARRANTY AND SUPPORT

Warranty information for the BUAIAHUG BHG 45oz Automatic Nut and Soy Milk Maker is not provided within this manual. Please refer to the product packaging, the retailer's website, or contact BUAIAHUG customer support directly for detailed warranty terms and conditions.

For technical support, troubleshooting assistance beyond what is listed in this manual, or to inquire about replacement parts, please contact BUAIAHUG customer service through their official channels.