Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- Tineco /
- Tineco FLOOR ONE S6 Stretch Steam Corded Wet Dry Vacuum Steam Mop Instruction Manual

Tineco FLOOR ONE S6 Stretch Steam

Tineco FLOOR ONE S6 Stretch Steam Corded Wet Dry Vacuum Steam Mop Instruction Manual

1. Introduction

Thank you for choosing the Tineco FLOOR ONE S6 Stretch Steam Corded Wet Dry Vacuum Steam Mop. This all-in-one cleaning solution is designed to simplify your floor care routine by combining vacuuming, mopping, and high-temperature steam cleaning. Please read this instruction manual thoroughly before use to ensure safe and optimal operation of your appliance.

2. IMPORTANT SAFETY INSTRUCTIONS

When using an electrical appliance, basic precautions should always be followed to avoid fire, electric shock, or injury. Please observe the following:

- · Read all instructions before using the appliance.
- Do not immerse the appliance in water or other liquids.
- Do not leave the appliance unattended when plugged in. Unplug from outlet when not in use and before servicing.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Keep cord away from heated surfaces.
- Do not allow children to play with the appliance. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Always disconnect the appliance from the electrical outlet before filling with water.
- Do not direct steam at people, animals, or electrical outlets.
- Use caution when using the appliance on stairs.
- · Do not use the appliance in enclosed spaces where explosive or toxic vapors are given off.
- Do not use on leather, wax polished furniture or floors, synthetic fabrics, velvet or other delicate, steam-sensitive materials.

• Do not use cleaning solutions other than those recommended by Tineco.

3. PACKAGE CONTENTS

Your Tineco FLOOR ONE S6 Stretch Steam package includes the following items:

- Main Unit (with Dirty Water Tank and Clean Water Tank installed)
- Handle
- ZeroTangle Brush (pre-installed)
- Replacement Brush Roller
- Dry Filter (pre-installed)
- Cleaning Tool
- Drying & Charging Dock




Figure 1: All included components of the Tineco FLOOR ONE S6 Stretch Steam.

4. SETUP

4.1 Assembling the Main Unit

- 1. Insert the handle into the main unit until you hear a click. Ensure it is securely fastened.
- 2. Place the main unit onto the Drying & Charging Dock. Connect the power adapter to the dock and plug it into a wall outlet.

4.2 Filling the Clean Water Tank

- 1. Press the Clean Water Tank release button and remove the tank from the main unit.
- 2. Open the tank cap and fill with cold tap water up to the MAX line. Do not use hot water.
- 3. If desired, add one capful of Tineco cleaning solution to the clean water tank. Do not use other cleaning solutions.
- 4. Close the tank cap securely and reinsert the Clean Water Tank into the main unit until it clicks into place.



Figure 2: The Tineco FLOOR ONE S6 Stretch Steam fully assembled and ready for charging.

5. OPERATING INSTRUCTIONS

5.1 Powering On and Steam Preparation

- 1. Ensure the appliance is plugged into a power outlet.
- 2. Press the Power Button on the handle to turn on the appliance.
- 3. The appliance will begin heating the water for steam. This process typically takes around 60 seconds for the first use and about 45 seconds for subsequent uses. The display will indicate when steam is ready.



Figure 3: The appliance heating water for 320°F high-temperature steam cleaning.

5.2 Cleaning Modes and Features

- **Tineco BoostSteam Technology:** High-pressure steam instantly liquefies stubborn grime, grease, and deep-seated dirt effortlessly.
- 320°F High-Temp Steam Cleaning: Heats steam up to 320°F, ensuring the outlet temperature does not fall below 210°F, effectively dissolving stubborn grease and stains.

- **iLoop Smart Sensor:** The intelligent iLoop sensor detects dirt on your floor and automatically adjusts suction power and water flow for optimal cleaning efficiency. The LED display will change color (red for dirty, blue for clean) to indicate the floor's cleanliness.
- 180° Lay-Flat Design: With a slimmer body and a height of just 5.1 inches when laid flat, the appliance easily maneuvers under furniture and into low areas to clean hidden dust.
- **Dual-sided Edge Cleaning:** The brush head is designed to effectively clean along baseboards, ensuring that every corner is thoroughly cleaned.
- 326 inches Extended Reach: The extra-long cord allows you to clean large areas continuously without unplugging interruptions.



Figure 4: BoostSteam Technology in action, showing steam dissolving grime.



Figure 5: The 180° Lay-Flat Design allows easy cleaning under low furniture.



Figure 6: Dual-sided edge cleaning for thorough cleaning along walls.

Your browser does not support the video tag.

Video 1: Official Tineco video demonstrating the FLOOR ONE S6 Stretch Steam's features, including steam cleaning and maneuverability.

6. MAINTENANCE

6.1 One-Touch Self-Cleaning System

After each cleaning session, place the appliance on the Drying & Charging Dock and press the self-cleaning button on the handle. The appliance will automatically perform a self-cleaning cycle:

1. Step 1: Self-cleaning with Steam & Heated Water: Using steam and fresh heated water, the

system effectively dissolves stains from the pipe to the brush roller, providing a superior self-cleaning result

2. **Step 2: Centrifugal Air Drying:** The system effectively removes water from the brush roller for a hygienic, odor-free home.



Figure 7: The appliance automatically cleans its brush roller and internal pipes.

6.2 Emptying the Dirty Water Tank

The Dirty Water Tank should be emptied after each use. Press the release button and remove the tank. Open the lid and dispose of the dirty water and debris. Rinse the tank with clean water and allow it to air dry before reinserting.

6.3 Cleaning the Brush Roller and Filter

Regularly inspect and clean the brush roller and dry filter to maintain optimal performance. The brush roller

can be removed by opening the brush cover. Wash the brush roller and filter with water and allow them to air dry completely before reinstallation. Replace the brush roller every 3-6 months and the filter every 2-3 months, or as needed.

7. TROUBLESHOOTING

If you encounter any issues with your Tineco FLOOR ONE S6 Stretch Steam, please refer to the following common troubleshooting tips:

- **No Power:** Ensure the power cord is securely plugged into a working outlet and the charging dock. Check for any tripped circuit breakers.
- **No Steam:** Verify that the Clean Water Tank is filled with water and properly installed. Allow sufficient time (up to 60 seconds) for the appliance to heat up.
- **Poor Suction:** Check if the Dirty Water Tank is full and needs emptying. Ensure the brush roller and filter are clean and free from blockages.
- **Unpleasant Odor:** Regularly empty and clean the Dirty Water Tank, brush roller, and filter. Run the self-cleaning cycle after each use.
- **Appliance Not Charging:** Ensure the appliance is correctly placed on the Drying & Charging Dock and the power adapter is connected.

For persistent issues, please contact Tineco Customer Support.

8. Specifications

Feature	Specification
Brand	Tineco
Model Name	Floor One S6 Stretch Steam
Special Features	BoostSteam Technology, 320°F HyperSteam, DualBlock Anti-Tangle Design, Self-cleaning System, LED Headlight
Surface Recommendation	Hard Floor, Hardwoods, Laminate, Multi Surface
Power Source	Corded Electric
Voltage	120 Volts
Capacity (Clean Water Tank)	1 Liter
Capacity (Dirty Water Tank)	0.72 Liters
Item Weight	9.48 pounds
Product Dimensions	12.44"D x 11.42"W x 28.27"H

9. WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the official Tineco website or the warranty

card included in your product packaging. You can also visit the Tineco Store on Amazon for additional resources.

Related Documents - FLOOR ONE S6 Stretch Steam



Tineco FLOOR ONE i6 STRETCH SERIES Cordless Floor Washer User Manual

This user manual provides comprehensive instructions for the Tineco FLOOR ONE i6 STRETCH SERIES Cordless Floor Washer. It covers essential safety precautions, detailed operation guides, maintenance procedures, troubleshooting tips, technical specifications, and warranty information to ensure optimal use and care of the appliance.



Tineco FLOOR ONE S7 STRETCH SERIES Smart Cordless Floor Washer User Manual

User manual for the Tineco FLOOR ONE S7 STRETCH SERIES Smart Cordless Floor Washer, offering setup, operation, safety, and maintenance guidance for efficient hard floor cleaning.



Tineco FLOOR ONE SWITCH S7 STRETCH SERIES Smart Cordless Floor Washer User Manual

Comprehensive user manual for the Tineco FLOOR ONE SWITCH S7 STRETCH SERIES Smart Cordless Floor Washer, covering safety, setup, operation, maintenance, troubleshooting, and warranty information. This guide provides detailed instructions for optimal use and care of your Tineco floor washer.



Tineco FLOOR ONE S6 STRETCH STEAM SERIES Manuale Utente

Manuale utente completo per il Tineco FLOOR ONE S6 STRETCH STEAM SERIES, una lavapavimenti a vapore intelligente. Include istruzioni di sicurezza, funzionamento, manutenzione e risoluzione dei problemi.



Tineco FLOOR ONE S7 STRETCH SERIES Smart Cordless Floor Washer User Manual

Comprehensive user manual for the Tineco FLOOR ONE S7 STRETCH SERIES Smart Cordless Floor Washer. This guide provides detailed information on safety instructions, product specifications, component presentation, accessories, assembly, operation, maintenance, troubleshooting, and warranty.



Tineco FLOOR ONE STRETCH S6/S5 Series Smart Cordless Floor Washer Manual

User manual for the Tineco FLOOR ONE STRETCH S6, S6 STRETCH, and S5 STRETCH series smart cordless floor washers. Includes safety instructions, specifications, general description, accessories, assembly, operation, maintenance, troubleshooting, and warranty information.