

[Manuals.plus](#) /

› [Philips](#) /

› Philips Lady Shaver Series 8000 BRL149/00 User Manual

## Philips BRL149/00

# Philips Lady Shaver Series 8000 BRL149/00 User Manual

Model: BRL149/00

## 1. INTRODUCTION

Thank you for choosing the Philips Lady Shaver Series 8000. This electric shaver is designed for comfortable and efficient hair removal on your legs, body, and bikini area. It features a flexible shaving head, an integrated LED light, and a 3-blade system for a smooth experience. Please read this manual carefully before first use and retain it for future reference.

### Package Contents

The Philips Lady Shaver Series 8000 BRL149/00 package typically includes the following items:

- Philips Lady Shaver Series 8000 (Main Unit)
- Shaving Head
- Bikini Trimmer Head
- Trimming Comb
- Bikini Comb (3mm)
- Pouch
- Exfoliating Glove
- Power Cable (adapter not included)



**SHAVING  
HEAD**



**BIKINI  
TRIMMER  
HEAD**



**POUCH**



**TRIMMING  
COMB**



**BIKINI  
COMB**



**EXFOLIATING  
GLOVE**

Image: Overview of the Philips Lady Shaver Series 8000 and its included accessories.

## 2. SAFETY INFORMATION

Please observe the following safety precautions to prevent injury or damage to the appliance:

- Always hold the shaver away from your face and body while charging.
- Do not use or charge the shaver near water.
- To prevent skin irritation, do not use on broken skin or irritated areas.
- Always replace the foil once a year for optimal performance and safety.
- Dispose of the shaver and batteries according to local regulations to protect the environment.

## 3. SETUP

### Charging the Shaver

Before first use, fully charge the shaver. A full charge takes approximately 8 hours and provides up to 100 minutes of

cordless runtime.

1. Ensure the shaver is dry before charging.
2. Connect the power cable to the shaver and plug it into a wall outlet.
3. The charging indicator light will illuminate to show that the shaver is charging.
4. Once fully charged, disconnect the power cable.

**Note:** A power adapter is not included with this product. Use a compatible USB power adapter.

## 4. OPERATING INSTRUCTIONS

### Preparation for Shaving

For optimal results and to help prevent ingrown hairs, it is recommended to exfoliate your skin before shaving.



## PREVENT NICKS & CUTS

Rounded trimmer tips glide smoothly over the skin and prevent nicks & cuts




Image: Using the exfoliating glove to prepare skin for shaving.

### Shaving Techniques

The Philips Lady Shaver Series 8000 can be used for both wet and dry shaving. Choose the method that best suits your preference and routine.



## FAST & EASY

Shave Up. Shave Down.  
Shave yourself free of hair  
in only 7 minutes<sup>3</sup>




Image: Demonstrating wet shaving with the Philips Lady Shaver.

- **Wet Shaving:** Use with water, foam, or gel for a comfortable shave, especially in the shower or bath.
- **Dry Shaving:** Convenient for quick touch-ups or when you are on the go.

To achieve the best results:

1. Ensure your skin is clean. If using wet, apply shaving foam or gel.
2. Turn on the shaver. The integrated LED light will illuminate to help you spot fine hairs.

SPOT IT  
SHAVE IT  
LOVE IT

LED light makes  
sure no hair  
hides from you



Image: The shaver's LED light helps reveal fine hairs for a thorough shave.

3. Gently press the shaver against your skin and move it slowly against the direction of hair growth. The flexible shaving head will adapt to your body contours.

# FLEXIBLE SHAVING HEAD

follows your body countours.  
Even on hard-to-reach areas<sup>1</sup>



Image: The flexible shaving head adapts to body curves for efficient hair removal.

4. You can shave in both up and down motions as preferred.
5. For longer hairs, pre-trimming with the trimming comb may improve efficiency.
6. For the bikini area, attach the bikini trimmer head and use the bikini comb for precise styling.

## Speed Settings

The shaver features two speed settings, allowing you to adjust the intensity of hair removal for different areas or skin sensitivities. Press the power button to cycle between the two settings.

## 5. MAINTENANCE

### Cleaning the Shaver

Regular cleaning ensures optimal performance and hygiene.

1. After each use, turn off the shaver and detach the shaving head.
2. Rinse the shaving head and the shaver body under running water.
3. Shake off excess water and allow all parts to air dry completely before reassembling or storing.

4. Do not use abrasive cleaning agents or harsh chemicals.

## Replacing the Shaving Foil

For continued optimal performance and a comfortable shave, it is recommended to replace the shaving foil once a year. Replacement foils can be purchased from authorized Philips retailers or online.

## 6. TROUBLESHOOTING

If you encounter any issues with your Philips Lady Shaver, please refer to the following common solutions:

- **Shaver not turning on:** Ensure the shaver is fully charged. If the battery is low, connect it to the power cable and charge for 8 hours.
- **Reduced shaving performance:** The shaving foil may be worn or clogged with hair. Clean the shaving head thoroughly or replace the foil if it has been used for over a year.
- **Skin irritation:** Ensure you are shaving against the direction of hair growth and not applying excessive pressure. Exfoliating before shaving can also help. If irritation persists, consult a dermatologist.
- **Shaver not charging:** Check if the power cable is securely connected to both the shaver and the power outlet. Ensure the outlet is functional.

If the problem persists after trying these steps, please contact Philips customer support for further assistance.

## 7. SPECIFICATIONS

Feature	Specification
Model Number	BRL149/00
Power Source	Battery Powered
Battery Type	Rechargeable
Runtime	Up to 100 minutes
Charging Time	8 hours
Shaving System	3-Blade System with Dual-sided Trimmer Tips
Features	Cordless, Wet & Dry Use, Flexible Shaving Head, LED Light, 2 Speed Settings
Recommended Use	Legs, Body, Bikini Line, Underarm
Dimensions (Package)	7.44 x 5.04 x 2.48 inches
Weight (Package)	9.92 ounces

## 8. WARRANTY AND SUPPORT

### Warranty Information

This Philips Lady Shaver Series 8000 comes with a 2-year limited warranty from the date of purchase. Please retain your proof of purchase for warranty claims. The warranty covers defects in materials and workmanship under normal use.

## Customer Support

For further assistance, product registration, or to find replacement parts, please visit the official Philips Norelco website or contact their customer service department.

Official Philips Norelco Store: [Visit Store](#)

