Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- duraflame /
- duraflame Electric Fireplace TV Stand User Manual

duraflame Electric Fireplace TV Stand

duraflame Electric Fireplace TV Stand User Manual

Model: Electric Fireplace TV Stand

1. Introduction

This manual provides essential instructions for the safe assembly, operation, and maintenance of your duraflame Electric Fireplace TV Stand. Please read all instructions carefully before use and retain this manual for future reference.



Image 1.1: The duraflame Electric Fireplace TV Stand, showcasing its central fireplace unit, glass-front storage cabinets, and overall black finish.

2. IMPORTANT SAFETY INFORMATION

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, and injury to persons.

- Read all instructions before using this appliance.
- Do not operate any heater with a damaged cord or plug, or after the heater malfunctions or has been dropped or damaged in any manner.
- Do not use outdoors. This product is for indoor use only.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater and away from the sides and rear.
- To prevent a possible fire, do not block air intakes or exhaust in any manner.
- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- This product features patented Safer Plug technology, which monitors the temperature of the plug to prevent overheating. If the plug overheats, it will automatically shut off power to the unit.

3. PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, do not attempt to assemble the unit. Contact customer support for assistance.

- duraflame Electric Fireplace TV Stand Unit
- Remote Control (with 1 CR2025 Battery)
- User Manual (this document)
- Assembly Hardware (screws, dowels, etc. quantity may vary)

4. ASSEMBLY AND SETUP

Assembly typically requires two adults. Ensure you have adequate space and the necessary tools (e.g., Phillips head screwdriver) before starting.

4.1 Unpacking and Preparation

- 1. Carefully remove all components from the packaging.
- 2. Place all parts on a soft, clean surface (e.g., a blanket or carpet) to prevent scratches.
- 3. Identify and separate all hardware components.

4.2 Assembly Steps

Follow the detailed assembly diagrams provided in the separate assembly guide included with your product. General steps include:

- Attaching the base and legs.
- · Assembling the main cabinet structure.
- · Installing the glass shelves and doors.
- Inserting the electric fireplace insert into the central opening.
- Connecting any internal wiring for LED lighting (if applicable and not pre-assembled).

4.3 Placement and Electrical Connection

- Place the assembled TV stand on a firm, level surface.
- Ensure adequate clearance around the unit for proper ventilation and safety (refer to safety guidelines).
- The TV stand supports TVs up to 65 inches. Ensure your television's base fits securely on the top surface.
- Plug the power cord directly into a 120V, 15 Amp grounded outlet. Do not use extension cords or power strips.



Image 4.1: Dimensional view of the TV stand, indicating a width of 59.5 inches, height of 28 inches, and depth of 15.5 inches.

5. Operating Instructions

Your duraflame Electric Fireplace TV Stand can be operated using the control panel on the unit or the included remote control.

5.1 Remote Control Functions



Image 5.1: The remote control, showing buttons for Power, Timer, Temperature, and Flame Effect.

- Power Button (O): Turns the fireplace unit ON or OFF.
- **Timer Button (hourglass icon):** Activates the sleep timer function. Press repeatedly to cycle through timer settings (e.g., 30 minutes, 1 hour, up to 9 hours).
- Temperature Up/Down Buttons (arrows): Adjusts the thermostat setting for the heater.
- Flame Effect Button (flame icon): Cycles through different flame brightness settings.
- **LED Light Button (light bulb icon):** Cycles through various LED accent lighting colors and effects for the storage compartments.

5.2 Unit Control Panel



Image 5.2: Close-up of the unit's control panel, featuring a digital display and touch-sensitive buttons for operation. The control panel on the fireplace insert mirrors the functions of the remote control. Press the corresponding icons to adjust settings.

5.3 Fireplace Operation

- Turning On/Off: Press the Power button on the remote or control panel.
- Adjusting Heat: Use the Temperature Up/Down buttons to set your desired room temperature. The heater will cycle on and off to maintain this setting. The infrared heater can warm up to 1,000 square feet.
- Adjusting Flame Effect: Press the Flame Effect button to cycle through various brightness levels of the 3D flame effect. The flame effect can be operated independently of the heat.

5.4 LED Accent Lighting

The TV stand features integrated LED accent lighting in the storage compartments. Use the LED Light button on the remote or control panel to:

- Turn the LED lights ON/OFF.
- Cycle through multiple color options (e.g., blue, green, red, purple, yellow, etc.).



6. MAINTENANCE

Regular maintenance ensures optimal performance and longevity of your electric fireplace TV stand.

6.1 Cleaning

- · Always unplug the unit before cleaning.
- Wipe the exterior surfaces with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Clean the glass doors and fireplace screen with a glass cleaner, applied to a cloth first, not directly to the unit.
- Periodically vacuum the air intake and exhaust vents to prevent dust buildup.

6.2 Remote Control Battery Replacement

The remote control uses one CR2025 battery. To replace:

- 1. Locate the battery compartment on the back of the remote.
- 2. Slide the battery tray out.
- 3. Remove the old battery and insert a new CR2025 battery with the positive (+) side facing up.
- 4. Slide the battery tray back into place until it clicks.

7. TROUBLESHOOTING

If you experience issues with your electric fireplace TV stand, refer to the following common problems and solutions.

| Problem | Possible Cause | Solution |
|--|--|---|
| Unit does not turn on. | Not plugged in; power outlet not working; circuit breaker tripped; Safer Plug activated. | Ensure unit is securely plugged into a working, grounded outlet. Check household circuit breaker. Unplug and replug the unit to reset Safer Plug. |
| No heat, but flames are visible. | Heater function is off; thermostat set too low; air vents blocked. | Increase the thermostat setting. Ensure air intake/exhaust vents are clear of obstructions. |
| Remote control not working. | Battery depleted; remote not aimed at sensor; obstruction. | Replace the CR2025 battery. Ensure clear line of sight to the fireplace unit's sensor. |
| Flame effect is dim or not working. | Flame brightness setting is low; LED component issue. | Press the Flame Effect button to cycle through brightness levels. If issue persists, contact customer support. |

8. Specifications

• Brand: duraflame

• Model: Electric Fireplace TV Stand

• Product Dimensions: 39.4D x 151.1W x 71.1H Centimetres (15.5D x 59.5W x 28H Inches)

• Item Weight: 116.6 Pounds

• Material: MDF, PB, Glass, Metal Iron, Hardware Iron, Plastic

• Finish Type: Black

• Power Source: Corded Electric

• Heater Coverage: Up to 1,000 square feet

• TV Size Support: Up to 65 inches

• Special Features: 3D Flame Effect, LED Accent Lighting, Patented Safer Plug Technology, Independent Flame and Heat Controls

• Batteries Required: Yes (1 x CR2025 for remote control)

• Manufacturer: Twin-Star International, Inc.

9. WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your product or visit the official duraflame website. If you require technical assistance or have questions not covered in this manual, please contact Twin-Star International, Inc. customer support.

Contact Information: Refer to your product packaging or the manufacturer's official website for the most current support details.

© 2025 duraflame. All rights reserved.

Related Documents - Electric Fireplace TV Stand



<u>Duraflame 23MM4469 Electric Fireplace TV Stand User Manual</u>

Comprehensive user manual and assembly guide for the Duraflame 23MM4469 Electric Fireplace TV Stand. Includes safety instructions, operation details, care, and troubleshooting tips from Twin-Star International Inc.

duraflame



<u>Duraflame 28MM7281 Electric Fireplace TV Stand Owner's Manual</u>



This Duraflame 28MM7281 Electric Fireplace TV Stand owner's manual provides comprehensive instructions for assembly, operation, safety, troubleshooting, and warranty. Learn how to install and enjoy your Duraflame electric fireplace media console.

duraflame



<u>Duraflame 23MM1495 Electric Fireplace TV Stand - Assembly and User Manual</u>

Comprehensive assembly and user manual for the Duraflame 23MM1495 Electric Fireplace TV Stand. Includes safety information, parts list, assembly instructions, operation details, troubleshooting, and warranty information.

duraflame



<u>Duraflame DFI041ARU-2 Electric Fireplace User Manual and Instructions</u>

Comprehensive user manual for the Duraflame DFI041ARU-2 electric fireplace, covering setup, operation, safety instructions, troubleshooting, maintenance, and warranty information.

worst. worst. worst. www.tsicustomerservic.com

Duraflame 48HF201CGT Electric Fireplace User Manual and Installation Guide

Comprehensive user manual and installation guide for the Duraflame 48HF201CGT electric fireplace, covering safety instructions, setup, operation, troubleshooting, and replacement parts.

duraflame



<u>Duraflame 23MM7537 Electric Fireplace Entertainment Center User Manual</u>

Comprehensive user manual and assembly guide for the Duraflame 23MM7537 Electric Fireplace Entertainment Center, including safety instructions, operation details, and troubleshooting tips. Manufactured by Twin-Star International, Inc.