

CAFELFFE MK-611

CAFELFFE MK-611 Multi-Capsule Coffee Machine User Manual

Model: MK-611

[Components](#) [Setup](#) [Operation](#) [Maintenance](#) [Safety Instructions](#) [Product](#) [Troubleshooting](#) [Specifications](#) [Warranty & Support](#)

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using the appliance. Retain this manual for future reference.

- Ensure the voltage rating on the appliance matches your local power supply.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Keep the appliance out of reach of children.
- Unplug from the outlet when not in use and before cleaning.
- Do not operate any appliance with a damaged cord or plug.
- Use only accessories recommended by the manufacturer.
- Do not use outdoors.
- Place the appliance on a stable, flat surface.
- Avoid contact with hot surfaces.
- Do not open the brewing chamber during operation.

PRODUCT COMPONENTS

Familiarize yourself with the parts of your CAFELFFE MK-611 coffee machine.



Image: Overview of the Cafelffe MK-611 coffee machine, showing its compact design and the three different capsule adapters for Nes Original, DG, and ground coffee.

- **Water Tank:** Removable, 600ml capacity.
- **Brewing Head:** Where capsules/ground coffee adapter are inserted.
- **Control Panel:** Power button, brew size selection (70ml/110ml), hot/cold brew selection.
- **Drip Tray:** Removable for easy cleaning and height adjustment.
- **Cup Stand:** Adjustable 3-tier height (7-11cm).
- **Capsule Adapters:**
 - Nes Original compatible adapter
 - DG compatible adapter
 - Ground Coffee adapter (for 12-14g fine coffee powder)
- **Cleaning Pin:** For clearing blockages.
- **Pump Pipe:** (Internal component, not user-serviceable)
- **Dual-Purpose Coffee Powder Scoop:** For measuring ground coffee.



Image: Detailed view of the packing list, showing the coffee maker, three capsule adapters (Nes Original, DG, Ground), cleaning pin, pump pipe, user manual, and dual-purpose coffee powder scoop.

INITIAL SETUP

1. **Unpacking:** Carefully remove all components from the packaging. Retain packaging for future transport or storage.
2. **Cleaning:** Wash the water tank, drip tray, and capsule adapters with warm, soapy water. Rinse thoroughly and dry.
3. **Placement:** Place the machine on a stable, flat, heat-resistant surface near a power outlet. Ensure adequate ventilation.
4. **Fill Water Tank:** Fill the water tank with fresh, cold drinking water up to the MAX line. Do not exceed the MAX line.
5. **First Use Cycle (Priming):**
 - Plug the machine into a grounded power outlet.
 - Place a large cup (at least 200ml) on the drip tray.
 - Do not insert any capsule or ground coffee adapter.
 - Press the power button to turn on the machine. It will preheat.
 - Once preheated, press either the 70ml or 110ml brew button. The machine will dispense hot water. Repeat this process 2-3 times to flush the internal system.

OPERATING INSTRUCTIONS

Brewing Coffee (Hot)

1. **Fill Water Tank:** Ensure the water tank is filled with fresh, cold water.
2. **Power On:** Plug in the machine and press the power button. Wait for the machine to preheat (indicator light will stabilize).
3. **Insert Adapter:**
 - **For Capsules (Nes Original/DG):** Open the brewing head, insert the appropriate capsule adapter, then place the capsule into the adapter. Close the brewing head firmly.
 - **For Ground Coffee:** Open the brewing head, insert the ground coffee adapter. Use the scoop to add 12-14g of fine ground coffee into the adapter. Tamp lightly if desired. Close the brewing head firmly.
4. **Adjust Cup Stand:** Adjust the cup stand height (7cm, 9cm, or 11cm) to fit your cup.
5. **Select Brew Size:** Place your cup on the drip tray. Press either the 70ml (ristretto) or 110ml (lungo) button. The

machine will begin brewing.

6. **Enjoy:** Once brewing is complete, remove your cup. The machine will automatically shut off after 15 minutes of inactivity.



Image: The Cafelffe MK-611 coffee machine demonstrating the use of a DG capsule adapter, highlighting its multi-capsule compatibility.

Adjustable Cup Holder

Cup With Drip Tray

7cm/2.76inch



Cup With Drip Tray

9cm/3.54inch



Cup Without Drip Tray

11cm/4.33inch



**The above data is tested by CAFELFFE laboratory. There may be errors in the data. It is for reference only. Please refer to the actual data.*

Image: The Cafelffe MK-611 coffee machine demonstrating the use of a Nes capsule adapter, showcasing its versatility.



Image: The Cafelife MK-611 coffee machine demonstrating the use of the ground coffee adapter, illustrating its 3-in-1 functionality.

Brewing Coffee (Cold)

The machine supports cold extraction for iced beverages.

1. Follow steps 1-4 for hot brewing.
2. **Select Cold Brew Mode:** Press the dedicated cold brew button (refer to specific button combination in the machine's quick guide). The indicator light will change to signify cold brew mode.
3. **Select Brew Size:** Press either the 70ml or 110ml button. The machine will dispense cold water through the capsule/ground coffee.
4. **Enjoy:** Add ice and any desired additions to your cold brew.

3-In-1 Hot & Cold Espresso Brewing Machine

One-Touch Fully Automatic Operation



Image: Illustration of the Cafelife MK-611's hot and cold extraction modes, showing temperature ranges for optimal brewing.

Customizing Cup Sizes (Memory Function)

The machine allows you to program your preferred brew volume for the 70ml and 110ml buttons.

1. Place a cup under the dispenser.
2. Press and hold the desired brew size button (70ml or 110ml).
3. Release the button when the desired volume of coffee has been dispensed into your cup. The machine will memorize this setting for future use with that button.

CUSTOMIZABLE CUP SIZES

Program the cup sizes as you need



Image: The Cafelffe MK-611 coffee machine demonstrating customizable cup sizes, with options for 70ml (small) and 110ml (large) brews.

CARE AND MAINTENANCE

Daily Cleaning

- **Drip Tray:** Empty and rinse the drip tray after each use or when full.
- **Water Tank:** Empty and rinse the water tank daily. Refill with fresh water.
- **Capsule Adapters:** Remove and rinse the used capsule adapter after each brew. For ground coffee adapter, discard grounds and rinse thoroughly.
- **Exterior:** Wipe the exterior of the machine with a damp, soft cloth. Do not use abrasive cleaners.

Auto-Cleaning System

The machine features a 120-second auto-clean function.

1. Ensure the water tank is filled.
2. Place a large empty cup under the dispenser.
3. Refer to your quick start guide for the specific button combination to activate the auto-clean cycle. Typically, this

involves pressing and holding two buttons simultaneously.

4. The machine will run hot water through its system for approximately 120 seconds.
5. Discard the water from the cup.



Image: The Cafelife MK-611 coffee machine demonstrating its 120-second auto-cleaning system, showing water being dispensed into a cup.

Descaling

It is recommended to descale the machine every 3 months, or more frequently in areas with hard water, to prevent mineral buildup and maintain performance.

1. Empty the water tank.
2. Fill the water tank with a descaling solution suitable for coffee machines (follow descaler manufacturer's instructions for dilution).
3. Place a large container under the dispenser.
4. Activate the descaling cycle (refer to your quick start guide for specific instructions, as this often involves a unique button sequence).
5. Once the descaling solution has run through, rinse the water tank thoroughly and fill with fresh water.
6. Run 2-3 cycles with fresh water to flush out any remaining descaling solution.

TROUBLESHOOTING GUIDE

| Problem | Possible Cause | Solution |
|-----------------------------------|--|--|
| Machine does not turn on. | No power supply. | Check if the power cord is securely plugged into a working outlet. |
| No coffee dispenses. | Water tank empty; brewing head not closed; nozzle blocked. | Fill water tank; ensure brewing head is firmly closed; use cleaning pin to clear nozzle. |
| Coffee is cold or not hot enough. | Machine not preheated; cold brew mode selected. | Wait for preheating indicator; ensure hot brew mode is selected. |
| Water leaks from machine. | Water tank not properly seated; drip tray full. | Re-seat water tank; empty drip tray. |

| Problem | Possible Cause | Solution |
|-------------------------------|--|--|
| Coffee tastes weak or watery. | Incorrect capsule/ground coffee amount; machine needs descaling. | Ensure correct capsule or 12-14g ground coffee; perform descaling. |

If the problem persists after attempting these solutions, please contact customer support.

PRODUCT SPECIFICATIONS

- **Model:** MK-611
- **Brand:** CAFELFFE
- **Power:** 1450 Watts
- **Voltage:** 220 Volts
- **Pressure:** 19 Bar
- **Water Tank Capacity:** 600 Milliliters
- **Product Dimensions:** 27.5 x 11 x 25 cm (L x W x H)
- **Item Weight:** 2.75 Kilograms
- **Material:** Metal, Polypropylene
- **Special Features:** Auto Shut-Off (15 min), Lightweight, Removable Tank, Self-Cleaning, Single Cup Brew, Hot/Cold Brew, Adjustable Cup Height
- **Compatibility:** Nes Original capsules, DG capsules, 12-14g fine ground coffee
- **Brewing Temperature (Hot):** 92°C (±1°C)
- **Brewing Temperature (Cold):** 25°C (Room Temperature Extraction)
- **Brew Speed:** Approximately 45 seconds from power-on

WARRANTY AND SUPPORT

Your CAFELFFE MK-611 coffee machine comes with a standard manufacturer's warranty. Please refer to the warranty card included in your packaging for specific terms and conditions, including warranty duration and coverage details. For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact CAFELFFE customer service through the official website or the contact information provided in your product packaging.

Online Resources: You may find additional support and FAQs on the official CAFELFFE website: [CAFELFFE Store](#)