

[Manuals.plus](#) /

› [SR SUN RISE](#) /

› SR SUN RISE Floor Mount Bathtub Faucet with Handheld Shower, Brushed Nickel (Model TJYG004)

SR SUN RISE TJYG004

SR SUN RISE Floor Mount Bathtub Faucet Instruction Manual

Model: TJYG004 (Brushed Nickel)

INTRODUCTION

Thank you for choosing the SR SUN RISE Floor Mount Bathtub Faucet. This manual provides detailed instructions for the safe and efficient installation, operation, and maintenance of your new faucet. Please read all instructions carefully before beginning installation and retain this manual for future reference.

SETUP AND INSTALLATION

Before installation, ensure all necessary components are present and that you have the required tools. Professional installation is recommended for optimal performance and safety.

Included Components

The package includes:

- Bathtub Faucet Body
- Brass Tube
- Handheld Sprayer
- 59 Inch Shower Hose
- Hot and Cold Water Supply Lines (G 1/2" threaded)
- Base Cover
- Mounting Hardware (including G 1/2" to G 3/8" threaded adapter and 8-inch extension hoses)
- Installation Instructions



Figure 1: All included components for installation.

Installation Steps (4-Step Process)

Follow these steps for a straightforward installation:

1. **Mark & Drill Holes:** Position the faucet base on the floor where it will be installed. Use a marker to accurately mark the drilling points for the mounting hardware. Drill the necessary holes according to the provided template.
2. **Assemble the Faucet:** Connect the main faucet body to the brass tube. Ensure all connections are secure.
3. **Secure the Faucet:** Insert the faucet assembly into the drilled holes. Secure the base to the floor using the provided mounting hardware. Ensure the faucet is stable and level.
4. **Install the Handheld Shower:** Connect the 59-inch shower hose to the handheld sprayer and the faucet body. Ensure all connections are hand-tightened to prevent leaks. *Do not use a wrench to overtighten connections involving O-rings, as this can cause damage and leaks.*

FROM BOX TO BATH IN NO TIME

EASY FAUCET INSTALLATION!



1 Mark & Drill Holes



2 Assemble the Faucet



3 Secure the Faucet



4 Install the Handheld Shower

Figure 2: Visual guide for the 4-step installation process.



Figure 3: Faucet dimensions and important note on connection tightening.

OPERATING INSTRUCTIONS

Your SR SUN RISE bathtub faucet is designed for ease of use and versatility.

Water Flow and Temperature Control

The faucet features a single handle for controlling both water flow and temperature. Lift the handle to increase flow and move it left for hot water or right for cold water. The dual ceramic valve cartridge ensures precise control and durability.

HIGH TEMPERA- TURE RESISTANCE



THICKER HOSE



304 Stainless Steel Hose

Figure 4: Hot & Cold Balance Valve for temperature control.

360° Swivel Spout

The main spout can swivel 360 degrees, allowing for flexible positioning and easy filling of bathtubs or other containers. This feature is particularly useful for directing water flow precisely where needed.

EASILY RUN A WARM BATH FOR YOUR LITTLE ONE




Figure 5: The 360° swivel spout in use.

3-Function Handheld Shower Head

The handheld shower head offers three distinct spray settings for various needs:

- **Massage Spray:** A focused, invigorating spray.
- **Powerful Cleaning:** A strong, concentrated stream ideal for rinsing the tub.
- **Powerful Full Body Spray:** A broad, consistent spray for general showering or rinsing.



3 SPRAY SETTINGS




Figure 6: Three spray settings of the handheld shower head.

MAINTENANCE

Proper care and maintenance will ensure the longevity and appearance of your SR SUN RISE faucet.

Cleaning the Faucet

To maintain the brushed nickel finish, clean regularly with a soft, damp cloth. Avoid abrasive cleaners, harsh chemicals, or scouring pads, as these can damage the finish. For stubborn water spots, a mild soap solution can be used, followed by rinsing and drying.

Checking Connections

Periodically inspect all connections for any signs of leaks. If a leak is detected, gently tighten the connection. Remember not to overtighten, especially where O-rings are present, to prevent damage.

Aerator Maintenance

If water flow from the spout decreases, the aerator may be clogged. Unscrew the aerator from the spout, clean any debris or mineral deposits, and then reattach it securely.

59 Inch Hose
REACH EVERY NOOK AND CRANNY



Figure 7: Non-splashing mesh outlet and solid brass construction.

TROUBLESHOOTING

This section addresses common issues you might encounter.

Problem	Possible Cause	Solution
Low Water Flow	Clogged aerator or supply lines.	Clean the aerator. Check supply lines for kinks or obstructions. Ensure water shut-off valves are fully open.
Leaks at Connections	Loose connections or damaged O-rings.	Gently tighten connections. If leaks persist, check O-rings for damage and replace if necessary. Avoid overtightening.
Water Temperature Issues	Improper hot/cold supply connection or issue with valve cartridge.	Verify hot and cold supply lines are correctly connected. If problem persists, contact customer support.
Handheld Shower Not Working	Hose kinked or sprayer clogged.	Check the shower hose for kinks. Clean the spray nozzles on the handheld shower head.

SPECIFICATIONS

Key technical details for the SR SUN RISE Floor Mount Bathtub Faucet.

Feature	Detail
Brand	SR SUN RISE
Model Number	TJYG004
Color	Brushed Nickel

Feature	Detail
Material	Solid Brass (faucet body), 304 Stainless Steel (supply lines, shower hose)
Finish Type	Brushed
Number of Handles	1
Mounting Type	Floor Mount
Handheld Shower Functions	3 (Massage, Powerful Cleaning, Full Body Spray)
Shower Hose Length	59 inches
Valve Type	Dual Ceramic Valve Cartridge (tested over 150,000 cycles)
Water Flow Rate	4 GPM (Gallons Per Minute)
Certifications	CEC & DOE certified



Figure 8: High-temperature resistant 304 stainless steel hose.

WARRANTY INFORMATION

SR SUN RISE provides a **10-year support** for this product. This warranty covers any product quality problems that may arise under normal use and service. Please retain your proof of purchase for warranty claims.

CUSTOMER SUPPORT

If you have any questions, require assistance with installation, or need to make a warranty claim, please do not hesitate to contact our customer service team. Our **24/7 online customer service team** is available to provide support. For contact information, please refer to the SR SUN RISE official website or the contact details provided with your purchase documentation.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question