

[Manuals.plus](#) /

> [Fixwal](#) /

> Fixwal White Nightstand with Charging Station (Model WFN-25081101) User Manual

Fixwal WFN-25081101

Fixwal White Nightstand with Charging Station (Model WFN-25081101) User Manual

INTRODUCTION

Thank you for choosing the Fixwal White Nightstand with Charging Station. This modern bedside table is designed to enhance your living space with its functional features and elegant design. It includes two fluted wood drawers for storage, an integrated charging station, and adjustable RGB LED lighting. This manual provides essential information for assembly, operation, maintenance, and troubleshooting to ensure optimal use of your new nightstand.



Image: The Fixwal White Nightstand, highlighting its overall design and integrated features.

SAFETY INFORMATION

Please read and adhere to the following safety guidelines to prevent injury or damage to the product:

- Always unplug the charging station when not in use.
- Do not overload the table. The maximum load capacity is 80 pounds (36 kg).
- Assemble the table strictly according to the provided instructions and ensure it is stable before use.
- Keep the table away from heat sources and liquids to prevent damage to the electrical components.

- Ensure all electrical connections are secure and properly grounded.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly:

- Top Panel with Integrated Charging Station
- Side Panels (2)
- Bottom Panel
- Back Panel
- Drawer Fronts (2)
- Drawer Side Panels (4)
- Drawer Back Panels (2)
- Drawer Bottom Panels (2)
- Legs (4)
- LED Lighting Strip (pre-installed)
- Hardware Pack (screws, dowels, cam locks, drawer slides, handles)
- Assembly Instructions Manual

ASSEMBLY INSTRUCTIONS

Assembly is estimated to take approximately 45 minutes. Two people are recommended for easier assembly. Tools required include a hammer and a screwdriver.

1. **Prepare Components:** Unpack all parts and hardware. Lay them out on a clean, soft surface to prevent scratches. Refer to the included parts list to identify each component.
2. **Assemble the Frame:** Attach the side panels to the bottom panel using the designated hardware. Ensure all connections are secure.
3. **Install Back Panel:** Slide or fasten the back panel into the grooves or designated areas on the assembled frame.
4. **Attach Legs:** Securely fasten the four legs to the bottom of the nightstand frame.
5. **Assemble Drawers:** Construct the two drawers by attaching the side, back, and bottom panels to the drawer fronts. Install the drawer slides onto the drawers and the corresponding parts on the nightstand frame.
6. **Install Handles:** Attach the metal handles to the drawer fronts.
7. **Place Top Panel:** Carefully place and secure the top panel, which includes the pre-installed charging station and LED lighting strip, onto the assembled frame. Ensure the power cord is accessible.
8. **Final Check:** Verify all screws are tightened and the nightstand is stable.




Image: Overview of the nightstand dimensions and individual components for assembly reference.

OPERATING INSTRUCTIONS


Charging Station

The nightstand features a built-in charging station on the top surface, equipped with multiple ports for convenient device charging.

- **Power Connection:** Plug the 5-foot power supply cord from the nightstand into a standard 120V/12A wall outlet.
- **AC Outlets:** Two standard AC outlets are available for plugging in lamps, laptops, or other electronic devices.
- **USB Ports:** The station includes two USB-C ports and one USB-A port (5V/2A output) for charging smartphones, tablets, and other USB-powered devices.



RECESSED POWER STRIP



120V/12A

– 2 AC Outlets –



5V/2A

– 1 USB Port & –
2 C PortS



5-FOOT

– Power Cord –

Image: Detailed view of the integrated charging station with its various power and USB ports.

LED Lighting

The nightstand is equipped with an RGB LED lighting strip, offering various colors and brightness levels to suit your preference. The light is designed to be soft and gentle on the eyes.

- **Button Switch Control:** Use the inline button switch on the power cord to cycle through different colors, adjust brightness, and turn the lights on/off.
- **App Control:** For advanced features such as 20 dynamic modes, built-in microphone for music sync, cinema mode, camera color picking, and timing functions, download the compatible mobile application. Refer to the included assembly instructions for details on the specific app to download.




Image: Visual representation of the LED light control options, including the physical button and smartphone app interface.

MAINTENANCE

To maintain the appearance and functionality of your nightstand:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Dusting:** Regularly dust the nightstand with a dry, soft cloth.
- **Drawer Care:** If drawers become stiff, apply a small amount of silicone lubricant to the drawer slides.

- **Electrical Components:** Keep the charging station and LED lights dry. Do not attempt to repair electrical components yourself; contact qualified personnel if issues arise.
- **Tighten Hardware:** Periodically check and tighten all screws and fasteners to ensure stability.

TROUBLESHOOTING

Refer to the table below for common issues and their solutions:

Problem	Possible Cause	Solution
Charging station not working.	Power cord unplugged; wall outlet not active; device not compatible.	Ensure the power cord is securely plugged into a working outlet. Test the outlet with another device. Verify your device is compatible with the charging station's output.
LED lights not turning on or changing colors.	Power cord unplugged; button switch malfunction; app not connected.	Check power connection. Ensure the button switch is pressed correctly. If using app control, verify Bluetooth connection and app settings.
Drawers stick or do not slide smoothly.	Drawer slides misaligned; debris in slides; overtightened screws.	Check that drawer slides are properly aligned and free of obstructions. Loosen any overtightened screws on the drawer slides. Apply silicone lubricant if needed.
Nightstand feels wobbly.	Loose assembly hardware; uneven floor.	Tighten all assembly screws. Ensure the nightstand is placed on a level surface. Adjust leg levelers if available.

SPECIFICATIONS

Feature	Detail
Brand	Fixwal
Model Number	WFN-25081101
Product Dimensions (D x W x H)	15.7" x 11.8" x 25.6" (40cm x 30cm x 65cm)
Item Weight	19 pounds (8.6 kg)
Maximum Weight Recommendation	80 pounds (36 kg)
Frame Material	MDF (Medium-Density Fiberboard)
Furniture Finish	Painted
Color	White
Number of Drawers	2
Charging Station	2 AC Outlets (120V/12A), 2 USB-C Ports (5V/2A), 1 USB-A Port (5V/2A)
Power Cord Length	5 feet
LED Lighting	RGB strip with button switch and app control

Feature	Detail
Assembly Time (Estimated)	45 minutes
Recommended Tools for Assembly	Hammer, Screwdriver

WARRANTY AND SUPPORT

Fixwal products are manufactured with quality and care. For specific warranty details, please refer to the documentation included with your purchase or contact Fixwal customer support. If you encounter any issues or have questions regarding your nightstand, please reach out to our customer service team for assistance. We are committed to providing support and ensuring your satisfaction.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Email

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Details

Submit question

Open the live page

<https://manuals.plus/asin/B0FLXLRQ82>

More documents and user manuals: <https://manuals.plus/>