

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [INGA](#) /

› [INGA Computer Speaker MZ-631 Instruction Manual](#)

INGA MZ-631

INGA Computer Speaker MZ-631 Instruction Manual

Model: MZ-631

INTRODUCTION

Thank you for purchasing the INGA Computer Speaker MZ-631. This USB plug-and-play desktop speaker is designed to provide enhanced stereo sound and deep bass for your computer, laptop, or Mac. Its convenient clamp design allows for easy attachment to most monitors, saving valuable desk space. This manual provides detailed instructions for setup, operation, maintenance, and troubleshooting to ensure optimal performance and longevity of your speaker.

PACKAGE CONTENTS

Please check the package for the following items:

- 1 x INGA Computer Speaker (Model MZ-631)
- 1 x User Manual
- 1 x USB-C to USB-A Adapter (included for versatile connectivity)

PRODUCT OVERVIEW

The INGA MZ-631 speaker features a compact design with an integrated clamping mechanism for monitor attachment. It delivers 10 Watts of stereo sound with enhanced bass through dual precision-tuned speakers and a passive radiator. Connectivity is simplified with a single USB cable for both audio and power.

Klipp-Design

Einfach an Ihrem Monitor befestigen, um Tischfläche zu sparen.



Image: Front view of the INGA Computer Speaker MZ-631, shown clamped to the top of a computer monitor, displaying its sleek design and space-saving placement.

Key Features:

- **Enhanced Stereo Sound with Rich Audio & Deep Bass:** Dual speakers and a passive radiator provide balanced, powerful, and clear audio.
- **Instant Plug & Play Setup:** Single USB cable for audio and power, no additional drivers or software needed.
- **Secure Clip System:** Enhanced clamping mechanism fits most monitors up to 1.5 inches thick, with protective silicone pads. *(Note: Not compatible with curved-back monitors.)*
- **Multi-Function Controls:** Top-mounted buttons for Volume Down, Mute, Volume Up, and Power.
- **Universal Compatibility:** Works with PC, Mac, Laptops, and other devices via USB.

SETUP INSTRUCTIONS

1. Connecting the Speaker

1. Locate the USB cable attached to the INGA Computer Speaker.
2. Plug the USB connector into an available USB port on your computer (PC or Mac). If your computer only has USB-C ports, use the included USB-C to USB-A adapter.
3. The speaker will automatically power on and be recognized by your operating system as an audio output device.



Image: The INGA Computer Speaker connected via its USB cable to a laptop, illustrating the plug-and-play setup. The control buttons (Volume+, Mute, Volume-, Power) are visible on top.

2. Audio Output Selection

After connecting, ensure your computer's audio output is set to the INGA speaker.


- **Windows:** Right-click the speaker icon in the taskbar, select "Sound settings" or "Playback devices," and choose "INGA Speaker" as the default output device.
- **macOS:** Go to System Settings > Sound > Output, and select "INGA Speaker."

INSTALLATION (MONITOR MOUNTING)

The INGA MZ-631 speaker is designed for easy and secure attachment to most flat-panel monitors.

1. Gently open the clamping mechanism on the back of the speaker.
2. Position the speaker on top of your monitor, ensuring the front grille faces you.
3. Adjust the clamp so that it securely grips the top edge of your monitor. The protective silicone pads will prevent scratches and ensure a firm hold.
4. Ensure the speaker is stable and does not obstruct your monitor's view or ventilation.

Important Note: This speaker is not compatible with curved-back monitors due to its mounting requirements. The clamping mechanism is designed for monitors up to 1.5 inches (approximately 3.8 cm) thick.



Upgegradete Klipp

Sicher befestigt an dickeren Oberflächen für größere Vielseitigkeit.

Image: A detailed view of the speaker's clamping mechanism, showing how it securely attaches to the top edge of a monitor, highlighting the 1-inch (2.54 cm) thickness capacity.

Alternative Placement: Desktop

If monitor mounting is not suitable, the speaker can also be placed directly on your desk in front of your monitor. Ensure it is on a stable, flat surface.




Image: Demonstrates various placement options for the speaker, including clamping to the top or bottom of a monitor, or resting on a desk surface.

OPERATING INSTRUCTIONS

The INGA MZ-631 speaker features intuitive controls located on the top panel.



Image: A close-up view of the speaker's top panel, clearly showing the four control buttons: Volume Down, Mute, Volume Up, and Power.

- **Power Button (⏻):** Press to turn the speaker on or off.
- **Volume Up Button (+):** Press to increase the volume.
- **Volume Down Button (-):** Press to decrease the volume.
- **Mute Button (🔇):** Press to instantly mute or unmute the audio.

Audio Experience

The speaker is engineered to deliver a rich audio experience with clear dialogues and powerful bass, suitable for various applications including music, movies, and online meetings.



Image: An internal diagram of the speaker, highlighting its dual speaker drivers and passive radiator, which contribute to its 10W audio output and enhanced sound quality.

MAINTENANCE

To ensure the longevity and optimal performance of your INGA Computer Speaker, follow these simple maintenance guidelines:

- **Cleaning:** Use a soft, dry cloth to wipe the speaker's surface. Do not use liquid cleaners, aerosols, or solvents, as these may damage the finish or internal components.
- **Storage:** When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.
- **Handling:** Avoid dropping the speaker or subjecting it to strong impacts.
- **Environment:** Keep the speaker away from water, moisture, and excessive dust.

TROUBLESHOOTING

If you encounter issues with your INGA Computer Speaker, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
No sound from the speaker.	<ul style="list-style-type: none"> ◦ Speaker not powered on. ◦ Incorrect audio output selected on computer. ◦ USB cable not properly connected. ◦ Computer's sound card driver is outdated or faulty. ◦ Speaker volume is too low or muted. 	<ul style="list-style-type: none"> ◦ Press the Power button on the speaker. ◦ Verify "INGA Speaker" is selected as the default audio output in your computer's sound settings. ◦ Ensure the USB cable is firmly connected to both the speaker and the computer. Try a different USB port. ◦ Update your computer's sound card drivers. ◦ Increase the volume using the speaker's Volume Up button or your computer's volume controls. Ensure the speaker is not muted.
Sound is distorted or unclear.	<ul style="list-style-type: none"> ◦ Volume set too high. ◦ Audio source quality is low. ◦ Interference. 	<ul style="list-style-type: none"> ◦ Reduce the volume on both the speaker and your computer. ◦ Try playing audio from a different source or file to check if the issue persists. ◦ Move the speaker away from other electronic devices that might cause interference.
Speaker does not clamp securely to monitor.	<ul style="list-style-type: none"> ◦ Monitor thickness exceeds limit. ◦ Monitor has a curved back. 	<ul style="list-style-type: none"> ◦ Ensure your monitor's thickness is within the 1.5-inch limit. ◦ The speaker is not designed for curved-back monitors. Consider placing it on your desk instead.

If the problem persists after trying these solutions, please contact INGA Customer Service for further assistance.

SPECIFICATIONS

Feature	Detail
Model Name	MZ-631
Brand	INGA
Speaker Type	Monitor Speaker
Connectivity Technology	USB
Audio Output Mode	Stereo
Surround Sound Channel Configuration	2.0
Speaker Maximum Output Power	10 Watts
Frequency Response	20000 KHz
Input Voltage	5 Volts (DC)

Feature	Detail
Power Source	Corded Electric (USB)
Mounting Type	Clip
Material	Plastic
Color	Black
Product Dimensions	8"D x 2"W x 3"H (approx. 20.3cm D x 5.1cm W x 7.6cm H)
Item Weight	12.3 ounces (approx. 348 grams)
Control Method	Push Button
Compatible Devices	Desktop, Laptop, MAC, PC, Smartphone, Tablet
Special Features	Bass Boost, Clip-on, Hi Res Audio, Portable, USB-C to USB Port

WARRANTY AND SUPPORT

Warranty Information

The INGA Computer Speaker MZ-631 comes with a Limited Warranty. Please refer to the warranty card included in your package for specific terms and conditions.

Customer Support

INGA is committed to providing lifetime technical support for its products. If you have any questions, concerns, or require assistance with your speaker, please do not hesitate to contact our Customer Service team. We aim to resolve all inquiries within 24 hours.

Contact Information:

Please visit the official INGA website or refer to the contact details provided on your product packaging or warranty card.

