

[manuals.plus](#) /› [Monster](#) /› **Monster N-Lite 211 Wireless Earbuds User Manual**

Monster W39

Monster N-Lite 211 Wireless Earbuds User Manual

Model: W39 / MH22229



INTRODUCTION

This manual provides detailed instructions for the Monster N-Lite 211 Wireless Earbuds. Please read this manual carefully before using the product to ensure proper operation and to maximize your listening experience.

1. SETUP

1.1 Package Contents

Verify that all items are present in the package:

- Monster N-Lite 211 Wireless Earbuds
- Charging Case
- USB Charging Cable
- User Manual

1.2 Charging the Earbuds and Case

Before first use, fully charge the earbuds and charging case.

1. Place the earbuds into the charging case. Ensure they are correctly seated.
2. Connect the USB charging cable to the charging port on the case and to a power source.
3. The LED power display on the charging case will show the battery percentage. It will flash from 1-100 during charging.
4. Once fully charged, the display will show 100.



Image: Monster N-Lite 211 Earbuds in their charging case, displaying the digital battery percentage on the front LED screen. The earbuds are black with gold accents.

A full charge provides approximately 6-7 hours of listening time for the earbuds, with the charging case extending total battery life up to 36 hours.

1.3 Pairing with a Device

To pair your earbuds with a Bluetooth-enabled device:

1. Open the charging case. The earbuds will automatically enter pairing mode.
2. On your device (smartphone, tablet, computer), enable Bluetooth.
3. Search for available Bluetooth devices and select "Monster N-Lite 211" from the list.
4. Once connected, a voice prompt will confirm successful pairing.
5. The earbuds will automatically reconnect to the last paired device when removed from the case, if Bluetooth is enabled on the device.

Bluetooth 6.0 for Fast & Stable Connection

The upgraded Bluetooth 6.0 chip offers faster connections, lower power consumption, and quicker data transmission.



Image: A stylized diagram highlighting the Bluetooth 6.0 chip, indicating fast and stable wireless connectivity for the earbuds.

2. OPERATION

2.1 Wearing the Earbuds

Insert the earbuds gently into your ears. Adjust them for a comfortable and secure fit. The ergonomic design ensures stability during various activities.

 MONSTER®

Better Music Experience

Image: A person wearing a Monster N-Lite 211 earbud, illustrating its comfortable fit and emphasizing the Hi-Fi Audio and Deep Bass sound quality.

2.2 Touch Controls

The Monster N-Lite 211 earbuds feature intuitive touch controls on each earbud. The following table outlines the functions:

Action	Function
Single Tap (Left/Right)	Play/Pause Music, Answer/End Call
Double Tap (Right)	Next Track
Double Tap (Left)	Previous Track
Triple Tap (Left/Right)	Activate Voice Assistant
Long Press (2 seconds)	Reject Call

2.3 Noise Cancellation (ENC)

The earbuds are equipped with an Environmental Noise Cancellation (ENC) chip to reduce background noise during calls, ensuring clear communication.



Image: A woman wearing a Monster N-Lite 211 earbud, with a graphic overlay illustrating the Environmental Noise Cancellation (ENC) technology reducing ambient sound for clearer calls.

3. MAINTENANCE

3.1 Cleaning

- Use a soft, dry, lint-free cloth to clean the earbuds and charging case.
- Do not use harsh chemicals, cleaning solvents, or strong detergents.
- Gently remove any earwax or debris from the eartips and speaker mesh using a small, soft brush or cotton swab.

3.2 Water Resistance

The Monster N-Lite 211 earbuds feature IPX5 water resistance, protecting them from sweat and splashes. They are

not designed for submersion in water.

- Avoid exposing the charging case to water.
- Do not wear the earbuds while swimming or showering.
- If the earbuds get wet, wipe them dry before placing them back in the charging case.



Image: An illustration depicting the IPX5 water resistance of the earbuds, showing protection against rainy conditions, sweat, and splashes.

3.3 Storage

When not in use, store the earbuds in their charging case to protect them and keep them charged. Store the case in a cool, dry place away from extreme temperatures.

4. TROUBLESHOOTING

Common Issues and Solutions:

Problem	Solution
Earbuds not charging	<ul style="list-style-type: none">◦ Ensure earbuds are correctly seated in the charging case.◦ Check if the charging cable is securely connected to both the case and the power source.◦ Verify the power source is active.◦ Clean the charging contacts on both the earbuds and the case.
Cannot pair with device	<ul style="list-style-type: none">◦ Ensure Bluetooth is enabled on your device.◦ Make sure the earbuds are in pairing mode (open the case).◦ Forget "Monster N-Lite 211" from your device's Bluetooth list and try pairing again.◦ Move the earbuds closer to your device.◦ Restart your device and the earbuds (by placing them back in the case and then taking them out).

Problem	Solution
No sound or low volume	<ul style="list-style-type: none"> Adjust the volume on both your device and the earbuds. Ensure the earbuds are properly connected to your device. Check if the earbuds have sufficient battery. Clean any debris from the earbud speaker mesh.
Intermittent connection	<ul style="list-style-type: none"> Ensure there are no obstructions between the earbuds and your device. Move away from sources of strong electromagnetic interference. Keep the device within the Bluetooth range (up to 12 meters).

5. SPECIFICATIONS

Feature	Detail
Model Name	MH22229
Item Model Number	W39
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	6.0
Bluetooth Range	12 Meters
Audio Driver Type	Dynamic Driver (13mm)
Battery Life (Earbuds)	Up to 6-7 Hours (single charge)
Total Battery Life (with Case)	Up to 36 Hours
Noise Control Features	Environmental Noise Cancellation (ENC)
Water Resistance Level	IPX5 (Sweatproof, Splashproof)
Control Method	Touch
Item Weight	0.17 Kilograms / 5.9 ounces
Material	Plastic, Silicone, Or Rubber
Compatible Devices	Laptops, Desktops, Gaming Consoles, Tablets, Telephones, Smart Speakers, Televisions, Cellphones

Superior Hi-Fi Stereo

The 13mm dynamic drivers deliver clear, pure sound.



Image: An exploded diagram showcasing the internal components of the Monster N-Lite 211 earbud, highlighting the 13mm dynamic driver responsible for audio output.

6. WARRANTY AND SUPPORT

Monster products are designed and manufactured to the highest quality standards. For detailed warranty information and customer support, please refer to the warranty card included in your package or visit the official Monster website.

For further assistance, please contact Monster customer support through their official channels.

Note: Warranty terms and conditions may vary by region. Please retain your proof of purchase.