

[Manuals.plus](#) /

› [Hupoaf](#) /

› Hupoaf WYS-2306BT Portable Bluetooth Speaker User Manual

Hupoaf WYS-2306BT

Hupoaf WYS-2306BT Portable Bluetooth Speaker User Manual

Model: WYS-2306BT

INTRODUCTION

Thank you for choosing the Hupoaf WYS-2306BT Portable Bluetooth Speaker. This manual provides essential instructions for setting up, operating, and maintaining your device. Please read it thoroughly before use to ensure optimal performance and longevity.



Image: The Hupoaf WYS-2306BT Portable Bluetooth Speaker, featuring an adjustable stand for a mobile device, a speaker grille, and a control panel with buttons for lighting, volume adjustment, and power, illuminated by an RGB light strip.

SETUP

1. Unboxing

Carefully remove all components from the packaging. Ensure the following items are present:

- Hupoaf WYS-2306BT Portable Bluetooth Speaker
- Quick Start Guide
- Charging Cable (if applicable, not explicitly listed but implied for a portable speaker)

2. Charging the Battery

The speaker is equipped with an internal rechargeable battery. Before first use, fully charge the speaker. Connect the charging cable to the speaker's charging port and a suitable power source (e.g., USB wall adapter, computer USB port). The charging indicator light will typically show charging status and turn off or change color when fully charged.

Note: The device includes 1 A battery, which is pre-installed.

3. Power On/Off

To power on the speaker, press and hold the **Power button** (usually marked with a circle and a vertical line) located on the control panel until you hear an audible prompt or see an indicator light illuminate. To power off, press and hold the same button again.

OPERATING INSTRUCTIONS

1. Bluetooth Pairing

1. Ensure the speaker is powered on and in pairing mode. The Bluetooth indicator light will typically flash.
2. On your mobile device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
3. Select "WYS-2306BT" from the list of found devices.
4. Once paired, the speaker will emit a confirmation sound, and the Bluetooth indicator light will become solid.

2. Audio Playback

After successful pairing, you can play audio from your connected device. Use the volume controls on the speaker or your connected device to adjust the sound level. The speaker's control panel includes '+' and '-' buttons for volume adjustment.

3. True Wireless Stereo (TWS) Pairing

For an enhanced stereo experience, you can pair two Hupoaf WYS-2306BT speakers together. Refer to the Quick Start Guide for detailed instructions on TWS pairing, as the process may vary slightly.

4. Lighting Controls

The speaker features integrated lighting. Use the **Light button** (usually marked with a lightbulb icon) on the control panel to cycle through different lighting modes or to turn the lighting on/off.

MAINTENANCE

1. Cleaning

Wipe the speaker's exterior with a soft, dry, or slightly damp cloth. Do not use abrasive cleaners, alcohol, or solvents, as these may damage the finish. Ensure the speaker is powered off and disconnected from any power source before cleaning.

2. Storage

When not in use for extended periods, store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. It is recommended to charge the battery periodically (e.g., every 3-6 months) to maintain battery health.

3. Battery Care

To prolong battery life, avoid fully discharging the battery frequently. Charge the speaker using only the provided or recommended charging cables and adapters. Do not expose the battery to high temperatures or puncture it.

TROUBLESHOOTING

- **No Power:** Ensure the battery is charged. Connect the speaker to a power source and try turning it on again.
- **No Sound:** Check the volume levels on both the speaker and your connected device. Ensure the speaker is properly paired via Bluetooth.
- **Bluetooth Pairing Issues:** Make sure the speaker is in pairing mode. Turn off and on Bluetooth on your device, then try pairing again. Move the speaker closer to your device and away from potential interference sources.
- **Poor Sound Quality:** Ensure the speaker is within Bluetooth range of your device. Check for any physical obstructions. Try playing audio from a different source or device.

SPECIFICATIONS

Feature	Detail
Model Name	WYS-2306BT
Brand	Hupoaf
Connectivity Technology	Bluetooth
Speaker Maximum Output Power	150 Watts
Product Dimensions	3"D x 2"W x 3"H
Item Weight	0.176 ounces
Number of Batteries	1 A battery (included)
Included Components	Quick Start Guide
Mounting Type	Anywhere

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided in the Quick Start Guide or visit the official Hupoaf website. Keep your proof of purchase for warranty claims.

