

Limitless Innovations LIM-TBSTM5-M001

Limitless Innovations TotalBoost Mini Pro 5,000mAh Universal Power Bank
Instruction Manual

Model: LIM-TBSTM5-M001

			Introduction	Safety Information	Package		
Contents	Setup	Operation	Maintenance	Troubleshooting	Specifications	Warranty & Support	

1. INTRODUCTION

The Limitless Innovations TotalBoost Mini Pro is a compact and versatile 5,000mAh portable power bank designed to provide on-the-go charging for a wide range of electronic devices. It features interchangeable adapters for broad compatibility, a built-in kickstand for convenient viewing, and an integrated flashlight for added utility. The digital display indicates the remaining battery level, ensuring you are always aware of its charge status.



Image: The TotalBoost Mini Pro power bank shown with its interchangeable adapters.

2. IMPORTANT SAFETY INFORMATION

- Do not expose the power bank to extreme temperatures, direct sunlight, or fire.
- Avoid dropping, puncturing, or disassembling the device.
- Keep away from water and other liquids.
- Do not use if the device is damaged or swollen.
- Keep out of reach of children.
- Use only the provided charging cable and compatible adapters.
- Dispose of the power bank responsibly according to local regulations.

3. PACKAGE CONTENTS

Your Limitless Innovations TotalBoost Mini Pro package includes:

- TotalBoost Mini Pro Power Bank
- 3x Charging Adapters (Micro USB, Lightning, Type-C)
- USB-A to Type-C Charging Cable
- Faux Leather Storage Case with built-in adapter compartments
- Detachable Carrying Strap
- Instruction Manual

COMPATIBILITY

Type-C | Lightning | Micro



Image: The faux leather storage case with compartments for the interchangeable adapters.

4. SETUP

4.1 Initial Charging of the Power Bank

1. Connect the included USB-A to Type-C charging cable to the power bank's Type-C input/output port.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The digital display will show the charging percentage. A full charge typically takes 2-3 hours.

Note: It is recommended to fully charge the power bank before its first use.

Your browser does not support the video tag.

Video: An animated overview demonstrating the features and charging process of the TotalBoost Mini Pro.

4.2 Attaching/Changing Adapters

The TotalBoost Mini Pro comes with three interchangeable adapters (Micro USB, Lightning, Type-C) to ensure compatibility with various devices.

1. Select the appropriate adapter for your device from the storage case.
2. Align the adapter with the power bank's output port and firmly insert it until it clicks into place.
3. To remove an adapter, press the release button located on the side of the power bank and gently pull the adapter out.



Image: A hand demonstrating how to insert an interchangeable adapter into the power bank.

5. OPERATING INSTRUCTIONS

5.1 Charging a Device

1. Ensure the power bank is sufficiently charged.
2. Attach the correct adapter to the power bank.
3. Plug the power bank directly into your mobile device's charging port.

4. The power bank will automatically begin charging your device. The digital display will show the power bank's remaining charge.
5. To stop charging, simply disconnect the power bank from your device.

UNIVERSAL Power Bank



Image: A smartphone charging vertically from the TotalBoost Mini Pro, utilizing its built-in kickstand.

The TotalBoost Mini Pro is designed for seamless integration, allowing you to use your device while it charges without the need for additional cables. It can provide significant extended talk time, as shown in the compatibility chart.

The TotalBoost Mini Pro can provide up to an additional:

Device	Extended Talk Time
Samsung Galaxy S22	23 Hours
iPhone 14 Pro	17 Hours
LG G8 ThinQ	15 Hours



Image: A chart illustrating the additional talk time provided by the power bank for different smartphone models.



Image: A user holding a smartphone that is charging from the TotalBoost Mini Pro, demonstrating on-the-go use.

5.2 Using the Built-in Kickstand

The power bank features a built-in kickstand for hands-free viewing while your device charges.

1. Locate the kickstand on the back of the power bank.
2. Gently pull the kickstand out until it locks into an open position.
3. Place your device, connected to the power bank, onto the kickstand for vertical or horizontal viewing.
4. When not in use, fold the kickstand back into its magnetic storage position.



Image: A smartphone positioned horizontally on the power bank's kickstand, ideal for media consumption.

5.3 Using the Flashlight

The TotalBoost Mini Pro includes a 25-lumen mini flashlight with multiple modes.

1. Press and hold the power button for 2 seconds to turn the flashlight ON.
2. Single-click the power button to cycle through the 4 modes: Low, Medium, High, and S.O.S.
3. Press and hold the power button for 2 seconds to turn the flashlight OFF.



Image: A hand holding the power bank, showcasing its integrated flashlight in use.

5.4 Digital Battery Level Indicator

The integrated digital display shows the remaining battery percentage of the power bank, allowing you to monitor its charge status at a glance.

5.5 Charging Multiple Devices

The power bank can charge up to two devices simultaneously. Use the integrated adapter for one device and the Type-C output port with a separate cable for a second device.

Your browser does not support the video tag.

Video: A lifestyle video demonstrating the TotalBoost Mini Pro charging various devices in different settings.

6. MAINTENANCE

- **Cleaning:** Wipe the power bank with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.

- **Storage:** Store the power bank in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the power bank regularly. Recharge it when the battery level is low.

7. TROUBLESHOOTING

Problem	Possible Solution
Power bank not charging device.	◦ Ensure the power bank is sufficiently charged. ◦ Verify the correct adapter is securely attached and compatible with your device. ◦ Check if the device's charging port is clean and free of debris. ◦ Try using a different charging cable or adapter.
Power bank not recharging.	◦ Ensure the charging cable is properly connected to the power bank and power source. ◦ Try a different USB power adapter or USB port. ◦ Check the charging cable for any damage.
Flashlight not working.	◦ Press and hold the power button for 2 seconds to activate the flashlight. ◦ Ensure the power bank has sufficient charge.

8. SPECIFICATIONS

Feature	Detail
Model Number	LIM-TBSTM5-M001
Battery Capacity	5,000mAh (Lithium-Ion)
Output Power	15W Max
Input/Output Port	USB Type-C
Interchangeable Adapters	Micro USB, Lightning, USB Type-C
Flashlight	25 Lumens, 4 Modes (Low, Medium, High, S.O.S.)
Display	Digital Battery Level Indicator
Dimensions	2.32 x 3.23 x 1.08 inches
Weight	4.2 ounces

For a comprehensive list of compatible devices, please refer to the [Limitless Innovations Store](#) or the product packaging.

LIMITLESS™

CHARGING COMPATIBILITY

Mobile Phones



Tablets



E-Readers



Gaming Systems



Smart Watches



Fitness Trackers



Cameras



Earbuds & Headphones



Wireless Speakers



and more!

Image: A visual guide to the wide range of devices compatible with the TotalBoost Mini Pro, including phones, tablets, e-readers, and more.

9. WARRANTY & SUPPORT

Limitless Innovations products are designed and manufactured to the highest quality standards. This product is covered by a limited warranty against defects in materials and workmanship. For specific warranty details, registration, or technical support, please visit the official Limitless Innovations website or contact their customer service.

For further assistance, please visit: [Limitless Innovations Store on Amazon](#)

© 2025 Limitless Innovations. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question