

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [EasyKeys](#) /

› [EasyKeys Yamaha B39878 Golf Cart Replacement Key Instruction Manual](#)

EasyKeys B39878

EasyKeys Yamaha B39878 Golf Cart Replacement Key Instruction Manual

Model: B39878 | Brand: EasyKeys

1. INTRODUCTION

This manual provides essential information for the proper identification, use, and care of your EasyKeys B39878 replacement key for Yamaha golf carts. Please read these instructions carefully to ensure correct application and longevity of your key.

2. PRODUCT OVERVIEW

The EasyKeys B39878 is a precision-cut replacement key designed for Yamaha golf carts. It is compatible with Yamaha key series B30000 through B39999. This key is specifically manufactured to match the B39878 lock code, ensuring a secure and functional replacement for your original key.



Image 1: The EasyKeys B39878 replacement key, featuring a standard key design with 'USA B30001' stamped on it, indicating its series.

Key Features:

- Custom cut for Yamaha B39878 lock codes.
- Durable brass material for extended use.

- Compatible with Yamaha golf carts and other products using the B30000 - B39999 series.

3. KEY IDENTIFICATION AND SETUP

Before using your new replacement key, it is crucial to verify that it matches your specific lock code. The B39878 key is designed for Yamaha locks within the B30000 to B39999 series. Incorrect key codes will not operate your lock.

How to Find Your Lock Code:

Your lock code can typically be found in one of the following locations:

1. **On Your Existing Key:** If you have an original or working spare key, the code is often stamped directly on the key blade or head.
2. **On the Lock Face:** For many ignition or compartment locks, the code is engraved on the visible face of the lock cylinder.
3. **On a Label:** Check inside or behind the lock mechanism, or on a label affixed to the cabinet or door near the lock.




Image 2: A visual guide illustrating common locations for lock codes, including on the key itself, the lock cylinder face, and various labels.

Important Notes:

- Always verify the manufacturer (Yamaha) and the exact lock code (B39878) to ensure compatibility.
- Key cuts differ significantly between manufacturers, even if codes appear similar.

4. OPERATING INSTRUCTIONS

Using your EasyKeys B39878 replacement key is straightforward:

1. **Insert the Key:** Gently insert the key into the lock cylinder. Do not force the key if it does not slide in smoothly.
2. **Turn the Key:** Once fully inserted, turn the key clockwise or counter-clockwise as required to operate the lock mechanism (e.g., to start the golf cart or open a compartment).
3. **Remove the Key:** After use, return the key to its neutral position and gently pull it out.

5. MAINTENANCE

To ensure the longevity and reliable operation of your key and lock:

- **Keep Clean:** Periodically wipe the key with a soft, dry cloth to remove dirt or debris.
- **Avoid Bending:** Do not apply excessive force or attempt to bend the key, as this can damage its structure and render it unusable.
- **Proper Storage:** Store the key in a safe place, away from extreme temperatures or corrosive materials.
- **Lock Maintenance:** If the lock mechanism becomes stiff, a small amount of graphite lubricant can be applied to the lock cylinder, not directly to the key.

6. TROUBLESHOOTING

If you encounter issues with your replacement key, consider the following:

- **Key Does Not Insert Fully:**
 - Check for obstructions in the lock cylinder.
 - Ensure the key is oriented correctly.
- **Key Inserts but Does Not Turn:**
 - Verify that the lock code on your key (B39878) matches the lock.
 - The lock mechanism may be seized or damaged. Consult a professional if the lock is unresponsive.
 - Ensure the steering wheel or other mechanisms are not binding the ignition lock (common in golf carts).
- **Key Feels Loose or Wobbly:**
 - This may indicate wear in the lock cylinder or an incorrect key cut. Re-verify your lock code.

7. SPECIFICATIONS

Brand	EasyKeys
Model Name	B39878
Manufacturer	Yamaha (for compatible locks)
Material	Brass

Lock Type	Cam
Item Dimensions (L x W x H)	0.5 x 0.5 x 1 inches
Item Weight	0.25 Pounds (approx.)
Special Features	Custom Cut Key, Durable

8. WARRANTY AND SUPPORT

For information regarding warranty coverage or technical support for your EasyKeys B39878 replacement key, please contact the seller or EasyKeys directly. Retain your purchase receipt for any warranty claims. For further assistance, please refer to the EasyKeys official website or contact their customer service department.
