

## Miracase iPhone 17 Pro Max

# Miracase Magnetic Case for iPhone 17 Pro Max - Instruction Manual

Model: iPhone 17 Pro Max | Brand: Miracase

## INTRODUCTION

---

This manual provides detailed instructions for the Miracase Magnetic Case designed for the iPhone 17 Pro Max. It covers installation, usage, maintenance, and troubleshooting to ensure optimal protection and functionality of your device.



*Image: The Miracase Magnetic Case in Dark Blue, fitted onto an iPhone 17 Pro Max, showcasing its design and MagSafe compatibility ring.*

## SETUP

### 1. Case Installation

1. Ensure your iPhone 17 Pro Max is clean and free of dust or debris.
2. Align the camera cutouts of the case with your phone's camera module.
3. Gently press your phone into the case, starting from one side and working your way around until all edges are securely fitted.
4. Verify that all buttons and ports are accessible and aligned correctly.

### 2. Screen Protector Application

The package includes a high-quality tempered glass screen protector. Follow these steps for proper application:

1. Clean your phone screen thoroughly using the provided cleaning wipes (if included) to remove all dust, smudges, and fingerprints.

2. Use the dust-absorber sticker to pick up any remaining dust particles.
3. Carefully peel off the protective film from the adhesive side of the screen protector.
4. Align the screen protector with your phone's screen, ensuring the cutouts for the speaker and sensors match.
5. Gently lower the screen protector onto the screen. It will adhere automatically.
6. If any bubbles appear, gently push them towards the edges using a soft cloth or the provided squeegee card.



*Image: Multiple views of the Miracase Magnetic Case, illustrating its design and how it fits the iPhone 17 Pro Max.*

## OPERATING INSTRUCTIONS

### MagSafe Compatibility

The Miracase Magnetic Case features built-in N52 magnets for enhanced MagSafe compatibility. This allows for seamless attachment to MagSafe chargers and other magnetic accessories.

- **Wireless Charging:** Place your iPhone 17 Pro Max (with the case installed) onto a MagSafe wireless

charger. The magnets will automatically align the phone for efficient charging.

- **Magnetic Accessories:** Attach MagSafe-compatible accessories such as wallets, car mounts, or power banks directly to the back of the case. The strong magnetic connection ensures secure attachment.

## Stronger Magnetic Adsorption

Built-in high-grade N52 magnets,  
once snap never slide



**Magnets Strength**

Miracase	2300g
others	1600g

*Image: An iPhone 17 Pro Max in the Miracase Magnetic Case, actively charging on a MagSafe charger, demonstrating the magnetic alignment.*

# MagSafe Match, Strong Magnetic

Compatible with All MagSafe Accessories



*Image: A collage showing the Miracase Magnetic Case with a MagSafe wallet, a MagSafe car mount, and a MagSafe battery pack, illustrating accessory compatibility.*

## MAINTENANCE

### Cleaning the Case

The case features an upgraded Nano Oleophobic Coating to resist fingerprints and scratches. To clean your case:

- Wipe the case gently with a soft, damp cloth.
- Avoid using harsh chemicals, abrasive cleaners, or solvents, as these may damage the coating or material.
- Allow the case to air dry completely before re-installing your phone.

### Screen Protector Care

To maintain the clarity and effectiveness of your screen protector:

- Clean the screen protector with a microfiber cloth to remove smudges and fingerprints.
- Avoid sharp objects that could scratch or chip the tempered glass.

## TROUBLESHOOTING

---

- **Issue: Case does not fit correctly.**

**Solution:** Ensure you have the correct model (iPhone 17 Pro Max). Remove the case and re-install, making sure to align all edges and corners properly.

- **Issue: MagSafe accessories do not attach securely.**

**Solution:** Verify that the accessory is MagSafe compatible. Ensure there is no debris between the case and the accessory that could interfere with the magnetic connection.

- **Issue: Screen protector has bubbles after installation.**

**Solution:** Gently lift the nearest edge of the screen protector and re-apply, carefully pushing out air bubbles with a soft cloth or squeegee. Ensure the screen is completely dust-free before re-application.

- **Issue: Case appears dirty or discolored.**

**Solution:** Clean the case as per the maintenance instructions. Persistent discoloration, especially with lighter colored cases, can occur over time due to environmental factors and normal wear.

## SPECIFICATIONS

---

<b>Product Dimensions</b>	6.1 x 3.15 x 0.43 inches
<b>Item Weight</b>	1.41 ounces
<b>Material</b>	Thermoplastic Polyurethane
<b>Compatible Phone Model</b>	iPhone 17 Pro Max
<b>Special Features</b>	Screen Protector, Slim Fit, MagSafe Compatible (Built-in 38 N52 Magnets), Military-Grade Drop Protection (10ft)
<b>What's in the Box</b>	iPhone 17 Pro Max Case, Screen Protector

## WARRANTY AND SUPPORT

---

### Warranty Information

This Miracase product comes with a **1-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accidents, or unauthorized modifications.

### Customer Support

If you encounter any issues or have questions regarding your Miracase Magnetic Case, please contact us through the Amazon Message Center for assistance. Our support team is available to help with product inquiries, warranty claims, and troubleshooting.

For further information, you may visit the official Miracase store on Amazon: [Miracase Store](#)

