

[Manuals.plus](#) /

› [EasyKeys](#) /

› EasyKeys Replacement Key for Yale Lock E0162 Instruction Manual

EasyKeys E0162

EasyKeys Replacement Key for Yale Lock E0162 Instruction Manual

1. INTRODUCTION

This manual provides essential information for the proper use and care of your EasyKeys Replacement Key, specifically designed for Yale Lock models within the E0001 - E1600 series. This key is custom-cut to code E0162 and is compatible with Yale Lock systems.

2. PRODUCT OVERVIEW

The EasyKeys Replacement Key is a precision-cut brass key intended to replace lost or damaged keys for compatible Yale Lock systems. It features a durable brass construction and is specifically cut to the E0162 code.



Figure 1: Typical appearance of an EasyKeys replacement key. This image displays the typical appearance of an EasyKeys replacement key, made of brass, with a code stamped on the head.

Key Features:

- Custom-cut to Yale Lock code E0162.
- Compatible with Yale Lock E0001 - E1600 series.
- Constructed from durable brass material.
- Designed for reliable operation in compatible locks.

3. SETUP AND USAGE

Before using your new replacement key, it is crucial to verify that the lock code and manufacturer match the specifications of this key (Yale Lock E0162). Incorrect key usage can damage the lock.

3.1 Identifying Your Lock Code

Your lock code can typically be found in several locations. Refer to the diagram below to help locate your specific lock code:

Where to Find Your Lock Code




On the Key



On the Lock Face



**On a Label Inside/
Behind the Lock**



**On the
Cabinet/Door Label**



Important Notes

- Order by Manufacturer → Lock codes are manufacturer-specific.
- Key Cuts Differ → Even if codes look similar, they vary by brand.

Figure 2: Locations to find your lock code. This diagram illustrates common locations where you can find the code for your lock, such as directly on the original key, on the lock cylinder, or on labels associated with the lock or furniture.

- **On the Original Key:** The code is often stamped directly onto the head of the key.
- **On the Lock Face:** Some locks have the code engraved on the visible part of the cylinder.
- **Inside/Behind the Lock:** For cabinet or drawer locks, the code may be on a label or stamped on the

lock mechanism itself, often requiring removal of the lock or access to the interior.

- **On a Cabinet/Door Label:** Occasionally, the code is provided on a label affixed to the furniture or door where the lock is installed.

Important: Ensure the code you find precisely matches "E0162" and the manufacturer is "Yale Lock" before attempting to use this key.

3.2 Using the Key

1. Gently insert the key into the lock's keyway. Do not force the key.
2. Once fully inserted, turn the key smoothly in the direction required to unlock or lock the mechanism.
3. Remove the key after operation.

4. MAINTENANCE

To ensure the longevity and proper function of your replacement key and lock:

- Keep the key clean and free from dirt or debris.
- Avoid bending or applying excessive force to the key, as this can deform its shape and render it unusable.
- Store the key in a dry place to prevent corrosion.
- Periodically, a small amount of graphite lubricant can be applied to the lock mechanism to maintain smooth operation.

5. TROUBLESHOOTING

If you encounter issues with your replacement key, consider the following:

- **Key Does Not Insert Fully:** Check for obstructions in the lock's keyway. Ensure the key is oriented correctly.
- **Key Does Not Turn:** Double-check that the lock code on your key (E0162) precisely matches the code required by your Yale Lock. Verify that the lock mechanism is not jammed or damaged. Do not force the key.
- **Key Feels Stiff:** The lock mechanism may require lubrication. Apply a small amount of graphite lubricant into the keyway.

If problems persist after troubleshooting, contact EasyKeys customer support for assistance.

6. SPECIFICATIONS

Feature	Detail
Brand	EasyKeys
Model Name	E0162
Manufacturer	Yale Lock
Part Number	E0162-yalelock-key-1869881
Material	Brass

Lock Type	Cam
Item Dimensions (L x W x H)	0.5 x 0.5 x 1 inches
Item Weight	0.25 Pounds (4 ounces)
Special Features	Adjustable Fit, Custom Cut Key, Durable
Included Components	Key

7. WARRANTY AND SUPPORT

For any questions, concerns, or support regarding your EasyKeys Replacement Key, please contact EasyKeys directly. Specific warranty details may vary; please refer to the EasyKeys official website or contact their customer service for current warranty information.

You can visit the official EasyKeys store for more information: [EasyKeys Store on Amazon](#)