

[Manuals.plus](#) /

› [LEMEGA](#) /

› LEMEGA M5P Internet Radio with CD Player User Manual

LEMEGA M5P

LEMEGA M5P Internet Radio with CD Player User Manual

Model: M5P

1. INTRODUCTION

Thank you for choosing the LEMEGA M5P Internet Radio with CD Player. This device combines multiple audio functionalities, including Internet Radio, FM Radio, CD Player, Bluetooth streaming, Spotify HiFi, and Podcast playback, all controlled via the OKTIV app or the included remote. This manual provides essential information for setting up, operating, and maintaining your M5P system.



Front view of the LEMEGA M5P Internet Radio with CD Player.

2. SAFETY INFORMATION

Please read and understand all safety instructions before using this product. Keep this manual for future reference.

- **Power Source:** Use only the provided power adapter. Ensure the voltage matches your local power supply.
- **Water and Moisture:** Do not expose the unit to rain, moisture, or dripping/splashing liquids. Do not place objects filled with liquids on the unit.
- **Heat:** Do not place the unit near heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- **Ventilation:** Ensure proper ventilation. Do not block any ventilation openings.
- **Cleaning:** Unplug the unit from the power outlet before cleaning. Use a soft, dry cloth. Do not use liquid cleaners or aerosol cleaners.
- **Servicing:** Do not attempt to service this product yourself. Refer all servicing to qualified service personnel.

3. PACKAGE CONTENTS

Verify that all items are present in the box:

- 1 x LEMEGA M5P Stereo System
- 1 x Remote Control
- 1 x Mains Power Cable
- 1 x User Manual (this document)



Mains power adaptor included



User manual & remote control included

Image showing the LEMEGA M5P packaging, product dimensions, remote control, and user manual.

4. PRODUCT OVERVIEW

4.1 Front Panel Controls and Display

The front panel features a 2.8-inch full-color display, CD slot, and various control buttons and a rotary knob for navigation and selection.

4.2 Rear Panel Connections

The rear panel provides essential ports for connectivity.



Rear view of the LEMEGA M5P, highlighting the power input, AUX in, Line out, USB port, and antenna connection.

- **Power Input:** Connect the mains power cable here.
- **Antenna:** Extend the telescopic antenna for optimal FM reception.
- **AUX In:** Connect external audio devices using a 3.5mm audio cable.
- **Line Out:** Connect to an external amplifier or powered speakers.
- **USB Port:** For playing MP3 files from a USB storage device.

5. SETUP

5.1 Unpacking and Placement

1. Carefully remove the M5P system from its packaging.
2. Place the unit on a stable, flat surface, ensuring adequate ventilation around the device.

5.2 Power Connection

1. Connect the provided mains power cable to the Power Input port on the rear of the unit.

2. Plug the other end of the power cable into a wall outlet.

5.3 Antenna Connection

For FM radio reception, extend the telescopic antenna fully.

5.4 Initial Power On and Network Setup

1. Press the Power button on the unit or remote control to turn on the M5P.
2. The display will guide you through the initial setup, including language selection and network configuration.
3. Select your Wi-Fi network from the list and enter the password using the rotary knob and selection button. A stable internet connection is required for Internet Radio, Spotify, and Podcast features.

6. OPERATING INSTRUCTIONS

6.1 Mode Selection

Use the 'Mode' button on the unit or remote to switch between Internet Radio, FM, CD, Bluetooth, AUX, and USB modes.

6.2 Internet Radio

1. Select 'Internet Radio' mode.
2. Browse stations by location, genre, or use the search function.
3. To save a station as a preset, press and hold a preset button (1-10+) on the remote or use the menu option to save to the 50 available presets.

6.3 FM Radio

1. Select 'FM Radio' mode.
2. Use the tuning controls to scan for stations or enter a frequency directly.
3. Save your favorite FM stations to presets.

6.4 CD Player

1. Select 'CD' mode.
2. Gently insert a CD into the CD slot with the label side facing up. The unit will automatically load and begin playback.
3. Use the Play/Pause, Skip, and Stop buttons for control.

6.5 Bluetooth Streaming

1. Select 'Bluetooth' mode. The unit will enter pairing mode.
2. On your smartphone or tablet, enable Bluetooth and select 'LEMEGA M5P' from the list of available devices.
3. Once paired, you can stream audio from your device to the M5P.



The LEMEGA M5P connected via Bluetooth to a smartphone, streaming music.

6.6 Spotify HiFi and Podcast Player

1. Ensure the M5P is connected to the internet.
2. Select 'Spotify' or 'Podcast' from the mode menu.
3. Follow the on-screen instructions to link your Spotify account or browse podcasts.

6.7 OKTIV App Control

1. Download the 'OKTIV' app from your device's app store.
2. Ensure your smartphone/tablet is connected to the same Wi-Fi network as the M5P.
3. Open the app and follow the instructions to connect to your M5P. The app allows full control over all functions, presets, and music libraries.



The LEMEGA M5P display showing various service icons, indicating app control capabilities.

6.8 USB Playback

1. Insert a USB flash drive containing MP3 files into the USB port on the rear panel.
2. Select 'USB' mode. The unit will automatically detect and play the audio files.

6.9 AUX Input

1. Connect an external audio source (e.g., an MP3 player) to the 'AUX In' port using a 3.5mm audio cable.
2. Select 'AUX' mode to play audio from the connected device.

6.10 Headphone Output

Connect headphones to the headphone jack on the front panel for private listening. The main speakers will mute automatically.

6.11 Equalizer Settings

Access the equalizer settings through the system menu to adjust bass, treble, and midrange levels according to your preference.

7. MAINTENANCE

7.1 Cleaning the Unit

- Always unplug the M5P from the power outlet before cleaning.
- Use a soft, dry, lint-free cloth to wipe the exterior surfaces.
- Do not use abrasive cleaners, waxes, or solvents as they may damage the finish.

7.2 CD Player Care

- Handle CDs by their edges to avoid fingerprints and scratches.
- Clean CDs with a soft, dry cloth, wiping from the center outwards.
- Do not insert damaged or irregularly shaped CDs into the player.

8. TROUBLESHOOTING

If you encounter issues with your LEMEGA M5P, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No power	Power cable not connected; power outlet faulty.	Check power cable connection; try a different outlet.
No sound	Volume too low; wrong input mode; headphones connected.	Increase volume; select correct mode; disconnect headphones.
Poor FM reception	Antenna not extended or positioned incorrectly.	Extend and adjust the telescopic antenna for best reception.
Cannot connect to Wi-Fi	Incorrect password; router too far; network issue.	Verify Wi-Fi password; move unit closer to router; restart router.
CD not playing	CD inserted incorrectly; CD is dirty or scratched; wrong mode.	Re-insert CD correctly; clean CD; select 'CD' mode.
Bluetooth pairing fails	Device not in pairing mode; M5P not discoverable.	Ensure M5P is in Bluetooth mode; restart Bluetooth on your device.

9. SPECIFICATIONS

- **Model:** M5P
- **Brand:** LEMEGA
- **Product Dimensions (L x W x H):** 11.99" x 9" x 5" (30.45 cm x 22.86 cm x 12.7 cm)
- **Speaker Output Power:** 135 Watts (2.1 Stereo System with built-in subwoofer)
- **Connectivity:** Wi-Fi, Bluetooth
- **Tuner Technology:** Internet Radio, FM Radio
- **Voltage:** 100 Volts
- **Special Features:** Built-In Clock, 50 Presets, Spotify HiFi, Podcast Player, OKTIV App Control, USB Playback, AUX Input, Line Out, Headphone Jack
- **Cabinet Material:** Acoustic Wood



**Incredible 135W 2.1 Stereo Sound,
huge internal subwoofer & full EQ
settings.**

Internal speaker configuration of the LEMEGA M5P, illustrating the 135W 2.1 stereo sound system with subwoofer.

10. WARRANTY AND SUPPORT

LEMEGA has been producing audio systems since 2009. For product support, troubleshooting assistance, or warranty information, please visit the official LEMEGA website or contact their customer service directly. Details can typically be found on the manufacturer's website or the product packaging.

For the latest information and support resources, please refer to the official LEMEGA website:

www.lemegaaudio.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question