MiLESEEY GenePro G1

MILESEEY GenePro G1 Touchscreen & GPS Rangefinder User Manual

Model: GenePro G1

Introduction

The MILESEEY GenePro G1 is an advanced golf rangefinder combining laser precision with comprehensive GPS capabilities. It features a large AMOLED touchscreen, preloaded golf courses, SmartSlope technology, and rapid flag-lock functionality to enhance your golf game. This manual provides detailed instructions for setting up, operating, and maintaining your GenePro G1 device.

Safety Information

- Do not look directly into the laser beam or aim it at others.
- Keep the device away from extreme temperatures and direct sunlight.
- Avoid dropping the device or subjecting it to strong impacts.
- Do not attempt to disassemble or repair the device yourself. Contact authorized service personnel.
- Ensure the device is stored in its sturdy golf case when not in use to protect it.

Package Contents

Verify that all items are present in your GenePro G1 package:

- GenePro G1 GPS Rangefinder
- USB-C Cable
- Snap Hook
- Packing Box
- Carrying Case
- User Manual (this document)
- Quick Start Guide
- Lens Cleaning Cloth
- Accessories Box



Image: All items included in the MILESEEY GenePro G1 package.

Product Overview

The MILESEEY GenePro G1 features a sleek design with a large touchscreen display and intuitive controls. Key

components include the objective lens, eyepiece, laser emitter/receiver, and the 2.13-inch AMOLED touchscreen for interactive use.



Image: Front view of the GenePro G1 rangefinder.

Setup

1. Charging the Device

Before first use, fully charge your GenePro G1 using the provided USB-C cable. Connect the USB-C cable to the device and a compatible USB power adapter (not included). The charging indicator on the screen will show the charging status.

2. Powering On/Off

To power on, press and hold the power button until the screen illuminates. To power off, navigate to the settings menu and select 'Power Off' or press and hold the power button.

3. Initial Settings

Upon first power-on or after a reset, you may need to configure basic settings:

- **Language:** Select your preferred language from the available options.
- **Temperature Unit:** Choose between Celsius (°C) and Fahrenheit (°F) for temperature display.
- **Time and Date:** Set the current time and date. The device supports automatic time synchronization based on your selected time zone.

- **Time Zone:** Select your local time zone for accurate timekeeping.

The device's touchscreen allows for easy navigation through these settings.

4. Course Updates

The GenePro G1 comes preloaded with over 43,000 golf courses. Updates are free for life. If your course is newly opened or not listed, contact customer support for remote addition within 1 week.

Operating Instructions

1. Laser Rangefinding

Point the rangefinder at your target and press the measurement button. The device will quickly provide an accurate distance. It offers 6X magnification for clear viewing and a 0.1-second response time.




Image: Laser rangefinding in action, demonstrating the 1300-yard maximum range.

2. Flag-Lock with Vibration

For precise measurements to the flag, use the flag-lock feature. The device will vibrate to confirm that it has locked onto the flag, even at distances up to 600 yards, ensuring accuracy within ±0.5 yards.

3. GPS Yardages (Front, Center, Back)

The integrated GPS provides real-time distances to the front, center, and back of the green, assisting with club selection and course strategy.



Image: GPS display showing distances to the front, center, and back of the green.

4. SmartSlope Technology

SmartSlope adjusts distances based on elevation, temperature, and humidity for maximum accuracy. An external slope switch allows you to toggle this feature on or off, ensuring tournament compliance when needed.



Image: SmartSlope feature explanation with a visual of the slope switch.

5. Ball-to-Pin Mode

The patented Ball-to-Pin mode enables golfers to measure distances between any two points on the course from any location, including over obstacles or for a playing partner.



Image: Demonstration of the Ball-to-Pin measurement mode.

6. Scorecard Feature

Utilize the on-screen scorecard to track your strokes during a round.

7. App Connectivity

The device can sync with the MILESEEY Golf App to collect in-round shot data for post-round analysis.

Maintenance

- **Cleaning:** Use the provided lens cleaning cloth to gently wipe the lenses. For the body, use a soft, damp cloth. Avoid abrasive cleaners.
- **Storage:** Always store the GenePro G1 in its sturdy golf case when not in use to protect it from dust, moisture, and physical damage.
- **Battery Care:** To prolong battery life, avoid fully discharging the device frequently. Charge it regularly, especially if storing for extended periods.
- **Water Resistance:** The device has IP65 protection, meaning it is resistant to rain and fog. However, it is not designed for submersion.

Troubleshooting

Problem	Possible Cause / Solution
Device does not power on.	Battery may be depleted. Charge the device using the USB-C cable.
Inaccurate distance readings.	Ensure lenses are clean. Target may be too small or obscured. Recalibrate compass if necessary (check settings).
GPS not locating courses.	Ensure you are outdoors with a clear view of the sky. Course may not be preloaded; contact support if it's a new course.
Screen is dim or hard to read.	Adjust screen brightness in the settings menu. The AMOLED display is designed for ultra-clear visuals in all lighting conditions.

Specifications

Feature	Detail
Brand	MiLESEEY
Model Name	Gene Pro G1
Measuring Range	5 to 1300 yards
Accuracy	±0.5 yards (Flag-Lock)
Flag-Lock Speed	0.1 seconds
Magnification	6X
Display Type	2.13” AMOLED Touchscreen (Red & Green Display)
Preloaded Courses	43,000+ global golf courses (free lifetime updates)
Slope Compensation	SmartSlope (adjustable for tournament play)
Water Protection	IP65 (Rain & Fog Mode)

Feature	Detail
Battery Type	Alkaline (Included)
Item Weight	9.38 Ounces
Dimensions (L x W x H)	5.8 x 4.37 x 3.6 inches

Warranty and Support

The MILESEEY GenePro G1 comes with a**10-Year Manufacturer Warranty**.
For technical support, warranty claims, or to request the addition of a new golf course, please contact MILESEEY customer service. Refer to the contact information provided in your product packaging or visit the official MiLESEEY website.
If your golf course is newly opened or isn't listed, please contact us. Our tech team can add it remotely within 1 Week.

© 2025 MiLESEEY. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question