

Subsonic SA5721-2

Subsonic Superdrive 270 GT-5 Racing Wheel User Manual

INTRODUCTION

This manual provides essential instructions for the setup, operation, and maintenance of your Subsonic Superdrive 270 GT-5 Racing Wheel. Designed for a realistic racing experience, this wheel is compatible with PlayStation 5 (PS5) and PC. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.

PACKAGE CONTENTS

Verify that all items are present in your package:

- Superdrive 270 GT-5 Racing Wheel
- Pedal Set (Brake and Accelerator)
- Adjustable Mounting Clamp
- Removable Suction Cups (5 units)
- USB Connection Cable

SETUP INSTRUCTIONS

Follow these steps to connect your racing wheel to your console or PC.

Physical Installation

1. **Mounting the Wheel:** Place the racing wheel on a stable surface such as a desk or table. Use the adjustable clamp to secure it firmly. Alternatively, attach the five removable suction cups to the bottom of the wheel for additional stability on smooth surfaces.

DUAL JOYSTICKS & PROGRAMMABLE LEDES



FIX COLORS



FIX RAINBOW



BREATHING COLORS

COLOR
ADJUSTMENT



The adjustable clamp and suction cups provide stable fixation for the racing wheel.

2. **Connecting the Pedals:** Connect the pedal set cable to the designated port on the rear of the racing wheel base.
3. **Connecting to Console/PC:** Plug the USB connection cable from the racing wheel into an available USB port on your PlayStation 5 or PC.



The Superdrive 270 GT-5 Racing Wheel is designed for use with PS5 and PC.

PS5 Specific Setup

For optimal performance on PlayStation 5, ensure your console settings are configured correctly:

1. **Access Settings:** From the PS5 home screen, navigate to the **Settings** icon (gear icon).



Navigate to the Settings menu on your PS5 console.

2. **Navigate to Accessories:** In the Settings menu, select **Accessories**.
3. **Select Controller (General):** Under Accessories, choose **Controller (General)**.
4. **Choose Communication Method:** Select **Communication Method**.



Follow the menu path to 'Communication Method'.

5. **Select Use USB Cable:** From the Communication Method options, select **Use USB Cable**.



Ensure 'Use USB Cable' is selected for controller communication.

6. **Activate Wheel:** After connecting the USB cable, press the **HOME** button on the racing wheel to activate it.



Connect the USB cable and press the HOME button on the wheel.


OPERATING INSTRUCTIONS

The Superdrive 270 GT-5 Racing Wheel offers various features for an immersive gaming experience.

Steering and Pedals

- **270-Degree Rotation:** The steering wheel provides a 270-degree rotation for precise control in racing games.

REALISTIC DRIVING EXPERIENCE



The racing wheel offers a 270-degree rotation for enhanced control.

- **Analog Pedals:** The included pedal set features analog brake and accelerator pedals for responsive input.
- **Paddle Shifters:** Use the integrated paddle shifters on the wheel for quick and intuitive gear changes.

Dual Joysticks and Programmable LEDs

The racing wheel includes dual joysticks, replicating full controller functionality, and programmable RGB LEDs.

- **Dual Joysticks:** The right and left joysticks provide access to all standard controller functions, conveniently located on the wheel.
- **Programmable RGB LEDs:** The LEDs around the joysticks can be customized to fix colors, display a rainbow effect, or show breathing colors. Refer to the programming section for detailed instructions on customization.

PROGRESSIVE LED



The dual joysticks feature programmable RGB LEDs with various display options.

Progressive LEDs

LEDs located on the top of the steering wheel provide visual feedback for acceleration and braking, enhancing immersion.

COMPATIBILITIES



Progressive LEDs on the wheel indicate acceleration and braking.

Programmable Keys and Sensitivity Levels

The wheel features programmable buttons and adjustable sensitivity to suit different racing styles and game types.

- **Programmable Buttons:** Specific buttons on the wheel can be programmed for custom functions. Refer to the dedicated programming section in the full manual for detailed instructions.
- **Sensitivity Levels:** Choose from three sensitivity levels:
 - **Low Sensitivity:** Suitable for most racing games, offering stable control.
 - **Medium Sensitivity:** Ideal for games with many curves, providing a balance of responsiveness and control.
 - **High Sensitivity:** Best for linking tight turns, offering maximum responsiveness.

STABLE & ADAPTABLE FIXATION



adjustable clamp



**5 removable
suction cups**

Adjustable sensitivity levels allow customization for various racing scenarios.

MAINTENANCE

To ensure the longevity and proper functioning of your racing wheel:

- **Cleaning:** Use a soft, dry cloth to clean the surfaces of the wheel and pedals. Avoid abrasive cleaners or solvents.
- **Storage:** Store the device in a cool, dry place away from direct sunlight and extreme temperatures.
- **Cable Care:** Avoid bending or twisting cables excessively. Disconnect cables by pulling the plug, not the cable itself.

TROUBLESHOOTING

If you encounter issues with your Superdrive 270 GT-5 Racing Wheel, refer to the following common solutions:

- **Wheel Not Responding:**

- Ensure all cables are securely connected to the wheel, pedals, and console/PC.
- For PS5, verify that the console's communication method is set to 'Use USB Cable' as described in the setup section.
- Try connecting the wheel to a different USB port on your console or PC.
- Restart your console or PC.

- **Disconnections During Gameplay (PS5):**

- This issue may occur if the PS5 perceives the wheel as a DualShock 4 controller and disconnects it. Ensure the 'Use USB Cable' setting is correctly applied and remains active.
- Ensure your PS5 system software is up to date.
- Avoid using USB hubs; connect the wheel directly to the console.

- **Pedals Not Responding:**

- Check the connection cable between the pedals and the wheel base.
- Test the wheel and pedals with a different game or on a different platform (if available) to isolate the issue.

- **LEDs Not Functioning:**

- Ensure the wheel is powered on and properly connected.
- Refer to the programming section (in the full manual) for LED customization and ensure settings are correct.

If problems persist after attempting these solutions, please contact Subsonic customer support.

SPECIFICATIONS

Feature	Detail
Model Number	SA5721-2
Compatibility	PlayStation 5, PC
Steering Rotation	270 degrees
Wheel Diameter	270 mm
Grip Material	Micro-perforated synthetic leather
Vibration Feedback	Dual vibration motors
Controls	Dual joysticks, paddle shifters, programmable buttons
LEDs	Programmable RGB LEDs (joysticks), progressive LEDs (acceleration/braking)
Sensitivity Levels	3 (Low, Medium, High)
Mounting	Adjustable clamp, removable suction cups
Pedals	Analog brake and accelerator with footrest
Dimensions (Package)	32 x 29.21 x 27.94 cm

Weight (Package)	2.5 kilograms
Origin	China

WARRANTY AND SUPPORT

The Subsonic Superdrive 270 GT-5 Racing Wheel comes with a **2-year manufacturer's warranty**. This warranty covers defects in materials and workmanship under normal use.

For technical support, warranty claims, or further assistance, please visit the official Subsonic website or contact their customer service department. Keep your proof of purchase for warranty validation.