

[Manuals.plus](#) /

› [Freaks and Geeks](#) /

› [Freaks and Geeks Wireless Controller 151000b User Manual](#)

## Freaks and Geeks 151000b

# Freaks and Geeks Wireless Controller 151000b User Manual

Model: 151000b | Brand: Freaks and Geeks

## INTRODUCTION

This manual provides comprehensive instructions for the Freaks and Geeks Wireless Controller, model 151000b. This versatile controller is designed for use with PlayStation 5 (PS5), PlayStation 5 Slim (PS5 Slim), PC (Steam only), Android devices, and iOS devices. It features Bluetooth connectivity, integrated LED lighting, precise motion tracking, a 1000 mAh rechargeable battery, and built-in audio capabilities including a speaker, microphone, and 3.5mm audio jack.

## PACKAGE CONTENTS

- Freaks and Geeks Wireless Controller (Model 151000b)
- USB Charging Cable
- User Manual



Image: The retail packaging for the Freaks and Geeks Wireless Controller, showing the controller and branding.

## CONTROLLER LAYOUT

---



Image: Front view of the Freaks and Geeks Wireless Controller, highlighting the directional pad, action buttons, analog sticks, Share, Options, and Home buttons, and the central touchpad.

The Freaks and Geeks Wireless Controller features a standard layout for intuitive gaming. Key components include:

- **Directional Pad (D-Pad):** Located on the left, for precise directional input.
- **Action Buttons:** Triangle, Circle, Cross, and Square buttons on the right.
- **Analog Sticks:** Two clickable analog sticks for 360-degree movement and camera control.
- **Share Button:** For sharing gameplay content.
- **Options Button:** For in-game menus and options.
- **Home Button:** To access the console/device home screen.
- **Touchpad:** Central interactive surface.
- **LED Indicators:** Integrated lighting for status and visual feedback.



Image: Top view of the Freaks and Geeks Wireless Controller, showing the L1, L2, R1, and R2 shoulder buttons and triggers, along with the USB-C charging port.

- **L1/R1 Buttons:** Shoulder buttons.
- **L2/R2 Triggers:** Analog triggers for variable input.
- **USB-C Port:** For charging and wired connection.



Image: Side view of the Freaks and Geeks Wireless Controller, highlighting the 3.5mm audio jack located at the bottom center.

- **3.5mm Audio Jack:** For connecting headsets.



Image: Back view of the Freaks and Geeks Wireless Controller, showing the textured grip and two additional programmable buttons (MR and ML) on the underside.

- **Programmable Buttons (MR/ML):** Additional buttons on the back for custom assignments.

## SETUP

---

### 1. Initial Charging

Before first use, fully charge the controller using the provided USB charging cable. Connect the USB-C end to the controller and the USB-A end to a compatible power source (e.g., console, PC, USB wall adapter). The LED indicator will show charging status and turn off or change color when fully charged.

### 2. Pairing with PlayStation 5 / PS5 Slim

1. Ensure your PS5/PS5 Slim console is powered on.
2. Connect the controller to the PS5/PS5 Slim console using the USB charging cable.
3. Press the Home button (**PS logo**) on the controller.
4. Once recognized, you can disconnect the USB cable for wireless play. The controller will automatically pair via Bluetooth.
5. To pair wirelessly without a cable (after initial wired pairing or if previously paired): Press and hold the Share button and the Home button simultaneously until the light bar flashes. Then, go to your PS5's Bluetooth settings and select the controller.

### 3. Pairing with PC (Steam Only)

1. Ensure your PC has Bluetooth enabled.
2. On the controller, press and hold the Share button and the Home button simultaneously until the LED light bar flashes rapidly, indicating pairing mode.

3. On your PC, go to **Settings > Devices > Bluetooth & other devices**
4. Click **Add Bluetooth or other device**, then select **Bluetooth**.
5. Select the "Wireless Controller" or similar name from the list of available devices.
6. Follow any on-screen prompts to complete pairing.
7. For optimal performance with Steam, ensure Steam Input is enabled for PlayStation controllers in Steam settings.

## 4. Pairing with Android / iOS Devices

1. Ensure Bluetooth is enabled on your Android or iOS device.
2. On the controller, press and hold the Share button and the Home button simultaneously until the LED light bar flashes rapidly, indicating pairing mode.
3. On your device, go to **Bluetooth settings**.
4. Look for "Wireless Controller" or a similar name in the list of available devices and tap to connect.
5. Once connected, the LED light bar will stop flashing and remain solid.

## OPERATING INSTRUCTIONS

---

### 1. Charging the Controller

Connect the controller to a power source using the USB charging cable. The 1000 mAh battery allows for extended gameplay. You can continue playing while the controller charges. The LED indicator will typically show a pulsating light during charging and turn off or change to a solid color when fully charged.

### 2. Motion Tracking

The controller features integrated motion tracking for immersive gameplay experiences in supported titles. Movements of the controller in space will be translated into in-game actions. Ensure the controller is held steadily when not actively using motion controls to prevent unintended input.

### 3. Using Speaker, Microphone, and Headset Jack

- **Integrated Speaker:** The controller has a built-in speaker for enhanced audio feedback in games.
- **Integrated Microphone:** Use the built-in microphone for in-game communication. Ensure microphone settings are correctly configured on your console or device.
- **3.5mm Audio Jack:** Connect any standard 3.5mm headset to the jack located at the bottom of the controller for private audio and microphone use. This will typically override the built-in speaker and microphone.

### 4. LED Indicators

The LED light bar provides visual feedback on the controller's status:

- **Flashing rapidly:** Pairing mode.
- **Solid light:** Connected and active.
- **Pulsating light:** Charging (may vary).
- **Slow flash:** Low battery.

## MAINTENANCE

---

### 1. Cleaning

To clean the controller, use a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive

cleaner. Avoid using harsh chemicals, solvents, or abrasive materials, as these can damage the controller's finish and internal components. Ensure no liquid enters openings such as the USB port or audio jack.

## 2. Storage

Store the controller in a cool, dry place away from direct sunlight, extreme temperatures, and high humidity. Avoid placing heavy objects on the controller to prevent damage to the analog sticks or buttons. If storing for an extended period, ensure the battery is partially charged (around 50%) to prolong its lifespan.

## TROUBLESHOOTING

---

- **Controller not connecting:**

- Ensure the controller is charged.
- Verify Bluetooth is enabled on your device/console.
- Try re-pairing the controller by following the setup instructions for your specific device.
- If on PS5, try connecting via USB cable first.
- Restart your console/device and the controller.

- **Buttons or analog sticks not responding:**

- Ensure the controller is properly connected.
- Check for any physical obstructions or debris around the buttons/sticks.
- Try resetting the controller (if a reset button is available, typically a small pinhole on the back).

- **Controller not charging:**

- Ensure the USB cable is securely connected to both the controller and the power source.
- Try a different USB port or power adapter.
- Test with a different USB-C cable if available.

- **Audio issues (speaker/microphone/headset):**

- Check audio settings on your console/device to ensure the controller's audio output/input is selected.
- Ensure the headset is fully plugged into the 3.5mm jack.
- Test the headset with another device to rule out headset issues.

## SPECIFICATIONS

---

<b>Model Number</b>	151000b
<b>Brand</b>	Freaks and Geeks
<b>Connectivity</b>	Bluetooth Wireless
<b>Compatibility</b>	PS5, PS5 Slim, PC (Steam only), Android, iOS
<b>Battery Capacity</b>	1000 mAh
<b>Dimensions (L x W x H)</b>	10 x 10 x 15 cm
<b>Weight</b>	250 grams

<b>Audio Features</b>	Integrated Speaker, Integrated Microphone, 3.5mm Audio Jack
<b>Special Features</b>	LED Lighting, Motion Tracking, Programmable Back Buttons

## WARRANTY INFORMATION

---

Specific warranty details for the Freaks and Geeks Wireless Controller (Model 151000b) are not provided in this manual. Please refer to the product packaging or the manufacturer's official website for the most current warranty terms and conditions.

## SUPPORT

---

For further assistance, technical support, or inquiries regarding your Freaks and Geeks Wireless Controller, please visit the official Freaks and Geeks website or contact their customer service department. Contact information can typically be found on the product packaging or their official online presence.

