PINDOWS PDS-G652

PINDOWS G652 Minimalist Quartz Analog Watch User Manual

Model: PDS-G652

Introduction

This manual provides essential instructions for the setup, operation, maintenance, and troubleshooting of your PINDOWS G652 Minimalist Quartz Analog Watch. Please read this guide thoroughly to ensure proper use and care of your timepiece.

Product Overview

The PINDOWS G652 is a minimalist quartz analog watch featuring a gold-tone case, a green dial with clear numbering, and a black leather strap. It is designed for reliable timekeeping and comfortable daily wear.





Image: Front view of the PINDOWS G652 watch, showcasing the green dial, gold-tone case, and black leather strap.

Setup

1. Unpacking and Initial Inspection

Your PINDOWS watch is typically packaged in a protective tin. Carefully remove the watch and inspect it for any visible damage. Ensure the crown (the small knob on the side of the watch case) is pushed in to prevent battery

drain during storage.

2. Setting the Time

1. **Pull out the crown:** Gently pull the crown outwards to the first position. You may feel a slight click.
2. **Adjust the time:** Rotate the crown clockwise or counter-clockwise until the hour and minute hands display the correct time.
3. **Push in the crown:** Once the time is set, push the crown back into its original position. The second hand should begin to move, indicating the watch is running.

3. Adjusting the Strap

The watch features a black leather strap with a buckle closure. To adjust the fit:

1. Insert the pin of the buckle into the desired hole on the strap that provides a comfortable and secure fit on your wrist.
2. Ensure the strap is not too tight, which could restrict circulation, or too loose, which could cause the watch to move excessively.

Operating the Watch

Timekeeping

Your PINDOWS G652 watch is equipped with a reliable Japanese quartz movement, ensuring accurate timekeeping. Once the time is set, the watch will continuously display the current time.

Luminous Dial

The watch dial features luminous elements that absorb light and glow in low-light conditions, enhancing visibility. Exposure to sufficient light is required for the luminous effect to be active.



Image: The PINDOWS G652 watch dial illuminated in a dark environment, demonstrating its luminous feature for enhanced visibility.

Maintenance

Water Resistance (30M / 3 ATM)

The PINDOWS G652 watch is water-resistant to 30 meters (3 ATM). This means it is suitable for daily use and can withstand splashes, rain, or brief immersion in water, such as during hand washing. It is **not** suitable for showering, bathing, swimming, diving, or any water sports. Avoid operating the crown while the watch is wet.

Cleaning the Watch

To maintain the appearance of your watch:

- Wipe the watch case and crystal with a soft, dry cloth.
- For stubborn dirt, a slightly damp cloth can be used, followed by immediate drying.
- Avoid using chemical cleaners, solvents, or abrasive materials, as these can damage the watch's finish.

Leather Strap Care

The black leather strap requires proper care to ensure its longevity:

- Avoid prolonged exposure to direct sunlight, extreme temperatures, and moisture.
- If the strap gets wet, gently pat it dry with a soft cloth and allow it to air dry completely away from direct heat.
- Periodically clean the strap with a soft, slightly damp cloth. Specialized leather cleaners can be used if necessary, following the product instructions.

Battery Replacement

The watch is powered by a quartz battery. When the watch stops running, the battery may need replacement. It is recommended to have the battery replaced by a qualified watch technician to ensure the water resistance seal is properly maintained.



Image: Rear view of the PINDOWS G652 watch, highlighting the stainless steel back cover which protects the internal movement and battery.

Troubleshooting

If you encounter any issues with your PINDOWS G652 watch, please refer to the following common problems and solutions:

- **Watch not running:**

- Ensure the crown is fully pushed in.
- The battery may be depleted. Refer to the Battery Replacement section.

- **Time is inaccurate:**
  - Check if the crown is fully pushed in after setting the time.
  - Extreme temperatures or strong magnetic fields can affect quartz movement accuracy. Avoid such environments.
  - A low battery can also affect accuracy. Consider battery replacement.

If these steps do not resolve the issue, please contact PINDOWS customer support for further assistance.

Specifications

Feature	Detail
Model Number	PDS-G652
Movement	Japanese Quartz
Case Material	Gold-Tone Alloy
Case Thickness	Approximately 8 mm
Strap Material	Black Leather
Dial Color	Green
Water Resistance	30 Meters (3 ATM)



Image: Side profile of the PINDOWS G652 watch, illustrating its slim 8mm case thickness.

Warranty

PINDOWS is committed to providing quality products. While specific warranty details may vary, we strive to ensure customer satisfaction. For any issues or dissatisfaction with your watch, please contact our customer service team.

Support

For further assistance, technical support, or inquiries regarding your PINDOWS G652 watch, please refer to the

contact information provided at the point of purchase or visit the official PINDOWS website.

© 2025 PINDOWS. All rights reserved.