Manuals+

Q & A | Deep Search | Upload

manuals.plus /

- WELLFOR /
- > WELLFOR WB-SH003MB 10-inch Wall Mounted Shower Faucet System User Manual

WELLFOR WB-SH003MB

WELLFOR WB-SH003MB 10-inch Wall Mounted Shower Faucet System User Manual

Model: WB-SH003MB

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before installation and use. Failure to follow these instructions may result in property damage, personal injury, or void the product warranty.

- Installation should be performed by a qualified professional plumber.
- Ensure all local plumbing and building codes are met.
- Turn off the main water supply before beginning any installation or maintenance.
- Protect all finished surfaces during installation to prevent scratches or damage.
- Do not use harsh chemicals or abrasive cleaners on the product finish.

2. PRODUCT COMPONENTS

Verify that all components are present and undamaged before proceeding with installation. Refer to the diagram below for identification.



Figure 2.1: Overview of all shower system components, including the rough-in valve, control panel, overhead shower head, handheld sprayer, hose, and mounting hardware.

- 1. Rough-in Valve with Pressure Balance Cartridge
- 2. Control Panel Trim (Temperature and Diverter Handles)
- 3. 10-inch Overhead Shower Head with Wall-Mounted Arm
- 4. Handheld Shower Sprayer
- 5. Flexible Shower Hose (304 Stainless Steel)
- 6. Handheld Shower Holder
- 7. Mounting Hardware and Seals

3. SETUP AND INSTALLATION

This section outlines the general steps for installing the WELLFOR WB-SH003MB shower system. Professional installation is highly recommended.

3.1 Rough-in Valve Installation

The pressure balance rough-in valve is designed to maintain consistent water temperature and pressure.

Ensure proper depth and orientation during installation.



Figure 3.1: The rough-in valve, showing connections for hot and cold water supply and outlets for the shower components.

Note the "UP" and "IMPORTANT" markings for correct orientation.

- 1. Turn off the main water supply to the installation area.
- 2. Mount the rough-in valve securely within the wall, ensuring it is plumb and at the correct depth relative to the finished wall surface. The valve includes clear wall-depth markings.
- 3. Connect the hot and cold water supply lines to the designated inlets on the valve.
- 4. Connect the outlets from the valve to the overhead shower arm and the handheld shower hose connection point.
- 5. Perform a leak test before closing the wall.

3.2 Trim and Component Installation

Once the rough-in valve is installed and tested, proceed with installing the visible trim and shower



Figure 3.2: The complete WELLFOR shower system installed, showcasing the matte black finish of the overhead shower, handheld sprayer, and control panel.

- 1. Install the wall-mounted shower arm and attach the 10-inch overhead shower head. The brass ball joint allows for adjustable angles.
- 2. Install the handheld shower holder and connect the flexible shower hose. Attach the handheld sprayer to the hose.
- 3. Mount the control panel trim plate and secure the temperature and diverter handles onto the valve stems.
- 4. Ensure all connections are tight and sealed to prevent leaks.

4. OPERATING INSTRUCTIONS

The WELLFOR WB-SH003MB shower system features a dual-function control for water flow and temperature.




Figure 4.1: The control panel, featuring the lower handle for temperature adjustment and the upper knob for diverting water flow.

- **Temperature Control:** The lower handle controls the water temperature. Rotate it to adjust between hot (red indicator) and cold (blue indicator) water. The pressure balance valve will maintain a consistent temperature once set.
- Water Diverter: The upper knob is the 2-way diverter.
 - Rotate the knob to the first position to activate the 10-inch overhead shower.
 - Rotate the knob to the second position to activate the handheld shower sprayer.
 - Ensure the diverter is fully engaged in either position for optimal water flow.



Figure 4.2: The 10-inch overhead shower delivering a wide spray pattern.



Figure 4.3: The handheld shower sprayer providing a focused stream of water.

5. MAINTENANCE

Regular maintenance will ensure the longevity and optimal performance of your WELLFOR shower system.

- Cleaning: Clean the matte black finish with a soft, damp cloth. For stubborn spots, use a mild soap solution and rinse thoroughly. Avoid abrasive cleaners, scouring pads, or chemicals containing ammonia, bleach, or alcohol, as these can damage the finish.
- **Shower Head Nozzles:** Periodically inspect the silicone nozzles on the overhead and handheld shower heads for mineral buildup. Gently rub the nozzles to dislodge any deposits.
- Cartridge Inspection: If you notice persistent drips or difficulty in temperature control, the ceramic cartridge may need inspection or replacement. This typically requires professional assistance.
- **Hose Inspection:** Check the flexible shower hose for any signs of wear, kinks, or leaks. Replace if necessary.

6. TROUBLESHOOTING

Refer to this section for common issues and their potential solutions.

Problem	Possible Cause	Solution
Low Water Pressure	 Partially closed main water valve Clogged shower head nozzles Debris in the rough-in valve 	 Ensure main water valve is fully open. Clean shower head nozzles by rubbing them. Consult a plumber to inspect the valve.
Water Temperature Fluctuations	Issue with pressure balance cartridgeInconsistent hot/cold water supply	 Contact a plumber for cartridge inspection/replacement. Check water heater settings and supply.
Leaks from Connections	Loose connectionsDamaged seals/O-rings	 Ensure all connections are tightened properly (do not overtighten). Replace any damaged seals or O-rings.
Diverter Not Switching Properly	Debris in diverter mechanismWorn diverter cartridge	 Flush the system. Contact a plumber for diverter cartridge inspection/replacement.

7. SPECIFICATIONS

Feature	Detail	
Brand	WELLFOR	
Model Number	WB-SH003MB	
Color	Matte Black	
Material	Stainless Steel (Panel, Horizontal Bar, Hose), Brass (Ball Joint, Connectors)	
Finish Type	Matte	
Number of Handles	1 (Dual Function)	
Mounting Type	Wall Mount	
Shower Head Size	10 inches	
Valve Type	Pressure Balance Valve with Ceramic Cartridge	
Product Dimensions	20 x 13 x 8 inches (Packaging/Overall)	
UPC	754236109234	

8. WARRANTY AND SUPPORT

For warranty information or technical support, please contact WELLFOR customer service. Details regarding specific warranty periods and coverage are typically provided with your purchase documentation or can be obtained directly from the manufacturer.

Please retain your proof of purchase for any warranty claims.

Contact Information: Refer to the contact details provided on the WELLFOR website or your purchase receipt.

Related Documents - WB-SH003MB



WELLFOR Shower Faucet System Installation and Maintenance Guide

Comprehensive installation and maintenance guide for WELLFOR shower faucet systems, detailing setup, troubleshooting, and cleaning procedures. Includes product specifications and contact information.



WELLFOR WB-0977BN/MB/BG Luxury Shower System: Installation Guide and Product Information

Detailed installation guide, parts list, and specifications for the WELLFOR WB-0977BN/MB/BG Luxury Shower System. Includes features, maintenance tips, and warranty information. Designed in the USA, Made in China.




WELLFOR WB-FA061MB Wall Mounted Bathroom Faucet User Manual & Installation Guide

Official user manual and installation guide for the WELLFOR WB-FA061MB wall-mounted bathroom faucet. Includes detailed installation instructions, cleaning care, and product specifications.



WELLFOR WF-S3545 Luxury Shower System Installation Guide

Comprehensive installation guide for the WELLFOR WF-S3545 Luxury Shower System, including pressure balance valve, rainfall shower head, hand shower, and body jets. Details on parts, tools, and step-by-step assembly.



WELLFOR WF-3805 Series Luxury 3-Function Thermostatic Shower System Installation Guide

Comprehensive installation guide and product overview for the WELLFOR WF-3805 Series Luxury 3-Function Thermostatic Shower System, detailing components, tools, installation steps, and maintenance.



WELLFOR Luxury Shower System WF-S1607 Series Installation and Maintenance Guide

Comprehensive guide for the WELLFOR WF-S1607BN, WF-S1607MB, and WF-S1607BG Luxury Shower System. Covers product overview, installation features, parts list, valve piping, concealed mounting, installation steps for valve, shower head, and sliding bar, diverter knob installation, and maintenance procedures. Includes specifications and warranty information.