Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

IDEALHOUSE L2jlggx3sWH0dseWwB0dMA1CyeB7c

IDEALHOUSE White 3-Drawer Dresser Instruction Manual

Model: L2jlggx3sWH0dseWwB0dMA1CyeB7c | Brand: IDEALHOUSE

Introduction

Thank you for choosing the IDEALHOUSE White 3-Drawer Dresser. This modern dresser is designed to provide ample storage and enhance the aesthetic of your bedroom, living room, or entryway. Crafted from durable engineered wood with elegant gold metal accents, it offers both functionality and style. This manual provides essential information for safe assembly, operation, maintenance, and troubleshooting.

Safety Information

- **Anti-Tip Device:** An anti-tip device is included to prevent the dresser from tipping over. It is crucial to install this device securely to a wall stud to ensure the safety of children and pets. Failure to install the anti-tip device can result in serious injury or death.
- **Weight Distribution:** Distribute weight evenly across drawers and the top surface. Avoid placing excessively heavy items on top of the dresser.
- **Drawer Safety:** Do not allow children to climb on or play with the drawers. Keep drawers closed when not in use.
- **Assembly:** Assemble the dresser on a soft, clean surface to prevent scratches. Ensure all hardware is tightened securely before use.

Package Contents

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Dresser Panels (Top, Bottom, Sides, Back)
- Drawer Panels and Bottoms (3 sets)
- Gold Metal Legs and Support Frame
- Gold Metal Handles (3)
- Drawer Slides and Hardware
- Assembly Hardware (screws, dowels, cam locks, etc.)
- Anti-Tip Kit
- Assembly Instructions Manual

Setup and Assembly

Assembly is required for this dresser. Please follow the detailed graphic instructions provided in your package. A Phillips head screwdriver and a hammer (not included) may be required in addition to the tools provided.

1. **Unpack and Identify Parts:** Carefully unpack all components and lay them out on a soft, clean surface to prevent damage. Identify each part using the provided parts list.
2. **Assemble the Frame:** Begin by assembling the main frame of the dresser, attaching the side panels to the top and bottom panels using the specified hardware.
3. **Install Drawer Slides:** Attach the drawer slides to the interior of the dresser frame and to the drawer sides as indicated in the instructions.
4. **Assemble Drawers:** Construct each of the three drawers, ensuring the bottoms are securely inserted and all hardware is tightened. Attach the gold metal handles to the front of each drawer.
5. **Attach Metal Legs:** Secure the gold metal legs and support frame to the bottom of the dresser.
6. **Insert Drawers:** Carefully slide the assembled drawers into their respective slots. Ensure they open and close smoothly.
7. **Install Anti-Tip Device:** Securely attach the anti-tip device to the back of the dresser and to a wall stud. This step is critical for safety.



Image: Detailed dimensions of the dresser (15.8"D x 23.6"W x 27.9"H) and individual drawers (14"D x 22.2"W x 6.5"H).

Your browser does not support the video tag.

Video: Assembly guide for an IDEALHOUSE dresser. While this video features a 7-drawer model, the general assembly steps and techniques may be similar and helpful for your 3-drawer dresser.

Operating Instructions

- **Drawer Use:** The drawers are designed for smooth operation. Pull and push drawers gently using the handles. Avoid forcing them.

- **Storage Capacity:** Each drawer is suitable for storing clothing, accessories, or other personal items. The dresser has a maximum load capacity of 20kg (approximately 44 lbs) for the entire unit. Distribute items evenly.
- **Top Surface:** The large desktop surface can hold decorative items, lamps, or other light objects. Ensure items are stable and do not overhang precariously.



Image: The 3-drawer dresser with drawers open, illustrating storage capacity and indicating a maximum load of 20kg.



Image: Detailed views highlighting the large desktop, gold metal handles, smooth drawer operation, and the stable gold metal support frame.

Maintenance

Proper care will ensure the longevity and appearance of your dresser.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, as these can damage the finish.
- **Spills:** Although the engineered wood is waterproof, wipe up spills immediately to prevent potential damage or staining.
- **Scratches:** The material is scratch-resistant, but avoid dragging sharp or heavy objects across the surface to maintain its appearance.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **Sunlight:** Avoid prolonged exposure to direct sunlight to prevent fading or discoloration.

Troubleshooting

Problem	Possible Cause	Solution
Dresser is wobbly.	Loose hardware; uneven floor.	Check and tighten all assembly screws. Ensure the dresser is on a level surface; use shims if needed.
Drawers do not slide smoothly.	Drawer slides misaligned; obstruction in the track.	Ensure drawer slides are correctly installed and aligned. Check for any objects obstructing the tracks.
Missing parts or damaged components.	Packaging error or shipping damage.	Do not proceed with assembly. Contact IDEALHOUSE customer support immediately for replacement parts.
Anti-tip device not secure.	Improper installation; not anchored to a stud.	Re-install the anti-tip device, ensuring it is firmly anchored into a wall stud. Consult a professional if unsure.

Specifications

- **Brand:** IDEALHOUSE
- **Model Number:** L2jlggx3sWH0dseWwB0dMA1CyeB7c
- **UPC:** 199414613682
- **Product Dimensions (D x W x H):** 15.8" x 23.6" x 27.9"
- **Number of Drawers:** 3
- **Color:** White
- **Material:** Engineered Wood
- **Finish Type:** Polished
- **Item Weight:** 49 pounds
- **Additional Features:** Rust Resistant, Safety Stop, Scratch Resistant, Soft Close, Termite Resistant



Image: Front view of the IDEALHOUSE White 3-Drawer Dresser, showcasing its modern design, gold handles, and geometric pattern.

Warranty and Support

For warranty information, missing parts, or any product-related inquiries, please refer to the contact information provided with your purchase or visit the official IDEALHOUSE website. Our customer support team is available to assist you with any issues or questions you may have.

Online Support: Visit the IDEALHOUSE Store on Amazon

© 2023 IDEALHOUSE. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FM82XSBR

More documents and user manuals: **https://manuals.plus/**