

Max Build More 83186H

Max Build More Premium Snacks Sushi Building Brick
Collection

Instruction Manual

- [Introduction](#)
- [Safety Information](#)
- [Package Contents](#)
- [Setup & Assembly](#)
- [Operating](#)
- [Instructions](#)
- [Maintenance](#)
- [Troubleshooting](#)
- [Specifications](#)
- [Warranty & Support](#)

1. INTRODUCTION

This manual provides detailed instructions for the assembly, use, and care of your Max Build More Premium Snacks Sushi Building Brick Collection. This set allows you to construct a detailed sushi model using high-quality building bricks. Please read all instructions carefully before beginning assembly.



Image 1.1: The Max Build More Premium Snacks Sushi Building Brick Collection.

2. SAFETY INFORMATION

WARNING: CHOKING HAZARD – Small parts. This product contains small parts and is not suitable for children under 3 years of age. Adult supervision is recommended during assembly and play, especially with younger users, to prevent accidental ingestion of small components.

Keep all packaging materials away from children to avoid suffocation risks.

3. PACKAGE CONTENTS

Your Max Build More Premium Snacks Sushi Building Brick Collection package should contain the following items:

- MAX Premium Snacks (Sushi) building brick set (up to 200 pieces)
- Instruction Manual




Image 4.1: Visual assembly guide for the Sushi model. Follow the diagrams to connect the bricks correctly.

Once all pieces are assembled, ensure they are securely connected. The completed model can then be placed on its display base.

5. OPERATING INSTRUCTIONS (DISPLAY AND COLLECTION)

Your Max Build More Premium Snacks Sushi model is designed for display and collection. After assembly, you can:

- **Display:** Place your completed sushi model on its base in a prominent location. The model is suitable for desks, shelves, or display cabinets.
- **Collect:** This Sushi model is part of a larger collection of 6 different snack-themed building sets. You can collect other sets like the Burger, Ice Cream, Pizza, Hotdog, and Donut to expand your collection.
- **Compatibility:** Max Build More bricks are compatible with major building brick brands, allowing for integration into existing collections.



Image 5.1: The assembled Sushi model ready for display.



Image 5.2: Other snack models available in the Max Build More Premium Snacks collection.

6. MAINTENANCE

To keep your building brick model in optimal condition:

- **Cleaning:** Gently wipe the assembled model with a soft, dry cloth to remove dust. For more thorough cleaning, use a damp cloth with mild soap and water, then rinse and air dry completely. Avoid harsh chemicals or abrasive materials.
- **Storage:** Store the model away from direct sunlight and extreme temperatures to prevent material degradation or discoloration.
- **Handling:** Handle the model carefully to avoid accidental disassembly or damage to individual bricks.

7. TROUBLESHOOTING

If you encounter any issues during assembly or with your completed model, consider the following:

- **Missing Pieces:** Carefully check the packaging and surrounding area for any small pieces that may have been overlooked. If pieces are genuinely missing, contact customer support.
- **Difficulty Connecting Bricks:** Ensure bricks are aligned correctly before applying gentle, firm pressure. Avoid forcing bricks together, as this can cause damage.
- **Model Instability:** Double-check all connections according to the assembly instructions. Loose connections can lead to an unstable model.

8. PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Max Build More
Model Name	Sushi
Model Number	83186H
Material	Plastic
Color	Sushi (Multi-color)
Number of Pieces	Up to 200 (approx. 157 for this specific model)
Recommended Minimum Age	6 years (72 months)
Educational Objective	Building Skills
Dimensions (Item)	11.5 x 11.5 x 11.5 cm (approx. 4.5 x 4.5 x 4.5 inches)
UPC	193052073150
Manufacturer	ZURU

9. WARRANTY & SUPPORT

This product is manufactured by ZURU. For any questions, concerns, or support regarding your Max Build More Premium Snacks Sushi Building Brick Collection, please refer to the official ZURU website or contact their customer service department.

Please retain your proof of purchase for any warranty claims, if applicable. Specific warranty details may vary by region and retailer.

For more information, visit: www.zuru.com

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question