

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Fanbulous](#) /

› [Fanbulous 48 Inch Oil Bronze Ceiling Fan with Lights and Remote User Manual DS48](#)

Fanbulous DS48

Fanbulous 48 Inch Oil Bronze Ceiling Fan with Lights and Remote

MODEL: DS48

Introduction

This manual provides detailed instructions for the safe installation, operation, and maintenance of your Fanbulous 48-inch Oil Bronze Ceiling Fan with Lights and Remote (Model DS48). Please read this manual thoroughly before installation and retain it for future reference. Proper installation and use are essential for optimal performance and safety.

Safety Information

- Always disconnect power at the main fuse or circuit breaker before installing or servicing the fan.
- All wiring must be in accordance with national and local electrical codes. If you are unfamiliar with wiring, consult a qualified electrician.
- The fan must be mounted to a ceiling joist or support structure capable of supporting a minimum of 35 lbs (15.9 kg).
- Ensure all connections are secure and properly insulated to prevent electrical shock.
- Do not operate the fan if any part is damaged.
- Keep hands, clothing, and other objects away from the fan blades when the fan is in operation.

Package Contents

Verify that all components are present before beginning installation:

- Ceiling Fan Motor Assembly
- Fan Blades (5)
- Light Kit Assembly

- Remote Control with Wall Holder
- Mounting Bracket
- Hardware Pack (screws, wire nuts, washers)
- Instruction Manual

Specifications

Feature	Specification
Brand	Fanbulous
Model Number	DS48
Color	Oil Bronze
Size	48 inch
Product Dimensions	48"D x 48"W x 8"H
Power Source	AC/DC
Voltage	120 Volts
Motor Type	DC Quiet Motor
Noise Level	Less than 35 Decibels
Fan Speeds	6 Speeds
Light Color Temperature (CCT)	3000K (Warm White), 4500K (Natural White), 6000K (Cool White)
Control Method	Remote Control
Timer Functions	1H, 4H, 8H
Blade Material	Engineered Wood (Reversible: Light wood grain / Walnut color)
Item Weight	12.27 pounds

Installation

Professional installation is recommended. Ensure power is disconnected before proceeding.

- 1. Mounting Bracket Installation:** Secure the mounting bracket to a suitable ceiling junction box or support structure. Ensure it is firmly attached and can support the fan's weight.
- 2. Wiring Connections:** Connect the fan's electrical wires to the household wiring according to local codes. Typically, this involves connecting live, neutral, and ground wires. Ensure all connections are tight and covered with wire nuts.
- 3. Motor Assembly Attachment:** Carefully lift the fan motor assembly and attach it to the mounting bracket. Use the provided safety cable if applicable.
- 4. Blade Installation:** Attach the five fan blades to the motor housing. The blades are reversible, offering a choice between a light wood grain and a walnut color finish. Select your preferred side before securing them.

5. **Light Kit Installation:** Connect the light kit wiring to the fan motor assembly and secure the light kit in place.



Figure 1: Product Dimensions. This image illustrates the key measurements of the 48-inch ceiling fan, including the 48-inch diameter and 8-inch height, along with individual blade dimensions.

Fanbulous

3-Color Temperature

Meet the light demand in different scenarios



Figure 2: Reversible Fan Blades. This image highlights the dual-sided design of the fan blades, offering both a light wood grain and a darker walnut color option for aesthetic customization.

Operating Instructions

Your Fanbulous ceiling fan is controlled by the included remote. Ensure batteries are installed correctly in the remote.

Fanbulous

6 Speeds Selectable

Choose the wind speed according to your need



LOW WIND
Level 1-2 Soft Wind



MED WIND
Level 3-4 Natural Wind



HIGH WIND
Level 5-6 Cool wind

Figure 3: Remote Control. This image displays the remote control with clearly labeled buttons for various fan and light functions, including speed settings, light on/off, color temperature adjustment, timer, and reverse mode.

- **Power On/Off:** Press the power button (usually red) to turn the fan and light on or off.
- **Fan Speed Control:** Use the numbered buttons (1-6) to select your desired fan speed. The fan features 6 distinct speeds, from a gentle breeze to a powerful airflow.

2-Colors in One Blade

Suitable for variety decoration styles



Figure 4: 6 Speeds Selectable. This graphic details the six fan speed settings, allowing users to choose the airflow intensity according to their preference, from soft to cool wind.

- **Light Control (3CCT):** Press the light button to cycle through the three color temperature options: Warm White (3000K), Natural White (4500K), and Cool White (6000K). Press and hold the light button to dim or brighten the light.

Fanbulous

6-Speed Reversible


Cool in summer, warm in winter



Figure 5: 3-Color Temperature Adjustable. This image demonstrates the three adjustable light color temperatures (3000K, 4500K, 6000K) to suit different moods and scenarios.

- **Reversible Motor Function:** Use the reverse button on the remote to change the direction of the fan blades. In summer, blades should rotate counter-clockwise to push cool air down. In winter, blades should rotate clockwise to draw warm air up and circulate it.

48 Inch Ceiling Fan with Lights



Timer: 1/4/8 H



Control Distance: <15 M



Certificate: FCC



Wind Speed: 6 Speeds



LED Light: 3CCT



Material: Engineered Wood

Figure 6: 6-Speed Reversible Motor. This diagram illustrates how the fan's reversible motor function works, providing cool air in summer and circulating warm air in winter for year-round comfort.

- **Timer Function:** Select 1H, 4H, or 8H on the remote to set the fan to automatically turn off after the specified duration.

Maintenance

- **Cleaning:** To clean the fan, wipe with a soft, damp cloth. Do not use abrasive cleaners or solvents, as these may damage the finish or electrical components.

- **Blade Care:** Periodically check the fan blades for dust accumulation. Clean them gently to maintain balance and airflow efficiency.
- **Tightness:** Occasionally check that all screws and connections are tight.

Troubleshooting

Problem	Possible Cause	Solution
Fan does not start	No power to the fan; Loose wire connections; Remote control battery low or not paired.	Check circuit breaker/fuse; Verify all wire connections are secure; Replace remote batteries or re-pair remote.
Light does not turn on	Light kit wiring issue; LED driver malfunction; Remote control issue.	Check light kit connections; Ensure remote batteries are fresh; Contact customer support if issue persists.
Fan wobbles	Loose blades or mounting hardware; Unbalanced blades.	Tighten all blade screws and mounting hardware; Use a balancing kit (not included) to balance blades if necessary.
Remote not responding or inconsistent operation	Low remote battery; Interference; Remote not paired correctly.	Replace remote batteries; Ensure no obstructions between remote and receiver; Re-pair remote according to instructions (if applicable).
Delay in light turning on via wall switch	Inherent design characteristic with certain wiring setups.	This may be a normal operational characteristic. Ensure wiring is correct for single-switch operation if dual switches are not supported.

Warranty and Support

This Fanbulous ceiling fan comes with a **2-Year Manufacturer Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. For warranty claims, technical support, or replacement parts, please contact Fanbulous customer service through the retailer where the product was purchased. Please have your model number (DS48) and proof of purchase available.