

[Manuals.plus](#) /

> [Wireless Express](#) /

> Wireless Express Lumina Jellyfish Mood Lamp (SKU-VOLRED) User Manual

Wireless Express SKU-VOLRED

Wireless Express Lumina Jellyfish Mood Lamp (SKU-VOLRED) User Manual

MODEL: SKU-VOLRED

Brand: Wireless Express

Introduction

The Wireless Express Lumina Jellyfish Mood Lamp is designed to create a calming and immersive ambiance in your living space. This lamp features lifelike jellyfish that move within a water-filled chamber, illuminated by customizable RGB LED lighting. It also includes a built-in Bluetooth speaker and white noise functions for a multi-sensory experience. This manual provides instructions for setup, operation, and maintenance of your Lumina Jellyfish Mood Lamp.



Image: The Lumina Jellyfish Mood Lamp in operation, showcasing its blue illumination and artificial jellyfish.

What's in the Box

Please check the package contents to ensure all items are present:

- Lumina Jellyfish Mood Lamp Unit (Base and Cylinder)
- 2 x Artificial Jellyfish

- Remote Control
- Power Adapter
- Instruction Manual (this document)

Setup Instructions

1. **Unpack the Lamp:** Carefully remove all components from the packaging. Place the lamp base on a stable, flat surface.
2. **Fill with Water:** Remove the top lid of the lamp. Fill the transparent cylinder with distilled water up to the indicated fill line. Avoid overfilling.
3. **Add Jellyfish:** Gently place the artificial jellyfish into the water. If they float at the top, use a stick or similar object to push them down and release any trapped air bubbles. This may take a few minutes.
4. **Secure the Lid:** Replace the top lid firmly to prevent water spillage.
5. **Connect Power:** Plug the power adapter into the lamp's power input port, then plug the adapter into a standard electrical outlet.
6. **Remote Control Battery:** Ensure the remote control has a working battery. If not, insert or replace with the correct battery type.

Note: It may take up to 24 hours for the jellyfish to fully acclimate and move naturally within the water.

Operating Instructions

Power On/Off

Press the "ON/OFF" button on the remote control or the touch-sensitive switch on the lamp base to turn the lamp on or off.

LED Lighting Modes

Use the remote control to select various RGB LED lighting modes and colors. The remote typically includes buttons for specific colors (e.g., Red, Green, Blue) and modes (e.g., Flash, Strobe, Fade, Smooth) to customize the ambiance.

JELLYFISH SPEAKER MOOD LAMP



Built-in Speaker



Multi Color changing
LED Lights



White Noise Feature



Remote Control



Auto Shut-Off




Image: The Lumina Jellyfish Mood Lamp displaying various color options and highlighting its features, including the remote control.





Purple Illumination





Green Illumination





Red Illumination

Bluetooth Speaker Function

1. **Pairing:** Turn on the lamp. Activate Bluetooth on your mobile device and search for "Lumina Jellyfish Lamp" or a similar device name. Select it to pair.
2. **Playback:** Once paired, you can play audio from your device through the lamp's built-in speaker.
3. **Volume Control:** Adjust volume using your connected device.

White Noise Feature

The lamp includes a white noise function to aid relaxation. Refer to the remote control for a dedicated white noise button or a mode selection that includes white noise.

Auto Shut-Off Timer

The lamp features an auto shut-off timer for convenience. Consult the remote control for timer settings (e.g., 1-hour, 2-hour options).

Product Video Overview

Your browser does not support the video tag.

Video: An official product video demonstrating the color-changing LED lights, remote control functionality, white noise feature, and built-in speaker of the Lumina Jellyfish Mood Lamp.

Maintenance

Cleaning

To clean the exterior of the lamp, use a soft, damp cloth. Do not use abrasive cleaners or solvents. For the interior, if the water becomes cloudy, it is recommended to replace the distilled water. Unplug the lamp before cleaning.

Water Replacement

If the water appears cloudy or the jellyfish movement is hindered, replace the water. Unplug the lamp, remove the lid, and carefully pour out the old water. Rinse the cylinder and jellyfish with clean water, then refill with fresh distilled water as per setup instructions.

Troubleshooting

Lamp does not turn on:

Ensure the power adapter is securely plugged into both the lamp and a working electrical outlet. Check if the outlet is functional. Verify the remote control battery is not depleted.

Jellyfish are not moving or floating at the top:

This is common during initial setup. Gently push the jellyfish down with a non-sharp object to release trapped air bubbles. It may take up to 24 hours for them to move freely. Ensure only distilled water is used.

Bluetooth speaker not connecting:

Ensure the lamp is powered on and Bluetooth is enabled on your device. Try restarting both the lamp and your device. Make sure no other device is currently paired with the lamp.

Lights are not changing colors:

Check the remote control battery. Ensure you are pressing the correct buttons for color selection or mode changes.

Specifications

Feature	Detail
Model Number	SKU-VOLRED
Brand	Wireless Express
Product Dimensions	7"D x 7"W x 17.5"H
Lamp Type	Mood Light
Light Source Type	RGB LED
Power Source	Corded Electric
Voltage	12 Volts
Wattage	5 watts
Control Method	Touch, Remote Control
Connectivity Protocol	Bluetooth
Material Type	Metal, Glass
Indoor/Outdoor Usage	Indoor
Water Resistance Level	Not Water Resistant

Warranty and Support

This product comes with a limited warranty from Wireless Express. For specific warranty details, please refer to the documentation included with your purchase or visit the official Wireless Express website.

Manufacturer Warranty Description: Limited warranty.

For technical support or customer service, please contact Wireless Express directly through their official channels.

