Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Avrsol DRFG-1

Avrsol Kids Play Tent with Padded Mat Instruction Manual

Model: DRFG-1

Introduction

Thank you for choosing the Avrsol Kids Play Tent with Padded Mat. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new play tent. Please read these instructions carefully before use and retain them for future reference.



Image: The Avrsol Kids Play Tent with Padded Mat, showcasing its overall design and grey color.

Safety Information

WARNING: CHOKING HAZARD - Small parts. Not for children under 3 years.

- Always supervise children when they are playing in or around the tent.
- Keep the tent away from open flames, heat sources, and electrical heaters.
- Ensure all poles are securely connected and the tent fabric is properly attached to prevent collapse.
- Do not allow children to hang on the tent structure.
- Inspect the tent regularly for any damage or wear. Discontinue use if damaged.
- This product is intended for indoor and light outdoor use. Avoid use in strong winds or heavy rain.

What's in the Box

Please verify that all components are present before beginning assembly:

- Tent Cover (Fabric)
- Poles (for frame assembly)
- Padded Mat

Setup Instructions

The Avrsol Kids Play Tent is designed for simple and quick assembly. Follow these steps to set up your tent:

1. **Unpack Components:** Carefully remove all items from the packaging. Lay out the tent fabric, poles, and padded mat on a clean, flat surface.
2. **Assemble Poles:** Connect the pole sections together to form the complete frame structure. Ensure each section clicks securely into place. Refer to the diagram for the correct pole configuration.
3. **Insert Poles into Fabric Sleeves:** Carefully slide the assembled poles into the designated fabric sleeves on the tent cover.
4. **Secure the Frame:** Once all poles are in place, connect the ends of the poles to form the tent's stable structure. This typically involves inserting pole ends into connectors or pockets at the base of the tent.
5. **Position the Padded Mat:** Place the padded mat inside the assembled tent, ensuring it lies flat and covers the floor area.
6. **Adjust and Secure:** Gently adjust the tent fabric to ensure it is taut and evenly distributed over the frame. Tie back any curtains or flaps as desired.



Image: Children enjoying the fully assembled Avrsol Kids Play Tent, demonstrating its spacious interior.

Operating Instructions (Usage)

The Avrsol Kids Play Tent provides a versatile space for various activities:

- **Indoor Play:** Set up the tent in a playroom, bedroom, or living area for imaginative play, reading, or quiet time. Its large size accommodates several children or additional accessories like pillows and toys.
- **Outdoor Adventures:** The tent can be easily moved to a backyard for outdoor play on sunny days. Ensure it is placed on a flat, stable surface and protected from harsh weather conditions.
- **Cozy Retreat:** The included padded mat enhances comfort, making it an ideal spot for children to relax, read, or take a nap. The mesh curtains can be drawn closed to create a private, secure nook.



Image: The Avrsol Kids Play Tent with its comfortable padded mat, illustrating its readiness for play or relaxation.

Maintenance and Care

To ensure the longevity and cleanliness of your Avrsol Kids Play Tent, follow these care instructions:

- **Cleaning the Fabric:** The tent fabric is machine washable. Use a gentle cycle with cold water and mild detergent. Do not bleach. Air dry or tumble dry on low heat.
- **Cleaning the Padded Mat:** The padded mat is also machine washable. Follow the same instructions as for the tent fabric.
- **Cleaning the Poles:** Wipe the poles with a damp cloth as needed. Do not use abrasive cleaners.
- **Storage:** When not in use, disassemble the tent and store all components in a dry, cool place away from direct sunlight. This helps preserve the fabric and frame integrity.

Troubleshooting

If you encounter any issues with your play tent, refer to the following common solutions:

Problem	Possible Cause	Solution

Problem	Possible Cause	Solution
Tent is wobbly or unstable.	Poles not fully connected or inserted.	Ensure all pole sections are securely clicked together and fully inserted into their connectors or fabric pockets.
Fabric does not fit correctly.	Poles are incorrectly assembled or fabric is misaligned.	Review assembly instructions to confirm pole configuration. Adjust fabric evenly over the frame.
Difficulty disassembling.	Poles are tightly fitted.	Apply gentle, even pressure when disconnecting poles. Do not force.

Specifications

- **Brand:** Avrsol
- **Model Number:** DRFG-1
- **UPC:** 786750427624
- **Item Dimensions (D x W x H):** 57" x 35.5" x 53" (144.78 cm x 90.17 cm x 134.62 cm)
- **Item Weight:** 9.14 Pounds (4.15 kg)
- **Material Type:** Polycotton
- **Included Components:** Tent Cover, Poles, Padded Mat
- **Assembly Required:** Yes
- **Manufacturer Minimum Age:** 36 Months (3 years)

Warranty and Support

For any questions, concerns, or support regarding your Avrsol Kids Play Tent, please refer to your purchase documentation or contact the retailer. Specific warranty details may vary by region and retailer.
You can also visit the official Avrsol Store for more information:Avrsol Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FMDTSFB1

More documents and user manuals: **https://manuals.plus/**