

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

> [Coeshome](#) /

> Coeshome Dresser with Hanging Rod, LED, and Power Outlet (Model Coeshome-44-356) User Manual

Coeshome Coeshome-44-356

Coeshome Dresser with Hanging Rod, LED, and Power Outlet

Model: Coeshome-44-356

Brand: Coeshome

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your Coeshome multi-functional dresser. This unit combines a hanging rod, six fabric drawers, integrated LED lighting, and a convenient power outlet, offering a versatile storage solution for your bedroom or living space. Please read this manual thoroughly before assembly and use to ensure proper function and safety.



Image: The Coeshome 3-in-1 multifunctional dresser, showcasing its hanging rod, drawers, and top surface. This unit serves as a dresser, clothes rack, and shoe rack.

SAFETY INFORMATION

- Always follow assembly instructions carefully.
- Do not overload drawers or hanging rod.
- Ensure the anti-tip kit is securely installed to prevent accidental tipping, especially in households with children or pets.

- Keep electrical components (LED strip, power outlet) away from water or excessive moisture.
- Use only the provided power adapter for the LED lighting and power outlet.
- Periodically check all connections and fasteners to ensure they remain tight.

PACKAGE CONTENTS

Please verify that all components are present before beginning assembly. If any parts are missing or damaged, contact customer support.

- Metal frame components
- Fabric drawers (6 units)
- Top wooden board
- Hanging rod
- LED light strip with remote
- Power outlet module with cable
- Adjustable feet
- Anti-tip kit
- Assembly hardware (screws, wrench, etc.)
- Instruction manual

SETUP AND ASSEMBLY

Follow the step-by-step diagrams provided in the included printed manual for detailed assembly instructions. Ensure all connections are secure before use.

Reversible Design

The dresser features a reversible design, allowing you to position the hanging rod and drawer sections on either the left or right side to best suit your room layout. Decide on your preferred orientation before starting assembly.



Image: Two configurations of the Coleshome dresser, demonstrating its reversible design where the hanging section can be on either side of the drawer unit.

Anti-Tip Kit Installation

For safety, it is crucial to install the anti-tip kit. Secure the dresser to a wall using the provided hardware to

prevent accidental tipping. Refer to the assembly diagrams for specific placement.

Adjustable Feet

The dresser is equipped with adjustable feet to ensure stability on uneven surfaces. After assembly, gently rock the unit to identify any wobbling. Adjust the feet by turning them clockwise or counter-clockwise until the dresser is stable.



Image: Close-up views of the adjustable feet for leveling and the anti-tip kit for securing the dresser to a wall.

OPERATING INSTRUCTIONS

LED Lighting System

The integrated LED strip offers customizable lighting options:

- **10 Static Colors:** Select from a range of fixed colors to match your mood or decor.
- **10 Dynamic Modes:** Choose from various pre-programmed lighting effects.
- **7 Brightness Levels:** Adjust the intensity of the light.
- **Memory Function:** The system remembers your last setting when powered off and on.

Use the provided remote control to operate the LED lighting. Ensure the LED strip is properly connected to the power source.



Image: The dresser with its LED strip illuminated, showing various color options and the remote control for operation.

Integrated Power Outlet

The dresser includes a power outlet module for convenient charging and powering of devices:

- **3 AC Outlets:** 220-250V/15A
- **2 USB Ports:** 5V/2A

Connect the dresser's power cable to a wall outlet. You can then charge up to 5 devices simultaneously, such as phones, headphones, laptops, or desk lamps.



Image: A close-up of the integrated power outlet module on the dresser's top surface, showing 3 AC outlets and 2 USB ports, with devices charging.

Drawer and Hanging Rod Usage

- **Fabric Drawers:** The six fabric drawers are ideal for storing folded clothes, toys, jewelry, and other personal items. Ensure items are evenly distributed to prevent damage to the drawers.
- **Hanging Rod:** Use the hanging rod for suits, pants, shirts, and other garments that benefit from being hung to prevent wrinkles.
- **Side Hooks:** Utilize the side hooks for hanging hats, bags, or other accessories.

MAINTENANCE

- **Cleaning:** Wipe the metal frame and wooden top with a soft, damp cloth. For fabric drawers, spot clean with a mild detergent and allow to air dry. Do not use harsh chemicals or abrasive cleaners.
- **Dusting:** Regularly dust all surfaces to prevent buildup.
- **Inspection:** Periodically check all screws and connections to ensure they are tight. Re-tighten if necessary.
- **Drawer Care:** Avoid pulling drawers out with excessive force or overloading them, as this can damage the fabric or frame.

TROUBLESHOOTING

Dresser is Wobbly

- Check that all assembly screws are securely tightened.
- Adjust the leveling feet at the bottom of the unit to compensate for uneven flooring.

LED Lights Not Working

- Ensure the LED strip is correctly plugged into its power adapter and the adapter is plugged into a working wall outlet.
- Check the remote control battery.
- Verify that the LED strip is properly connected to the control box.

Power Outlets/USB Ports Not Working

- Ensure the dresser's main power cable is securely plugged into a functional wall outlet.
- Check if the wall outlet itself is working by plugging in another device.
- Avoid overloading the outlets; the maximum capacity is 15A.

SPECIFICATIONS

Feature	Detail
Brand	Coleshome
Model Number	Coleshome-44-356
Color	Black
Material	Metal frame, Fabric drawers
Product Dimensions	110.5 cm (W) x 30 cm (D) x 106 cm (H)
Product Weight	12 kg
Number of Drawers	6
Power Outlet	3 AC (220-250V/15A), 2 USB (5V/2A)
LED Lighting	10 static colors, 10 dynamic modes, 7 brightness levels, memory function
Assembly Required	Yes





Tomas De Corriente Para Carga

- ⏏
3 Tomas CA
 220-250V/15A
- 🔌
2 Puertos USB
 5V/2A
- 🔌
Cable De Corriente
 150cm

Image: Detailed diagram showing the dimensions of the Coleshome dresser, including overall height, width, depth, and individual drawer sizes.

PRODUCT VIDEOS

OYRREU Dresser with Hanging Rack and 4 Drawers

Video: This video demonstrates the organization capabilities of a similar dresser with a hanging rack and drawers, showing before and after scenarios for a tidy space. It highlights storage for clothes, bags, and shoes.

Uptyia Wardrobe Rack Assembly and Features

Video: This video illustrates the assembly process and various configurations of a metal wardrobe rack with fabric drawers, similar in concept to the Coleshome dresser. It shows how different components fit together and how the unit can be customized.

WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided on the product packaging or visit the official Coleshome website. Keep your purchase receipt as proof of purchase for any warranty claims.