



Manuals.plus /

- › **Aeitto** /
- › Aeitto Cold Press Juicer Machine JS8303 User Manual

Aeitto JS8303

Aeitto Cold Press Juicer Machine User Manual

Model: JS8303

1. INTRODUCTION

This manual provides essential information for the safe and efficient operation, maintenance, and care of your Aeitto Cold Press Juicer Machine. Please read this manual thoroughly before first use and retain it for future reference.



Image: The Aitto Cold Press Juicer Machine, silver and black, with a clear juicing chamber and a measuring cup of green juice, surrounded by fresh fruits and vegetables.

2. IMPORTANT SAFETY INSTRUCTIONS

WARNING: To reduce the risk of fire, electric shock, or injury, always follow basic safety precautions.

- Read all instructions before using the appliance.
- Do not immerse the motor base in water or other liquids.
- Ensure the appliance is properly assembled before operation.
- Keep hands and utensils out of the feed chute during operation to prevent injury.
- Always use the food pusher provided. Never use fingers or other utensils.
- Unplug from outlet when not in use, before putting on or taking off parts, and before cleaning.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

3. PRODUCT COMPONENTS

Familiarize yourself with the parts of your Aeitto Cold Press Juicer Machine:

1. Motor Base with Control Panel
2. Juicing Chamber
3. Auger (Masticating Screw)
4. Filter Screen
5. Feed Chute with Lid
6. Food Pusher
7. Juice Cup
8. Pulp Container
9. Cleaning Brush

Your browser does not support the video tag.

Video: An overview of the Aeitto Cold Press Juicer Machine's components and basic assembly steps.

4. SETUP AND ASSEMBLY

Before first use, wash all detachable parts (except the motor base) in warm, soapy water. Rinse thoroughly and dry.

1. Place the motor base on a stable, flat surface.
2. Insert the juicing chamber onto the motor base, aligning the marks and twisting until it locks into place.
3. Place the filter screen inside the juicing chamber.
4. Insert the auger into the center of the filter screen.
5. Attach the feed chute lid, aligning the marks and twisting until it locks. Ensure the lid is securely fastened for operation.
6. Position the juice cup under the juice outlet and the pulp container under the pulp outlet.

Your browser does not support the video tag.

Video: A user demonstrates the simple assembly and disassembly of the juicer, highlighting its ease of use.

5. OPERATING INSTRUCTIONS

5.1 Preparing Ingredients

- Wash all fruits and vegetables thoroughly.
- For most items, the 3.6-inch wide chute allows for larger pieces, reducing pre-cutting time.
- Remove hard pits from fruits (e.g., peaches, cherries) and tough seeds (e.g., large apple seeds).
- Peel citrus fruits before juicing.

3.6 Inch Extra-Wide Chute

Reduce Preparation & Save Your Time

Ours

Others



AEITTO 3.6 inch

- ✓ Large Fruits and Vegetables
- ✓ Less Cut Reduce Pre-work
- ✓ Save 1X Time

OTHERS 1.8 inch

- ✗ Need Cut Small Pieces
- ✗ More Preparation
- ✗ Take More Time

Image: The juicer's 3.6-inch extra-wide chute, designed to accommodate large pieces of fruit and vegetables, minimizing preparation time.

5.2 Juicing Process

1. Plug the juicer into a power outlet.
2. Select the appropriate masticating mode:
 - **'Hard' Mode:** For firm ingredients like celery, carrots, apples, ginger, pineapple, and beets.
 - **'Soft' Mode:** For softer ingredients such as oranges, blueberries, watermelon, tomatoes, kiwi, and strawberries.
3. Turn the juicer ON.
4. Gradually feed prepared ingredients into the feed chute. Use the food pusher gently if needed.
5. Allow the juicer to process the ingredients completely. Juice will flow into the juice cup, and pulp into the pulp container.
6. After juicing, turn the appliance OFF and unplug it.

2 Masticating Modes

Hard Mode



Soft Mode



Image: The juicer's control panel illustrating the 'Hard' mode for ingredients like celery and carrots, and 'Soft' mode for fruits such as oranges and blueberries.

5.3 Ice Cream Function

This juicer can also be used to make frozen desserts. For best results, use frozen fruits directly from the freezer. Ensure fruits are cut into appropriate sizes if necessary.

1. Ensure the correct filter/attachment for frozen desserts is installed (refer to specific instructions if an ice cream attachment is included).
2. Turn the juicer ON.
3. Feed frozen fruit pieces into the chute. The juicer will process them into a soft-serve consistency.
4. Collect the frozen dessert in a bowl.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures optimal performance and longevity of your juicer.

1. **Disassembly:** Turn off and unplug the juicer. Press the release button (if available) and twist the feed chute lid to unlock. Remove the auger, filter screen, and juicing chamber.
2. **Rinsing:** Rinse all detachable parts under running water immediately after use to prevent pulp from drying.
3. **Cleaning Brush:** Use the provided cleaning brush to remove stubborn pulp from the filter screen and other components.
4. **Washing:** All detachable parts are dishwasher safe. For hand washing, use warm, soapy water.
5. **Motor Base:** Wipe the motor base with a damp cloth. Never immerse it in water.
6. **Drying & Storage:** Ensure all parts are completely dry before reassembling or storing the juicer.

Easy To Clean & Disassemble



All parts, except the main motor, can be cleaned with the included brush or in the dishwasher

Image: A visual guide showing how to clean the juicer's filter with a brush and that its detachable parts are dishwasher safe.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Juicer does not turn on.	Not plugged in; parts not assembled correctly.	Ensure power cord is securely plugged in. Reassemble all parts, ensuring they are locked into place.
Excessive vibration or noise.	Improper assembly; hard ingredients.	Check assembly. Ensure ingredients are appropriate for the selected mode.
Low juice yield or wet pulp.	Incorrect mode for ingredients; feeding too quickly.	Select appropriate mode (Hard for firm, Soft for soft). Feed ingredients slowly.
Juicer stops during operation.	Overload protection activated.	Turn off and unplug. Remove ingredients. Let cool for 15-30 minutes before restarting.

8. SPECIFICATIONS

- **Brand:** Aeitto
- **Model:** JS8303 (ASIN: B0FMDXJBJF)
- **Color:** Silver
- **Product Dimensions:** 7.87 x 17.71 x 13.81 inches (7.87"D x 17.71"W x 13.81"H)
- **Item Weight:** 11.14 pounds (5.06 Kilograms)
- **Power:** 200 Watts (inferred from product video)
- **Chute Size:** 3.6 inches
- **Modes:** Soft, Hard

9. WARRANTY AND SUPPORT

Your Aeitto Cold Press Juicer Machine comes with a manufacturer's warranty. Please refer to the warranty card included in your packaging for detailed terms and conditions. For technical support, troubleshooting assistance, or to inquire about replacement parts, please contact Aeitto customer service through the contact information provided in your product documentation or on the official Aeitto website.