

PRETZI PB70-8COL-BLK

PRETZI 80" Modern Fireplace TV Stand with 36" Electric Fireplace User Manual

Model: PB70-8COL-BLK

1. IMPORTANT SAFETY INFORMATION

Please read all instructions carefully before assembly and use. Retain this manual for future reference.

- Ensure both packages (fireplace insert and TV stand) arrive before starting assembly. They may arrive on different days.
- Always use two people for assembly to prevent injury and ensure proper construction.
- Keep flammable materials at least 3 feet (0.9 meters) away from the front of the electric fireplace and away from the sides and rear to prevent fire hazards.
- Do not exceed the weight limit of the TV stand. The tabletop has a load capacity of 250 lbs.
- Do not operate the fireplace with a damaged cord or plug, or if the heater malfunctions.
- Do not insert or allow foreign objects to enter any ventilation or exhaust opening as this may cause an electric shock or fire, or damage the heater.

2. SETUP AND ASSEMBLY

The PRETZI 80" Modern Fireplace TV Stand is designed for straightforward assembly with detailed instructions, pre-drilled holes, and labeled parts. Two-person assembly is recommended.

2.1 Unpacking and Inspection

- Carefully unpack all components and verify against the parts list provided in the separate assembly guide.
- Inspect all parts for any damage. Contact customer support immediately if any parts are missing or damaged.
- Remove any protective plastic films from mirrored doors or high-gloss surfaces before final assembly.


2.2 Assembly Tips

- **Under Panel Lighting:** When connecting the under panel lighting, ensure the USB lighting connections are installed inward so they can reach the fireplace for connection. It is advisable to test the fireplace and lighting strips before fully securing them.
- **Fireplace Crystals:** Before inserting the electric fireplace into the TV stand, locate the decorative crystals (often in a plastic bag) and place them inside the fireplace glass frame. There is typically one screw that allows the glass frame to be removed for this purpose. Distribute the crystals evenly for the best visual effect. This step is crucial as the fireplace fit is snug once installed.

2.3 Placement

Position the TV stand on a flat, stable surface. This unit supports TVs up to 90 inches, providing a balanced and clean entertainment setup.

PRODUCT SIZE



**Two packages delivery,
may Not arrived on the same day.**



Figure 1: Product dimensions and TV size compatibility. The 80-inch stand is suitable for TVs up to 90 inches.



Figure 2: Illustration of the eight stainless steel support brackets, designed for enhanced stability and durability.

2.4 Assembly Video

Your browser does not support the video tag.

Video 1: Official product video demonstrating the features and functionality of the PRETZI Modern Fireplace TV Stand, including LED lighting and electric fireplace operation. This video can assist with visual guidance during assembly and feature understanding.

3. OPERATING INSTRUCTIONS

The TV stand features an integrated electric fireplace and LED lighting system, both controllable for a personalized experience.

3.1 Electric Fireplace Operation

- The 36-inch electric fireplace offers 750W and 1500W heating modes for warmth and energy efficiency.
- It features a 1-8 hour timer for automatic shut-off.

- Choose from 12 realistic flame effects and 5 levels of flame brightness to create a cozy ambiance.
- The flame effect can be enjoyed with or without heat, making it suitable for all seasons.
- Control the fireplace settings using the included remote control or the control panel on the unit.

3.2 LED Light Operation

- The integrated LED lighting system offers 20 color combinations.
- Use the dedicated remote control to change colors and adjust lighting modes.



Figure 3: The TV stand featuring its 20 LED color options, controllable via remote for customized ambiance.



8-Hour Timer




65°F / 95°F
36"



750W/1500W
Heater



Overheating
Protection
4.45"



13.31"



13.78"

12 Flame Colors + 5 Level Flame Brightness



Dim **L1** **L2** **L3** **L4** **L5** **Bright**




Figure 4: Detailed view of the electric fireplace's control panel and remote, highlighting features like the 8-hour timer, 750W/1500W heater, overheating protection, and options for 12 flame colors with 5 brightness levels.

4. MAINTENANCE

Proper care and maintenance will ensure the longevity and appearance of your TV stand.

4.1 Cleaning

- For the high-gloss cabinet and wood grain particle board surfaces, use a soft, damp cloth for cleaning. Avoid abrasive cleaners or harsh chemicals that could damage the finish.
- For the electric fireplace glass, use a glass cleaner and a soft cloth. Ensure the fireplace is turned off and cool before cleaning.
- Regularly dust the unit to prevent buildup.

4.2 General Care

- Avoid placing hot items directly on the surface without protection.
- Do not expose the unit to excessive moisture or direct sunlight for prolonged periods.
- Periodically check all fasteners and tighten if necessary to maintain stability.

5. TROUBLESHOOTING

If you encounter any issues, refer to the following common troubleshooting tips. For persistent problems, contact customer support.

5.1 Assembly Difficulties

- If instructions seem unclear, carefully re-read each step and refer to the provided diagrams. Ensure all parts are correctly oriented.
- Confirm all pre-drilled holes align before applying force. Do not overtighten screws.

5.2 Electric Fireplace / LED Lights Not Working

- Ensure the unit is properly plugged into a functional power outlet.
- Check if the power switch on the fireplace unit is in the 'ON' position.
- Verify that the remote control batteries are correctly installed and not depleted. If the remote is unresponsive, try replacing the batteries or contacting customer support for a replacement.
- For LED lights, ensure all connections, especially the USB lighting connections, are securely and correctly installed (inward-facing).

5.3 Appearance Issues

- If doors appear scratched, check if a protective plastic film is still present and gently peel it off.



Figure 5: The TV stand features ample storage cabinets with adjustable shelves and integrated cable holes for neat organization of media devices and accessories.

6. SPECIFICATIONS

Feature	Specification
Model Number	PB70-8COL-BLK
Dimensions (Overall)	80 x 14 x 24 inches (L x W x H)
Electric Fireplace Size	36 inches
Material	MDF, Fine Wood Grain Particle Board, Alloy Steel
Item Weight	76.7 pounds

Tabletop Load Capacity	250 lbs
TV Size Compatibility	Up to 90 inches
Fireplace Heating Modes	750W / 1500W
Fireplace Timer	1-8 hours
Flame Effects	12 realistic flame effects, 5 brightness levels
LED Lighting	20 color combinations
Special Features	Adjustable Flame, Adjustable Thermostat, Dimmer, Multicolor Flame, Cable Management, Mirrored Doors



Figure 6: The PRETZI 80-inch TV stand with electric fireplace, showcasing its modern design and ambient lighting in a living room setting.

7. WARRANTY AND SUPPORT

PRETZI is committed to providing quality products and customer satisfaction.

- For any questions, concerns, or assistance with your product, please contact PRETZI customer support.
- 24-hour customer support is available to help with assembly, troubleshooting, or any other product-related inquiries.
- Please refer to your purchase documentation for specific warranty details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question