

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [roomfitters](#) /

› [roomfitters Metal Twin Size House Platform Bed with Triangle Structure Frame Instruction Manual](#)

roomfitters RF-N709WF307193AAH

roomfitters Metal Twin Size House Platform Bed Instruction Manual

Model: RF-N709WF307193AAH

INTRODUCTION

Thank you for choosing the roomfitters Metal Twin Size House Platform Bed. This manual provides essential information for the safe assembly, operation, and maintenance of your new bed frame. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Important Safety Information

- Always follow assembly instructions precisely. Incorrect assembly can lead to instability and injury.
- Ensure all bolts and screws are securely tightened before use. Periodically check and re-tighten as necessary.
- Do not exceed the recommended weight limit for a twin-size bed.
- Keep small parts away from children during assembly to prevent choking hazards.
- Place the bed on a flat, level surface.
- This product is designed for indoor use only.



Image: The fully assembled roomfitters Metal Twin Size House Platform Bed, showcasing its house-shaped frame and low-profile design. This image provides a visual reference of the complete product.

PACKAGE CONTENTS

Before assembly, please verify that all components listed below are present and undamaged. If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.

Part	Description	Quantity
A	Headboard/Footboard Frame Sections	2
B	Side Rails	2
C	Support Slats	Approx. 12-14
D	Top Horizontal Bar	1

Part	Description	Quantity
E	Assembly Hardware (Bolts, Washers, Allen Wrench)	1 Set

Note: The exact number of slats may vary slightly.

SETUP: ASSEMBLY INSTRUCTIONS

Follow these steps carefully to assemble your roomfitters Metal Twin Size House Platform Bed. It is recommended to have two people for assembly.

Tools Required:

- Allen Wrench (included)

1. Unpack and Identify Parts: Carefully remove all components from the packaging. Lay them out on a soft, clean surface to prevent scratches. Refer to the "Package Contents" section to identify each part.

2. Assemble the Base Frame:

Connect the two Side Rails (B) to one Headboard/Footboard Frame Section (A) using the provided bolts and washers. Do not fully tighten the bolts yet. Repeat for the second Headboard/Footboard Frame Section (A).



Image: A view of the bed frame's base structure, illustrating how the main frame components connect. This helps visualize step 2 of assembly.

3. Attach the Top Horizontal Bar:

Secure the Top Horizontal Bar (D) between the two Headboard/Footboard Frame Sections (A) at the top of the house structure. Use the appropriate bolts and washers. Ensure it is centered and level.

4. Install Support Slats:

Place the Support Slats (C) across the Side Rails (B). Ensure they are evenly spaced and securely seated in their designated slots or attached with provided fasteners. The slats form the mattress support.



Image: A detailed view of the bed frame's corner and the metal slats, demonstrating how the slats are integrated into the frame for mattress support.

5. Final Tightening:

Once all parts are assembled, go back and fully tighten all bolts using the Allen wrench. Do not overtighten, but ensure all connections are firm and secure. The frame should feel stable.

6. Inspect:

Perform a final inspection to ensure all parts are correctly installed and tightened. The bed frame is now ready for use.

OPERATING INSTRUCTIONS

General Use

- Place a standard twin-size mattress directly onto the support slats. A box spring is not required.
- The unique triangular frame design includes a horizontal board at the top, which can be used for hanging lightweight decorative items or towels. Do not hang heavy objects that could compromise stability.
- The low-profile design and X-shaped safety railings are intended to provide a secure sleeping environment, especially for younger users.

MAINTENANCE

Cleaning and Care

- **Regular Cleaning:** Wipe the metal frame with a dry cloth to remove dust.
- **Spot Cleaning:** For spills or marks, wipe with a damp cloth. Avoid abrasive cleaners or harsh chemicals, as these can damage the finish.
- **Hardware Check:** Periodically (e.g., every 3-6 months) check all bolts and screws to ensure they remain tight. Re-tighten if necessary to maintain structural integrity.
- **Avoid Moisture:** Keep the bed frame in a dry environment to prevent rust or damage to the metal.

TROUBLESHOOTING

Refer to the table below for common issues and their solutions.

Problem	Possible Cause	Solution
Bed frame is wobbly or unstable.	Loose bolts or uneven surface.	Ensure all bolts are securely tightened. Move the bed to a flat, level surface.
Squeaking noises.	Loose connections or friction between metal parts.	Re-tighten all bolts. If squeaking persists, apply a small amount of lubricant (e.g., silicone spray) to connection points.
Missing parts during assembly.	Packaging error or lost during unpacking.	Double-check all packaging materials. Contact roomfitters customer support for replacement parts.

SPECIFICATIONS

Feature	Detail
Model Number	RF-N709WF307193AAH
Size	Twin
Product Dimensions (L x W x H)	78" x 41.3" x 63"
Item Weight	30.5 lbs
Material	Metal
Color	Pink
Assembly Required	Yes
Special Feature	No Box Spring Needed, Triangle Structure Frame
UPC	781962561500

SIZE:INCH




Image: A technical diagram illustrating the precise dimensions (length, width, height) of the bed frame, including the height of the house structure and the sleeping platform.

WARRANTY AND SUPPORT

Warranty Information

roomfitters products are manufactured with quality and care. For specific warranty details regarding your Metal Twin Size House Platform Bed, please refer to the warranty card included with your purchase or visit the official roomfitters website. Typically, warranties cover manufacturing defects under normal use.

Customer Support


If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact roomfitters customer support. You can often find contact information on the packaging, the brand's official website, or through your purchase platform.

For more information about roomfitters products, visit [theroomfitters Store](#).

© 2025 roomfitters. All rights reserved.

Related Documents - RF-N709WF307193AAH

	<p>VECELO Bed Frame Assembly Instructions - Model CY-No.1</p> <p>Step-by-step assembly guide for the VECELO Bed Frame (Model CY-No.1). Includes parts list, tools, and troubleshooting tips for easy setup.</p>
 <small>Installation & Assembly Bed Frame</small>	<p>Installation and Assembly Guide for Bed Frame</p> <p>Comprehensive guide for installing and assembling your Wayfair bed frame, including parts list, tools, and step-by-step instructions for TWIN, FULL, and QUEEN sizes.</p>
 <small>Hitachi Virtual Storage Platform 5000 Series Hitachi Virtual Storage Platform E Series Hitachi Virtual Storage Platform G130, G/ F350, G/F370, G/F700, G/F900 REST API Reference Guide</small>	<p>Hitachi Virtual Storage Platform REST API Reference Guide</p> <p>A comprehensive guide to using the REST API for Hitachi Virtual Storage Platform 5000 Series, E Series, G130, G/F350, G/F370, G/F700, G/F900 storage systems with SVOS RF 9.8.1 and 9.6.</p>

 <p>Hitachi Virtual Storage Platform 5000 Series Hitachi Virtual Storage Platform E Series Hitachi Virtual Storage Platform G130, G/F350, G/F370, G/F700, G/F900 v2024.04.0</p> <p>REST API Reference Guide This document is a REST API reference guide and contains the API reference of the Hitachi Virtual Storage Platform 5000 Series, E Series, G130, G/F350, G/F370, G/F700, G/F900. It provides detailed information on the API endpoints, request and response structures, and usage examples for each API endpoint. The API endpoints are organized by category, such as System Configuration, User Management, Volume Allocation, and more. The API reference is intended for system administrators and developers who need to interact with the Hitachi Virtual Storage Platform 5000 Series, E Series, G130, G/F350, G/F370, G/F700, G/F900 using the REST API.</p> <p>00-00000000000000000000000000000000</p>	<p><u>Hitachi Virtual Storage Platform REST API Reference Guide</u></p> <p>A comprehensive guide to using the REST API for Hitachi Virtual Storage Platform 5000 Series, E Series, G130, G/F350, G/F370, G/F700, G/F900, covering system configuration, user management, volume allocation, and more.</p>
 <p>DEWERT OKIN RF-ENHANCE Quick Guide: Pairing Instructions</p>	<p>This quick guide provides step-by-step instructions for pairing the DEWERT OKIN RF-ENHANCE wireless remote control with your motorized comfort bed system. Learn how to activate pairing mode and connect your device.</p>
 <p>QuietCool OWNER'S GUIDE STEALTH PRO X WHOLE HOUSE FAN RF Models</p> <p>DO NOT THROW AWAY! REFLECTOR FOR FAN IS LOCATED ON THE BACK COVER OF THE OWNER'S GUIDE. LEAVE WITH FAN.</p>	<p><u>QuietCool Stealth Pro X Whole House Fan RF Models Owner's Guide</u></p> <p>This owner's guide provides comprehensive instructions for the installation, wiring, operation, and maintenance of the QuietCool Stealth Pro X Whole House Fan RF Models. Learn about the features, benefits, and how to optimize your fan for energy efficiency and indoor air quality.</p>