

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [WMF](#) /

› [WMF Element One Water Carbonator Instruction Manual Model 608126040](#)

## WMF 608126040

# WMF Element One Water Carbonator Instruction Manual

Model: 608126040

## 1. INTRODUCTION

---

The WMF Element One Water Carbonator is designed to produce sparkling water with customizable carbonation levels. This device features a fully automatic operation, a unique click system for the water bottle, and compatibility with standard screw-in CO2 cylinders. Its compact design and Cromargan stainless steel housing provide both functionality and a modern aesthetic.

## 2. IMPORTANT SAFETY INSTRUCTIONS

---

Please read and understand all safety instructions before operating the WMF Element One Water Carbonator. Failure to follow these instructions may result in injury or damage to the appliance.

- Always keep the appliance out of reach of children.
- Use only WMF Element One water bottles. Do not use bottles that have passed their expiration date, as this can compromise safety and performance.
- Only carbonate plain water. Carbonating other liquids can cause excessive pressure buildup and damage the appliance.
- Do not immerse the main carbonator unit in water or any other liquid. Clean with a damp cloth only.
- Ensure the CO2 cylinder is correctly and securely installed before use.
- Do not clean the WMF Element One water bottle in a dishwasher. Hand wash only.
- Do not operate the appliance if the power cord or plug is damaged.
- This appliance is for household use only.

## 3. PACKAGE CONTENTS

---

Verify that all components are present in the package:

- 1 x WMF Element One Water Carbonator Unit
- 1 x WMF Element One Water Bottle (0.85L capacity)
- 1 x AC Adapter

**Note:** A CO2 cylinder is not included and must be purchased separately. Ensure compatibility with standard screw-in CO2 cylinders.

## 4. PRODUCT OVERVIEW

---

Familiarize yourself with the main components of your WMF Element One Water Carbonator.





**Figure 1:** Front view of the WMF Element One Water Carbonator. This image displays the main unit with a water bottle inserted, highlighting its sleek design and the WMF logo.



**Figure 2:** Close-up view of the control dial located on the top of the carbonator. The dial allows selection of three carbonation levels, indicated by subtle markings.



**Figure 3:** Detailed view of the bottle insertion mechanism. This area shows the carbonation nozzle and the unique click system for securing the water bottle.

## 5. SETUP

---

### 5.1 Unpacking and Placement

- Remove all packaging materials from the carbonator.
- Place the appliance on a flat, stable, and dry surface.
- Ensure adequate space around the unit for operation and ventilation.





**Figure 4:** The WMF Element One Water Carbonator shown with its approximate dimensions (height 44.1 cm, width 11.74 cm, depth 23.99 cm). This helps in planning placement on a countertop.

## 5.2 Installing the CO2 Cylinder

1. Locate the CO2 cylinder compartment at the top of the carbonator.
2. To open the compartment, press the button located at the back of the top section and gently turn the top part of the device counter-clockwise.
3. Carefully screw the CO2 cylinder into the designated port until it is firmly secured. Do not overtighten.
4. Replace the top part of the device by aligning it and turning clockwise until it clicks into place.

## 5.3 Connecting Power

- Connect the AC adapter to the power input port on the back of the carbonator.

- Plug the AC adapter into a suitable wall outlet.

## 6. OPERATING INSTRUCTIONS

---

### 6.1 Preparing the Water Bottle

1. Fill the WMF Element One water bottle with cold tap water up to the 'MAX' fill line. Do not overfill.
2. Ensure the water bottle is clean before use.

### 6.2 Attaching the Water Bottle

1. Hold the filled water bottle upright.
2. Insert the bottle into the carbonator's opening, aligning it with the unique click system.
3. Gently push the bottle upwards and twist it clockwise until it securely clicks into place. The bottle should be firmly held by the carbonator.

### 6.3 Selecting Carbonation Level and Carbonating

1. Rotate the control dial on the top of the carbonator to select your desired carbonation level: fine, medium, or sparkling.
2. Press the carbonation button (usually located on the front or top of the unit). The device will automatically carbonate the water.
3. Wait for the carbonation cycle to complete. The device may emit a sound indicating completion.





**Figure 5:** A close-up of the WMF Element One water bottle containing freshly carbonated water, showing the visible bubbles after the process.

## 6.4 Removing the Water Bottle

1. Once carbonation is complete, gently twist the water bottle counter-clockwise to release it from the click system.
2. Carefully pull the bottle downwards to remove it from the carbonator.
3. Serve immediately or store the bottle with its lid in the refrigerator.

## 7. MAINTENANCE AND CLEANING

---

### 7.1 Cleaning the Carbonator Unit

- Always unplug the appliance before cleaning.
- Wipe the exterior of the carbonator unit with a soft, damp cloth.
- Do not use abrasive cleaners, solvents, or harsh chemicals.
- Ensure no water enters the electrical components.

## 7.2 Cleaning the Water Bottle

- Hand wash the WMF Element One water bottle with mild dish soap and warm water.
- Rinse thoroughly.
- **Do not clean the water bottle in a dishwasher.** High temperatures can damage the bottle material.

## 7.3 Water Bottle Replacement

WMF Element One water bottles have an expiration date (MHD) printed on them. Due to repeated pressure stress during carbonation, bottles must be replaced regularly to ensure safe and reliable function. Please check the MHD of your bottle and replace it as recommended.

## 8. TROUBLESHOOTING

---

If you encounter issues with your WMF Element One Water Carbonator, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
No bubbles or insufficient carbonation	CO2 cylinder is empty or incorrectly installed. Water bottle not properly attached. Water level too low.	Replace CO2 cylinder. Ensure cylinder is screwed in tightly. Re-attach water bottle securely. Fill water to the 'MAX' line.
Water leaking during carbonation	Water bottle not properly attached. Seal around nozzle is damaged.	Ensure water bottle is securely clicked into place. Inspect the seal for damage; contact customer support if damaged.
Appliance not operating	AC adapter not properly connected or power outlet issue.	Check AC adapter connection to the unit and wall outlet. Test the outlet with another appliance.

## 9. SPECIFICATIONS

---

- **Model:** 608126040
- **Brand:** WMF
- **Material:** Cromargan rustproof stainless steel 18/10
- **Item Weight:** 2.9 Kilograms
- **Water Bottle Volume:** 850 Millilitres
- **Power Source:** AC adapter
- **Operation Mode:** Automatic
- **Approximate Dimensions (L x W x H):** 23.99 cm x 11.74 cm x 44.1 cm (based on package dimensions and product image)

## 10. WARRANTY AND SUPPORT

---

For detailed warranty information, product registration, or customer support, please refer to the documentation included with your purchase or visit the official WMF website. Keep your proof of purchase for warranty claims.

