

[Manuals.plus](#) /

› [PRETZI](#) /

› PRETZI 80" Modern Fireplace TV Stand with 36" Electric Fireplace Instruction Manual

PRETZI PB70-8COL-BLK

PRETZI 80" Modern Fireplace TV Stand with 36" Electric Fireplace Instruction Manual

Model: PB70-8COL-BLK

1. INTRODUCTION

Thank you for choosing the PRETZI 80" Modern Fireplace TV Stand. This product combines a spacious TV stand with an integrated 36-inch electric fireplace, offering both entertainment support and ambient heating. It features LED lighting, ample storage, and a durable construction designed for modern living spaces. This manual provides essential information for safe assembly, operation, and maintenance of your new TV stand.



Image 1.1: The PRETZI 80" Modern Fireplace TV Stand in a contemporary living room.

2. SAFETY INFORMATION

Please read and understand all safety instructions before assembly and use. Failure to follow these instructions may result in injury or product damage.

- Always assemble with two people to prevent tip-over.
- Keep the fireplace insert at least 3 feet away from any combustible materials.
- Do not place heavy objects on the fireplace insert.
- Always unplug the fireplace insert when not in use.
- Keep the fireplace insert and remote control out of reach of children and pets.
- Always follow the assembly instructions carefully to ensure safe usage and prevent injury.

3. PACKAGE CONTENTS

The product is delivered in two separate packages, which may arrive on different days. Please ensure you have received both packages before beginning assembly.

- Package 1: TV Stand components (panels, hardware, LED strip)
- Package 2: 36-inch Electric Fireplace insert and remote control

Verify all parts are present and undamaged by comparing them with the parts list provided in the separate assembly guide. If any parts are missing or damaged, contact customer support immediately.

PRODUCT SIZE




Image 3.1: Product dimensions and indication of two-package delivery.

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly is recommended for two people. Detailed instructions, pre-drilled holes, and labeled parts are included to facilitate the process. Please refer to the separate assembly guide for step-by-step visual instructions.

Key Assembly Considerations:

- **LED Lighting Connection:** When connecting the under-panel LED lighting (typically around Step 7), ensure the USB lighting connections are installed inward. This ensures the cables reach the fireplace insert for proper connection. It is advisable to test the fireplace and lighting strips before fully securing them.
- **Fireplace Crystal Placement:** Before fully inserting the electric fireplace into the TV stand (around Step 14), locate the decorative crystals in a plastic bag. Remove the single screw that secures the fireplace glass frame (this may require some effort) and place the crystals inside for visual effect. Distribute them evenly. This step is crucial to complete before the fireplace is fully seated, as the fit is snug.
- **Cable Management:** Utilize the integrated cable holes to organize wires for electronic devices, maintaining a clean and clutter-free appearance.



Image 4.1: Key features and structural elements of the TV stand.



Image 4.2: Example of cable management feature.

5. OPERATING INSTRUCTIONS

5.1 Electric Fireplace Operation

The 36-inch electric fireplace can be operated using the control panel on the unit or the included remote control. It offers both heating and aesthetic flame effects.

- **Heating Modes:** Select between 750W and 1500W heating modes for varying levels of warmth.
- **Timer Function:** Set the operational timer for 1 to 8 hours.
- **Flame Effects:** Choose from 12 realistic 3D flame effects to create a desired ambiance.
- **Flame Brightness:** Adjust the flame brightness across 5 levels (V1-V5).




Image 5.1: Electric fireplace features including flame colors, brightness, and remote control.

5.2 LED Light Operation

The integrated LED lights offer 20 color combinations to personalize your viewing and living space experience. Use the included remote control to cycle through colors and effects.



Image 5.2: The 20 color LED lights feature with remote control.

5.3 Video Demonstration

Watch this video for a visual guide on the operation of the fireplace and LED lighting features.

Your browser does not support the video tag.

Video 5.3: Demonstration of the 70" Modern Fireplace TV Stand with 36" Electric Fireplace, showcasing flame effects and LED lights.

6. MAINTENANCE

Regular maintenance helps ensure the longevity and optimal performance of your TV stand and electric fireplace.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the high-gloss finish or wood grain particle board.
- **Fireplace Care:** Ensure the fireplace vents are clear of obstructions to prevent overheating. Periodically clean the

glass front with a non-abrasive glass cleaner.

- **Hardware Check:** Periodically check all screws and connections to ensure they remain tight. Retighten if necessary.

7. TROUBLESHOOTING

If you encounter any issues with your PRETZI TV Stand or electric fireplace, refer to the following common troubleshooting tips:

- **Fireplace Not Turning On:** Ensure the unit is properly plugged into a working electrical outlet. Check if the power switch on the unit is in the 'ON' position. Verify the remote control batteries are functional.
- **No Heat Output:** Confirm the heating mode is activated. Ensure the thermostat setting is higher than the ambient room temperature. Check for any obstructions around the heater vents.
- **LED Lights Not Working:** Check all USB connections for the LED strips to ensure they are securely plugged in. Verify the remote control batteries.
- **Unstable Structure:** Recheck all assembly hardware to ensure all screws are tightened. Ensure the unit is placed on a flat, level surface.

For persistent issues or concerns not addressed here, please contact customer support.

8. SPECIFICATIONS

Feature	Detail
Material	Alloy Steel, Wood (MDF and fine wood grain particle board)
Product Dimensions (L x W x H)	80 x 14 x 24 inches (203.2 x 35.5 x 61 cm)
Item Weight	76.7 pounds
Electric Fireplace Size	36 inches (width)
Heating Modes	750W / 1500W
Timer	1-8 hour timer
Flame Effects	12 realistic 3D flame effects, 5 brightness levels
LED Lights	20 color combinations
TV Size Support	Up to 90 inches
Load Capacity of Tabletop	250 lbs
Model Number	PB70-8COL-BLK

8 STAINLESS STEEL BRACKETS

Durable stainless steel brackets provide strong support while creating open storage space.

Image 8.1: Visual summary of product specifications.

9. WARRANTY AND SUPPORT

PRETZI is committed to providing quality products and customer satisfaction. For any questions, concerns, or assistance with assembly, operation, or troubleshooting, please contact our customer support team. We offer 24-hour customer support to ensure a prompt resolution to your inquiries.

Please retain your purchase receipt for warranty purposes. Specific warranty details may be provided with your product packaging.

© 2025 PRETZI. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question