

[Manuals.plus](#) /

> [iPazzPort](#) /

> iPazzPort Mini Bluetooth Keyboard with Touchpad (Model 19SM01) User Manual

## iPazzPort 19SM01

# iPazzPort Mini Bluetooth Keyboard with Touchpad

Model: 19SM01

Brand: iPazzPort

## 1. INTRODUCTION

The iPazzPort Mini Bluetooth Keyboard with Touchpad (Model 19SM01) is a versatile, palm-sized wireless keyboard designed for convenient control of various devices. It features dual-mode connectivity, supporting both 2.4GHz wireless via a USB receiver and Bluetooth, offering broad compatibility with Smart TVs, laptops, PCs, gaming consoles, and mobile devices. Its integrated touchpad provides precise cursor control, making navigation effortless.



Image: The iPazzPort Mini Bluetooth Keyboard in use during a presentation, highlighting its compact and functional design.

## 2. WHAT'S IN THE BOX

---

- 1 x iPazzPort Mini Bluetooth Keyboard
- 1 x 2.4G USB Receiver (stored in the battery compartment)
- 1 x USB Extension Cable
- 1 x User Manual

*Note: 2 x AAA batteries are required for operation and are not included.*

## 3. SETUP INSTRUCTIONS

---

### 3.1. Installing Batteries and USB Receiver

1. Locate the battery compartment cover on the back of the keyboard.
2. Slide open the cover. Inside, you will find a slot for two AAA batteries and a dedicated storage slot for the 2.4G USB receiver.
3. Insert two AAA batteries (not included) into the compartment, ensuring correct polarity (+/-).
4. If using 2.4GHz mode, remove the USB receiver from its storage slot. If using Bluetooth mode only, you may leave the receiver stored.
5. Close the battery compartment cover securely.



Image: Battery compartment with AAA batteries and USB receiver storage.

### 3.2. 2.4GHz Wireless Mode Setup

1. Ensure the keyboard has fresh AAA batteries installed.
2. Remove the 2.4G USB receiver from the battery compartment.
3. Plug the USB receiver into an available USB port on your device (Smart TV, PC, laptop, gaming console, etc.). You may use the provided USB extension cable if needed for better signal reception or accessibility.
4. The device should automatically recognize the keyboard. The keyboard is now ready for use in 2.4GHz mode.

### 3.3. Bluetooth Mode Setup

1. Ensure the keyboard has fresh AAA batteries installed.
2. Turn on the keyboard.
3. Press and hold the **Fn** key, then press the **Bluetooth icon key** (usually F1 or F2, refer to keyboard layout) to activate Bluetooth pairing mode. The Bluetooth indicator light on the keyboard will flash.
4. On your device (Smart TV, PC, laptop, tablet, smartphone), go to the Bluetooth settings and enable Bluetooth.
5. Search for available devices. The keyboard should appear as "iPazzPort Keyboard" or similar.
6. Select the keyboard to pair. If prompted, enter the pairing code displayed on your device using the iPazzPort keyboard, then press Enter.
7. Once paired, the Bluetooth indicator light on the keyboard will stop flashing and remain solid or turn off, indicating a successful connection.

## 4. OPERATING INSTRUCTIONS

---

### 4.1. Switching Between 2.4GHz and Bluetooth Modes

The keyboard supports dual-mode operation. To switch between 2.4GHz and Bluetooth modes, simply short press the corresponding mode key (e.g., the 2.4G key or the Bluetooth icon key). The keyboard will automatically connect to the last paired device in the selected mode.

### 4.2. Keyboard Functions

- **Typing:** Use the QWERTY layout for standard text input.
- **Function Keys (Fn):** Press and hold the **Fn** key to access the secondary functions printed on certain keys (e.g., media controls, F-keys).
- **Side Page-Turn Keys:** Dedicated buttons on the side of the keyboard allow for quick page navigation, useful for browsing or presentations.

### 4.3. Touchpad Functions

The integrated touchpad provides responsive cursor control.

- **Cursor Movement:** Slide your finger across the touchpad surface to move the cursor.
- **Left Click:** Press the dedicated left mouse button below the touchpad, or tap once on the touchpad.
- **Right Click:** Press the dedicated right mouse button below the touchpad, or tap twice on the touchpad.
- **Scrolling:** Use two fingers to scroll vertically on the touchpad.

# Highly Responsive Touchpad



Image: Demonstrating the highly responsive touchpad and mouse buttons.

## 4.4. Device Compatibility

The iPazzPort Mini Bluetooth Keyboard is compatible with a wide range of devices and operating systems, including:

- Smart TVs (Fire TV, Android TV)
- Windows/Mac Laptops and PCs
- Tablets (iOS/Android)
- Gaming Consoles

## Wide Compatibility

Works with many Devices and Systems




Image: Visual representation of the keyboard's wide compatibility with different device types.

### 4.5. Official Product Video

Video: An official product video demonstrating the features and dual-mode functionality of the iPazzPort Mini Bluetooth Keyboard with Touchpad.

## 5. MAINTENANCE

### 5.1. Cleaning

- Use a soft, dry cloth to wipe the surface of the keyboard.
- For stubborn dirt, slightly dampen the cloth with water or a mild, non-abrasive cleaner. Avoid excessive moisture.
- Do not use harsh chemicals, solvents, or abrasive materials, as these can damage the keyboard's finish.

### 5.2. Battery Replacement

When the keyboard's performance degrades or it stops responding, it may be time to replace the AAA batteries. Follow the instructions in Section 3.1 to replace the batteries.

### 5.3. Storage

When not in use for extended periods, store the keyboard in a cool, dry place. It is recommended to remove the batteries to prevent leakage and potential damage to the device.

## 6. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Keyboard not responding	Low batteries; Incorrect mode selected; USB receiver not plugged in (2.4GHz); Not paired (Bluetooth)	Replace batteries; Switch to correct mode (2.4GHz or Bluetooth); Plug in USB receiver; Re-pair via Bluetooth settings.
Touchpad unresponsive	Software glitch; Keyboard frozen	Turn the keyboard off and on again; Restart the connected device.
Intermittent connection	Interference; Distance from device; Low battery	Move closer to the device; Ensure no obstructions; Replace batteries; Try a different USB port for the receiver.
Keys not typing correctly	Language settings; Keyboard layout issue	Check your device's language and keyboard layout settings.

## 7. SPECIFICATIONS

- **Brand:** iPazzPort
- **Model Number:** 19SM01
- **Connectivity Technology:** Bluetooth, RF (2.4GHz), USB
- **Compatible Devices:** Gaming Console, Laptop, PC, Television (Smart TV, Fire TV, Android TV), Tablets, iOS/Android devices
- **Keyboard Description:** Gaming
- **Special Feature:** Portable
- **Color:** Black
- **Keyboard Layout:** QWERTY
- **Number of Keys:** 82
- **Item Weight:** 75 Grams
- **Material:** Polymer
- **Power Source:** 2 x AAA Batteries (not included)

## 8. WARRANTY INFORMATION

This iPazzPort product is covered by a **1-year manufacturer's warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. It does not cover damage caused by misuse, accident, unauthorized modification, or external causes.

Please retain your proof of purchase for warranty claims.

## 9. SUPPORT

For further assistance, technical support, or warranty inquiries, please refer to the contact information provided in your product packaging or visit the official iPazzPort website. Our support team is available to help with any questions or issues you may encounter.

