

[Manuals.plus](#) /

› [Vonaural](#) /

› Vonaural Hybrid Active Noise Cancelling Headphones User Manual

Vonaural headphones

Vonaural Hybrid Active Noise Cancelling Headphones User Manual

Model: headphones

Brand: Vonaural

INTRODUCTION

Thank you for choosing Vonaural Hybrid Active Noise Cancelling Headphones. This manual provides essential information for setting up, operating, and maintaining your headphones. Please read it carefully to ensure optimal performance and longevity of your device. These headphones feature advanced Hybrid Active Noise Cancellation, Hi-Fi audio with deep bass, up to 30 hours of playtime, and Bluetooth 5.2 connectivity for clear calls and immersive listening.

WHAT'S IN THE BOX

- Vonaural Hybrid Active Noise Cancelling Headphones
- Charging Cable

PRODUCT OVERVIEW

Familiarize yourself with the components and controls of your Vonaural headphones.



Figure 1: Vonaural Hybrid Active Noise Cancelling Headphones, main view.

Controls and Indicators



Figure 2: Side view of the headphones showing control buttons and ports.

- **Power Button:** Press and hold to power on/off.
- **Volume Up/Next Track:** Short press for volume up, long press for next track.
- **Volume Down/Previous Track:** Short press for volume down, long press for previous track.
- **Multi-function Button (MFB):** Play/Pause, Answer/End calls.
- **ANC/Transparency Button:** Toggle between Active Noise Cancellation, Transparency Mode, and Normal Mode.
- **Charging Port:** USB-C port for charging.
- **LED Indicator:** Displays power, pairing, and charging status.
- **Microphones:** Built-in noise-reduction microphones for clear calls.

SETUP

1. Charging the Headphones

Before first use, fully charge your headphones. A full charge provides up to 30 hours of playtime.

1. Connect the provided charging cable to the USB-C port on the headphones.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The LED indicator will show charging status (e.g., red for charging, blue for fully charged).



Figure 3: Headphones illustrating 30 hours of playtime on a single charge.

2. Powering On/Off

- **To Power On:** Press and hold the Power button for approximately 3 seconds until the LED indicator flashes blue and you hear a power-on prompt.
- **To Power Off:** Press and hold the Power button for approximately 3 seconds until the LED indicator flashes red and you hear a power-off prompt.

3. Bluetooth Pairing

Pair your headphones with your device for wireless audio.

1. Ensure the headphones are powered off.

2. Press and hold the Power button for 5-7 seconds until the LED indicator flashes red and blue alternately, indicating pairing mode.
3. On your device (smartphone, tablet, computer), enable Bluetooth and search for available devices.
4. Select "SE7" from the list of available devices.
5. Once connected, the LED indicator will flash blue slowly, and you will hear a connection prompt.




Figure 4: Bluetooth 5.2 pairing with a smartphone, showing 'SE7' as the device name.

OPERATING INSTRUCTIONS

1. Active Noise Cancellation (ANC) and Transparency Mode

Your headphones feature Hybrid ANC to reduce external noise and Transparency Mode to stay aware of your surroundings.

- Press the **ANC/Transparency Button** to cycle through modes:
- **ANC On:** Reduces up to 97.5% of background noise. Ideal for travel or noisy environments.
- **Transparency Mode:** Allows ambient sounds to pass through, so you can hear your surroundings without removing your headphones.
- **Normal Mode:** ANC and Transparency Mode are off.





Figure 5: Hybrid ANC technology with dual microphones for noise reduction.



ENGAGE WITH THE WORLD, STAY IN THE MUSIC

Transparency mode lets you enjoy your music without missing what's happening around you.

Figure 6: Transparency Mode allows you to engage with your surroundings.

2. Music Playback

- **Play/Pause:** Press the MFB once.
- **Next Track:** Long press the Volume Up button.
- **Previous Track:** Long press the Volume Down button.

3. Call Management

- **Answer/End Call:** Press the MFB once.
- **Reject Call:** Press and hold the MFB for 2 seconds.




Figure 7: Headphones provide crystal clear calls with ENC microphones.

4. Volume Control

- **Increase Volume:** Short press the Volume Up button.
- **Decrease Volume:** Short press the Volume Down button.

MAINTENANCE

Cleaning

- Wipe the headphones with a soft, dry cloth.
- Do not use abrasive cleaners or solvents.
- Keep the charging port free of dust and debris.

Storage

- Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid placing heavy objects on the headphones.
- The foldable design allows for compact storage.



Figure 8: Ergonomic design with multi-angle rotation, memory foam ear cups, and adjustable headband for comfort.

TROUBLESHOOTING

If you encounter issues with your headphones, refer to the following solutions:

Problem	Solution
Headphones do not power on.	Ensure the headphones are fully charged. Connect to a power source and try again.

Problem	Solution
Cannot pair with device.	Ensure headphones are in pairing mode (LED flashes red/blue). Turn off and on Bluetooth on your device. Forget previous pairings and try again. Ensure your device is searching for 'SE7'.
No sound or low volume.	Check volume levels on both headphones and your connected device. Ensure headphones are properly paired.
ANC not working in wired mode.	Active Noise Cancellation is automatically disabled when the headphones are used in wired mode. This is a design characteristic.
Charging issues.	Use the original charging cable. Ensure the cable and charging port are clean and undamaged. Try a different USB power source.

SPECIFICATIONS

Detailed technical specifications for your Vonaural headphones.

Feature	Specification
Model Name	headphones
Connectivity Technology	Wireless (Bluetooth)
Bluetooth Version	5.2
Audio Driver Type	40mm Dynamic Driver
Noise Control	Hybrid Active Noise Cancellation, Transparency Mode
Battery Life	Up to 30 Hours
Earpiece Shape	Over Ear
Material	Plastic, Silicone (Memory Foam Earcups)
Item Weight	15.8 ounces
Control Method	Buttons
Included Components	Charging Cable

WARRANTY AND SUPPORT

Vonaural products are designed for reliability and performance. Your headphones are covered by a standard manufacturer's warranty against defects in materials and workmanship. For specific warranty details, please refer to the warranty card included with your purchase or contact Vonaural customer support.

For technical assistance, troubleshooting not covered in this manual, or warranty claims, please contact Vonaural customer support through the retailer where you purchased the product or visit the official Vonaural website for contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question

and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question