

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [BrickSoul](#) /

› [BrickSoul LED Light Kit for LEGO The Going Merry Pirate Ship 75639 - Wired Dimmable Instruction Manual](#)

BrickSoul 75639-TV

BrickSoul LED Light Kit for LEGO The Going Merry Pirate Ship 75639 - Wired Dimmable Instruction Manual

INTRODUCTION

Thank you for choosing the BrickSoul LED Light Kit. This kit is designed to enhance your LEGO The Going Merry Pirate Ship (model 75639) building set, bringing it to life with vibrant, dimmable lighting. This manual provides comprehensive instructions for installation, operation, maintenance, and troubleshooting to ensure a seamless experience. Please note: The LEGO building set is not included with this lighting kit.



Image: The BrickSoul LED Light Kit installed on the LEGO The Going Merry Pirate Ship, showcasing the illuminated details.

WHAT'S IN THE BOX

Your BrickSoul LED Light Kit package should contain the following components:

- LED Light Kits (various light strings and components)
- Light Control Button (integrated into USB cable)
- Battery Box (requires AAA batteries, not included)
- Installation Guide (for digital instructions)

Light Kit Only – Not Model

Package Include:



Image: A visual representation of the components included in your BrickSoul LED Light Kit package.

SETUP AND INSTALLATION

The BrickSoul LED kit is designed for quick and beginner-friendly setup. Follow the detailed digital instructions provided via video or PDF guides. No special skills are needed; simply remove a few bricks from your LEGO model and integrate the lighting components.

Key Installation Principles:

- **Seamless Fit:** The lighting components are designed to integrate neatly into your model, ensuring a clean and professional appearance without tangled wires.
- **Digital Guides:** Refer to the numbered step-by-step bags and clear video/PDF guides for precise installation instructions. These guides will walk you through each step of the process.
- **Power Connection:** Connect the lighting kit to the provided USB cable. You can power it via a USB power bank, USB wall adapter, or the included battery box (ensure AAA batteries are installed). The system operates safely on 3-5V input.

BRINGING EVERY DETAIL TO LIFE

Model is for Display Use Only and NOT INCLUDED




Image: Detailed view of the LED lights integrated into various sections of the LEGO model, showcasing the illumination.

Upgrade Your Building Set with Light

Bring Your Creation to Life at Night



Image: The LEGO model with BrickSoul LED lights, displayed in a home environment, demonstrating its visual impact.

Installation Video Guide:

Your browser does not support the video tag.

Video: An official BrickSoul video demonstrating the installation process and showcasing the illuminated LEGO The Going Merry Pirate Ship.

OPERATING INSTRUCTIONS

This upgraded BrickSoul LED Light Kit features a convenient built-in button on the USB cable for easy control.

- **Turn On/Off:** Simply tap the button on the USB cable to switch the lights on or off.
- **Adjust Brightness:** Press and hold the button to adjust the brightness level. Release the button when you reach your desired illumination. This allows for customization of your display and helps conserve energy.

Hold To Adjust Brightness By **Usb Button**

Light Kit Only – Model Not Included



Light Off

Light On



0%

50%

100%



Turn On / Off



Adjust Brightness

New Upgrade



Image: Visual guide demonstrating the dimmable functionality of the LED light kit, from off to full brightness, controlled by the USB button.

MAINTENANCE

To ensure the longevity and optimal performance of your BrickSoul LED Light Kit, follow these simple maintenance guidelines:

- **Cleaning:** Gently dust the lights and wires with a soft, dry cloth. Avoid using liquid cleaners directly on the electrical components.
- **Handling:** Handle the wires and LED components with care. Avoid excessive pulling or bending, which could damage the connections.
- **Power Supply:** Always use a stable 3-5V USB power source. Ensure batteries in the battery box are replaced when depleted to maintain consistent light output.
- **Storage:** If disassembling or storing the kit, ensure wires are not tangled or pinched. Store in a dry, cool place.

TROUBLESHOOTING

If you encounter any issues with your BrickSoul LED Light Kit, please refer to the following common solutions:

- **Lights Not Turning On:**

- Check all USB connections to ensure they are securely plugged in.
- Verify that your USB power source (power bank, wall adapter, or battery box) is functioning correctly and providing power.
- If using the battery box, ensure fresh AAA batteries are installed with correct polarity.

- **Some Lights Not Working:**

- Inspect individual light connections for any loose or bent connectors.
- Gently re-seat any connections that appear loose.

- **Lights Flickering:**

- Ensure a stable power supply. Fluctuations in power can cause flickering.
- Check for any loose connections.

If these steps do not resolve the issue, please contact BrickSoul customer support for further assistance.

SPECIFICATIONS

Feature	Detail
Product Dimensions	6.36 x 4.32 x 1.33 inches
Item Weight	4.8 ounces
Item Model Number	75639-TV
Manufacturer Recommended Age	14 years and up
Manufacturer	BrickSoul

WARRANTY AND SUPPORT

BrickSoul is committed to providing a smooth and stress-free lighting experience. Your LED Light Kit comes with a worry-free warranty.

- **Hassle-Free Replacements:** In the event of accidental damage, such as a bent connector or broken wire, BrickSoul offers quick and hassle-free replacements.
- **Customer Support:** Our dedicated support team is available to assist you with any questions, concerns, or issues you may encounter.

For support or to inquire about replacements, please visit the [BrickSoul Store on Amazon](#) or contact us through the platform where you purchased the product.