

RUOYINKE Q5 Projector Remote Control

RUOYINKE Remote Control for VOPLLS Q5 Mini Projectors User Manual

Model: Q5 Projector Remote Control

INTRODUCTION

This manual provides instructions for the proper setup, operation, and maintenance of your RUOYINKE Remote Control, specifically designed for VOPLLS Q5 Mini Projectors. Please read this manual thoroughly before use to ensure optimal performance and longevity of your device.

Compatibility Note: This remote control is exclusively compatible with VOPLLS Q5 Mini Projectors. It is not designed to work with other brands or models of projectors.

SETUP

Battery Installation

The remote control requires two (2) AAA 1.5V batteries for operation. No special matching or pairing procedure is required; simply install the batteries, and the remote will be ready for use.

1. Locate the battery compartment cover on the back of the remote control.
2. Slide the cover downwards or press the latch (if present) to open the compartment.
3. Insert two new AAA 1.5V batteries, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
4. Replace the battery compartment cover by sliding it back into place until it clicks securely.



Figure 1: Battery compartment with AAA batteries. Ensure correct polarity when inserting batteries.

OPERATING INSTRUCTIONS

Once batteries are installed, the remote control is ready to operate your VOPLLS Q5 Mini Projector. Point the remote directly at the projector for best signal transmission.



Figure 2: RUOYINKE Remote Control and VOPLLS Q5 Mini Projector.

Key Functions

- **Power Button ():** Turns the projector on or off.
- **Navigation Pad (Up, Down, Left, Right, OK):** Used to navigate menus and select options on the projector screen.
- **Back Button (←):** Returns to the previous menu or screen.
- **Home Button (△):** Accesses the projector's main home screen.
- **Volume Buttons (VOL+, VOL-):** Adjusts the audio output volume.
- **Source/Input Button:** Switches between different input sources (e.g., HDMI, USB).
- **Apps Button:** Opens the projector's application menu.
- **Settings Button (⚙):** Accesses the projector's system settings.
- **Focus Buttons (F+, F-):** Adjusts the projector's focus.
- **Mute Button ():** Mutes or unmutes the audio.
- **USB Button:** Likely for direct access to USB media.
- **Screen Mirroring/Cast Button:** Initiates screen mirroring or casting functions.
- **Dedicated App Buttons (Netflix, YouTube, Disney+, Prime Video):** Provides quick access to these streaming applications.

MAINTENANCE

Battery Care

- If the remote control will not be used for an extended period, remove the batteries to prevent potential leakage and damage to the controller.
- Replace batteries when the remote's responsiveness decreases or it stops functioning.
- Dispose of used batteries responsibly according to local regulations.

Cleaning

- Wipe the remote control with a soft, dry cloth.
- Do not use liquid cleaners or abrasive materials, as these can damage the surface or internal components.

TROUBLESHOOTING

- **Remote not responding:**
 - Ensure batteries are inserted correctly with the correct polarity.
 - Replace old batteries with new AAA 1.5V batteries.
 - Check for any obstructions between the remote control and the projector's IR receiver.
 - Confirm the remote is pointed directly at the projector.
- **Buttons not working:**
 - Verify that the remote is compatible with your specific VOPLLS Q5 Mini Projector model.
 - If only certain buttons are unresponsive, try replacing the batteries.
- **Physical damage during transport:**
 - If the remote control arrived damaged, please contact customer support for a replacement or refund.

SPECIFICATIONS

| | |
|---------------------------|-----------------------------|
| Brand | RUOYINKE |
| Model Number | Q5 Projector Remote Control |
| Compatible Devices | VOPLLS Q5 Mini Projectors |
| Batteries Required | 2 x AAA 1.5V batteries |
| Product Dimensions | 5 x 2 x 1 inches |
| Item Weight | 4.8 ounces |

SUPPORT AND WARRANTY

For any questions, concerns, or if you are unsure about the compatibility of this remote control with your projector, please contact RUOYINKE customer support before making a purchase or for assistance after purchase.

If the product is damaged during transportation, RUOYINKE offers a free replacement or a refund. Please contact customer support immediately upon receipt if you encounter any issues.

Contact information for support is typically available through your purchase platform or the manufacturer's official website.