

Nautica NAPSDF503

Nautica NCT Sea Dive Watch NAPSDF503 User Manual

Model: NAPSDF503

INTRODUCTION

The Nautica NCT Sea Dive watch, model NAPSDF503, is an analog timepiece designed for water sports enthusiasts. It features a robust 47mm case, a distinctive gradient dial, and a durable silicone strap. This watch is built to withstand aquatic environments with a water resistance rating of 200 meters (660 feet).

Key features include:

- Analog display with 3 hands (hour, minute, second).
- 47mm case with a blue dial and mineral crystal.
- Comfortable blue silicone strap.
- Water resistance up to 200 meters (660 feet).

Figure 1: Front view of the Nautica NCT Sea Dive watch. This image displays the front of the Nautica NCT Sea Dive watch. It features a dark blue dial with white luminous hour markers and hands, a yellow second hand, and a date window at 3 o'clock. The unidirectional bezel is dark blue with yellow and white markings.

The watch is fitted with a blue ribbed silicone strap.

SETUP

Setting the Time and Date

1. **Pull out the crown:** Gently pull the crown (the knob on the side of the watch) to position 2 for setting the date, or to position 3 for setting the time.
2. **Set the date:** If in position 2, turn the crown clockwise or counter-clockwise to adjust the date. Avoid setting the date between 9 PM and 3 AM, as this can damage the movement.
3. **Set the time:** If in position 3, turn the crown to move the hands clockwise until the correct time is displayed. Ensure you differentiate between AM and PM for watches with a date function.
4. **Push in the crown:** Once the time and date are set, push the crown back into position 1 (normal operating position) to start the watch.

Adjusting the Silicone Strap

The silicone strap is designed for comfort and durability. To adjust the fit, use the buckle to select the appropriate hole on the strap that provides a snug yet comfortable fit on your wrist. Ensure the watch is not too tight to allow for proper circulation, nor too loose to prevent it from sliding excessively.

OPERATING THE WATCH

Timekeeping

The Nautica NCT Sea Dive watch operates as a standard analog timepiece, displaying hours, minutes, and seconds. The date window provides a quick reference for the current day of the month.

Unidirectional Rotating Bezel

The watch features a unidirectional rotating bezel, which is a common tool for divers to measure elapsed time underwater. To use it:

1. Align the zero marker on the bezel with the minute hand at the start of your dive or activity.
2. As time passes, the minute hand will indicate the elapsed time against the bezel's scale.
3. The bezel rotates only counter-clockwise to prevent accidental increases in perceived elapsed time, which is a critical safety feature for diving.

Water Resistance (200 Meters / 660 Feet)

This watch is rated for 200 meters (20 ATM) of water resistance, making it suitable for professional marine activity and serious surface water sports, but not for saturation diving. Always ensure the crown is fully pushed in before exposing the watch to water. Do not operate the crown or pushers (if any) while the watch is wet or submerged.

MAINTENANCE

Cleaning

To maintain the appearance and longevity of your watch:

- Wipe the watch case and crystal with a soft, damp cloth.
- For the silicone strap, wash with mild soap and water, then rinse thoroughly and dry.
- After exposure to saltwater, rinse the watch with fresh water and dry it completely to prevent corrosion.

Battery Replacement

The watch is powered by a quartz movement that requires a battery. When the watch stops or the second hand begins to jump erratically (if applicable), it indicates a low battery. Battery replacement should be performed by a qualified watch technician to ensure the water resistance seal is properly maintained.

Water Resistance Checks

It is recommended to have the watch's water resistance checked annually, especially if it is frequently exposed to water or if the battery has been replaced. Gaskets and seals can degrade over time, affecting water resistance.



Figure 2: Back view of the Nautica NCT Sea Dive watch. This image shows the back of the Nautica NCT Sea Dive watch. The stainless steel case back is engraved with the Nautica logo, 'JAPAN MOVEMENT', 'STAINLESS STEEL', 'WATER RESISTANT 200 METERS', and the model number 'NAPSDF503'. The blue silicone strap is also visible.

TROUBLESHOOTING

- **Watch not running:** Check if the crown is fully pushed in. If it is, the battery may need replacement.
- **Condensation under the crystal:** This indicates a breach in the water resistance. Immediately take the watch to a qualified technician for inspection and repair to prevent further damage to the movement.
- **Date not changing:** Ensure the time is set correctly, differentiating between AM and PM. If the date changes at noon, the watch is set 12 hours off.

SPECIFICATIONS

Model Number	NAPSDF503
Movement Type	Analog Quartz
Case Material	Stainless Steel
Case Diameter	47 mm
Case Thickness	14 mm
Crystal Material	Mineral Glass
Strap Material	Silicone
Strap Width	22 mm
Water Resistance	200 Meters (660 Feet)
UPC	656086112443
Country of Origin	Philippines

WARRANTY INFORMATION

This Nautica watch comes with a **1-year limited warranty** from the date of purchase. The warranty covers manufacturing defects in materials and workmanship under normal use. It does not cover damage resulting from improper handling, accidents, unauthorized repairs, or normal wear and tear of the strap, case, or crystal. Please retain your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For further assistance, service, or warranty claims, please contact Nautica customer support or visit the official Nautica website. When contacting support, please have your watch model number (NAPSDF503) and proof of purchase readily available.

You can find more information and contact details on the [Nautica Brand Store](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question