

[Manuals.plus](#) /

› [YITAHOME](#) /

› YITAHOME Farmhouse TV Stand with Adjustable Mount (Model: B0FMFMG68N) - User Manual

YITAHOME B0FMFMG68N

YITAHOME Farmhouse TV Stand with Adjustable Mount

Model: B0FMFMG68N

User Manual

1. PRODUCT OVERVIEW

The YITAHOME Farmhouse TV Stand with Adjustable Mount is designed to accommodate televisions ranging from 32 to 70 inches. This entertainment center features a height-adjustable TV mount and ample storage solutions, blending functionality with a rustic farmhouse aesthetic. It is constructed from engineered wood, ensuring stability and durability.




Image 1.1: The YITAHOME Farmhouse TV Stand with an adjustable TV mount, featuring a grey-white finish and espresso top, suitable for living room environments.

2. KEY FEATURES

- **Versatile TV Mount Options:** The stand supports TVs from 32 to 70 inches. Users can choose to mount the TV directly on the integrated bracket or place it on the tabletop. For tabletop placement, a 65-inch TV is recommended for optimal fit.
- **Adjustable Viewing Angles:** The TV mount offers 3 height levels (16.54"-20.47") and left-right adjustments, allowing for customized viewing positions.
- **Ample, Flexible Storage:** This entertainment center includes a 3-level adjustable middle shelf and two side cabinets with interior shelves. These provide flexible storage for media consoles, decorative items, and accessories. Two integrated cutouts assist in organizing cables.
- **Sturdy Farmhouse Design:** Constructed from engineered wood with a reinforced base, the TV stand is designed for durability. The mixed colors and X-motif on the cabinet doors contribute to a rustic farmhouse aesthetic.

- **Effortless Assembly:** The product includes clearly labeled parts, necessary accessories, and step-by-step instructions to facilitate a straightforward assembly process.




X Reinforced Cabinet Door

Enhanced Durability and Security
with Strengthened Design

Non-slip Foot Pad

Ensuring Stability and Safety
with Anti-skid Technology



Adjustable Partition

Providing Diverse Choices for
Your Storage Space



Adjustable TV Bracket

Providing Optimal Viewing Angles for
Your TV Experience




Image 2.1: Detailed view of key features, including the X-reinforced cabinet doors, non-slip foot pads, adjustable interior shelves, and the adjustable TV bracket mechanism.



MULTI-FUNCTIONAL STORAGE SOLUTIONS

Bringing More Order to Your Life



headset



decoration



book



games console

Image 2.2: Illustration of the multi-functional storage solutions, accommodating items such as headphones, decorations, books, and game consoles.

Product Feature Video

Your browser does not support the video tag.

Video 2.3: A short video demonstrating the adjustable partition, storage capabilities, and overall design of the TV stand.

3. SETUP AND ASSEMBLY

Assembly of the YITAHOME TV Stand is designed to be straightforward. Please follow the detailed, step-by-step instructions provided in the packaging. Ensure all parts are accounted for before beginning assembly.

1. Unpack all components and verify against the parts list in the instruction manual.
2. Identify and separate hardware.
3. Follow the numbered steps in the manual for constructing the main cabinet.

4. Attach the TV mounting bracket according to the instructions, ensuring it is securely fastened.
5. Install the adjustable shelves as desired.

It is recommended to assemble the unit on a soft, clean surface to prevent scratches. Two people may be required for certain assembly steps, especially when handling larger components or mounting the TV.



**The TV is mounted
on the wall**

**Using the shelf to
install the TV**

Image 3.1: Comparison of TV mounting options: directly on the wall or utilizing the integrated adjustable TV stand mount.

4. OPERATING INSTRUCTIONS

4.1 Adjusting TV Mount Height

The integrated TV mount allows for height adjustments to optimize your viewing experience. To adjust the height:

1. Ensure the TV is securely attached to the mount.
2. Locate the height adjustment mechanism on the vertical support column.
3. Carefully lift or lower the TV to one of the three available height levels (16.54"-20.47").

4. Secure the TV at the desired height using the provided locking mechanisms.

4.2 Utilizing Storage Compartments

The TV stand offers various storage options:

- **Middle Shelves:** The middle shelf is adjustable to three different levels, allowing you to customize the space for media devices, game consoles, or decorative items. To adjust, remove the shelf pins, reposition the shelf, and reinsert the pins into the desired holes.
- **Side Cabinets:** The two side cabinets provide enclosed storage. Open the barn-door style doors to access the interior shelves.
- **Cable Management:** Use the integrated cutouts on the back panel to route and organize cables, maintaining a tidy appearance.

Adjustable Shelf Demonstration Video

Your browser does not support the video tag.

Video 4.1: A demonstration of how to adjust the interior shelves within the TV stand's cabinets.

5. MAINTENANCE

To ensure the longevity and appearance of your YITAHOME TV Stand, follow these maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid using harsh chemicals, abrasive cleaners, or polishes that may damage the engineered wood finish.
- **Spills:** Immediately blot any spills with a clean, dry cloth to prevent moisture absorption and staining.
- **Heat and Moisture:** Avoid placing hot items directly on the surface. Use coasters or protective pads. Keep the unit away from excessive moisture or direct sunlight to prevent warping or fading.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary to maintain structural integrity.

6. TROUBLESHOOTING

If you encounter any issues with your YITAHOME TV Stand, consider the following common solutions:

- **Wobbly Stand:** Ensure all cam locks and screws are fully tightened. Verify that the stand is placed on a level surface. Adjust the non-slip foot pads if necessary.
- **Doors Not Aligning:** Check the hinge adjustments on the cabinet doors. Most hinges allow for minor adjustments to align the doors properly. Refer to the assembly manual for specific hinge adjustment instructions.
- **TV Mount Instability:** Confirm that the TV mount is correctly assembled and securely fastened to both the TV and the stand. Ensure the TV's weight does not exceed the maximum load capacity (300 lbs).
- **Missing Parts:** If any parts were missing during assembly, please contact YITAHOME customer support with your purchase information.

For persistent issues or concerns not addressed here, please refer to the contact information in the Warranty and Support section.

7. SPECIFICATIONS

Feature	Detail
Brand	YITAHOME
Model Number	B0FMFMG68N
Material	Engineered Wood
Color	Grey White & Espresso
Item Dimensions (L x W x H)	149.9 x 39.9 x 50.3 Centimetres (59"W x 15.7"D x 19.8"H)
Item Weight	80.24 Pounds
TV Size Compatibility	32" to 70" (mount), up to 65" (tabletop)
TV Mount Load Capacity	300 lbs
Adjustable Mount Height	3 levels (16.54"-20.47")
Assembly Required	Yes
UPC	199449600404

PRODUCT SIZE



Image 7.1: Detailed product dimensions for the TV stand and its integrated mount.

8. WARRANTY AND SUPPORT

YITAHOME products are designed for quality and durability. For specific warranty information, including coverage details and duration, please refer to the warranty card included with your product or visit the official YITAHOME website. If you require assistance with assembly, have questions about product functionality, or need to report a defect, please contact YITAHOME customer support directly.

Customer Support:

- Refer to the contact information provided in your product packaging.
- Visit the [YITAHOME Store on Amazon](#) for additional resources and contact options.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question