

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [idoooz](#) /

› [idoooz X2 Mini MP3 Music Player User Manual](#)

idoooz X2

idoooz X2 Mini MP3 Music Player User Manual

Model: X2 | Brand: idoooz

1. INTRODUCTION

Thank you for choosing the idoooz X2 Mini MP3 Music Player. This compact and lightweight device is designed for portability and ease of use, perfect for sports, gym, jogging, and other activities. It features a clip-on design, LED indicators, and 8GB of built-in storage for your music.



Image 1.1: The idoooz X2 Mini MP3 Player with wired earphones.

2. WHAT'S IN THE BOX

Please check the package contents to ensure all items are present:

- idoooz X2 Mini MP3 Player
- High-quality Earphones
- USB-C Charging Cable
- User Manual (this document)



Image 2.1: Package contents of the idoooz X2 Mini MP3 Player.

3. PRODUCT OVERVIEW AND COMPONENTS

Familiarize yourself with the various parts and controls of your idoooz X2 MP3 Player.




Image 3.1: Labeled diagram of the idoooz X2 MP3 Player components.

- **USB-C Charging Port / Data Transfer:** Used for charging the device and transferring music files.
- **LED Charging Indicator Light:** Indicates charging status.
- **LED Playback Status Light:** Indicates device status (play/pause/power).
- **Volume - / +:** Adjusts the playback volume.
- **Previous Track / Fast Backward:** Navigates to the previous track or fast backward.
- **Next Track / Fast Forward:** Navigates to the next track or fast forward.
- **EQ / Shuffle / Standard Playback:** Toggles between equalizer modes, shuffle, and standard playback.
- **On / Off / Play / Pause:** Powers the device on/off and controls music playback.
- **3.5 mm Earphone Jack:** Connects your wired earphones.
- **RESET:** Small button for resetting the device if needed.
- **Clip:** Integrated clip for attaching the player to clothing or accessories.

4. SETUP

4.1 Charging the Device

Before first use, fully charge your MP3 player. The built-in 110mAh rechargeable battery provides approximately 15 hours of continuous music playback at medium volume and takes about 2.5 hours to fully charge.

1. Connect the provided USB-C cable to the charging port on the MP3 player.
2. Connect the other end of the USB-C cable to a USB power adapter (not included) or a computer's USB port.
3. The LED Charging Indicator Light will illuminate during charging. It will change or turn off once charging is complete.

4.2 Transferring Music Files

The idoooz X2 has 8GB of built-in flash memory, capable of storing over 2,000 songs. It supports MP3, WMA, APE, and FLAC formats with lossless audio quality.

1. Connect the MP3 player to your computer using the provided USB-C cable.
2. The computer will recognize the MP3 player as a removable disk drive.
3. Open the drive folder. You can drag and drop your music files (MP3, WMA, APE, FLAC) directly into this folder.
4. Once all files are transferred, safely eject the MP3 player from your computer before disconnecting the cable.

Small Size, Large Memory, Fast Transfer



OTG Function-Fast Transmission

Connect your cell phone and idoooz MP3 player via OTG cable for file transfer function.



Image 4.1: Transferring music files from a computer to the MP3 player.

OTG Function (Optional): You can also transfer music from your smartphone to the MP3 player using an OTG adapter (not included) and a compatible cable. Connect the OTG adapter to your phone, then connect the MP3 player via its USB-C cable to the adapter.

OTG function, cell phone transfer.

Use an OTG adapter to transfer music from your phone to the clip on MP3 player



Image 4.2: Using the OTG function to transfer music from a smartphone.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off and Playback

1. **Power On:** Press and hold the **On/Off/Play/Pause** button until the LED Playback Status Light illuminates.
2. **Play/Pause:** Briefly press the **On/Off/Play/Pause** button to play or pause the current track. The LED light will flash to indicate playback status.
3. **Power Off:** Press and hold the **On/Off/Play/Pause** button until the LED Playback Status Light turns off.

5.2 Volume Adjustment

- Press the **Volume +** button to increase the volume.
- Press the **Volume -** button to decrease the volume.

5.3 Track Navigation

- **Next Track:** Briefly press the **Next Track / Fast Forward** button.
- **Previous Track:** Briefly press the **Previous Track / Fast Backward** button.
- **Fast Forward:** Press and hold the **Next Track / Fast Forward** button.
- **Fast Backward:** Press and hold the **Previous Track / Fast Backward** button.

5.4 EQ / Shuffle / Standard Playback

Press the **EQ / Shuffle / Standard Playback** button to cycle through different playback modes, including equalizer settings and shuffle mode.




Image 5.1: The idoooz X2 MP3 Player in use during exercise.

6. MAINTENANCE

- Keep the device dry. Avoid exposure to moisture or liquids.
- Clean the device with a soft, dry cloth. Do not use harsh chemicals or abrasive cleaners.

- Avoid extreme temperatures. Do not store in very hot or cold environments.
- Protect the USB-C port and earphone jack from dust and debris.
- If the device becomes unresponsive, use a thin object (like a paperclip) to press the **RESET** button.

7. TROUBLESHOOTING

Problem	Possible Solution
Device does not power on.	Ensure the device is fully charged. Press and hold the Power button for a few seconds. If unresponsive, try the RESET button.
Cannot transfer files to the device.	Ensure the USB-C cable is securely connected to both the player and the computer. Try a different USB port or cable. Ensure the device is powered on when connected.
No sound from earphones.	Check if earphones are properly plugged into the 3.5mm jack. Ensure volume is not set to minimum. Test with different earphones if available.
LED indicator not working.	Refer to the "Product Overview and Components" section for expected LED behavior. If the device functions otherwise, this may not indicate a critical issue.
Device freezes or becomes unresponsive.	Press the RESET button using a thin, pointed object. This will restart the device without deleting data.

8. SPECIFICATIONS

Feature	Detail
Model Name	X2
Brand	idoooz
Memory Storage Capacity	8 GB
Product Dimensions	1.81 x 1.18 x 0.7 inches
Item Weight	0.52 ounces
Connectivity Technology	USB-C
Supported Audio Formats	MP3, WMA, APE, FLAC
Battery Life	Approx. 15 hours (medium volume)
Charging Time	Approx. 2.5 hours
Special Features	Built-In Clip, Equalizer, LED light

9. WARRANTY AND SUPPORT

The idoooz X2 Mini MP3 Music Player comes with a 365-day warranty. If you encounter any problems or have questions regarding your device, please contact idoooz customer service directly for assistance.

For support, please refer to the contact information provided with your purchase or visit the official idoooz website.

Related Documents - X2

	<p><u>User Manual: IP68 Bone Conduction Headphones for Swimming</u></p> <p>This user manual provides instructions and specifications for IP68 bone conduction headphones designed for swimming, Bluetooth 5.2, MP3 playback, and sports activities.</p>
	<p><u>OPENEAR AS18 X2 Waterproof Bone Conduction Headphones User Manual</u></p> <p>User manual for the OPENEAR AS18 X2 waterproof bone conduction headphones, detailing features, operation, and care instructions.</p>
	<p><u>OPENEAR AS18 X2 Waterproof Bone Conduction Headphones User Manual</u></p> <p>User manual for the OPENEAR AS18 X2 Waterproof Bone Conduction Headphones, detailing features, operation, and specifications.</p>
	<p><u>HONGNIX X2 Bone Conduction Headphones User Manual</u></p> <p>User manual for HONGNIX X2 bone conduction headphones. This guide details charging procedures using a DC 5V adapter, explaining the LED indicators for charging status. It also identifies and describes the device's control buttons: Control Button, Plus Button (+), Minus Button (-), and the Multi-Function Button (MFB), along with the charging port. The document includes Italian translations for these terms. Key features of the HONGNIX X2 include Bluetooth 5.3 connectivity, IP68 waterproofing, and 32GB of internal memory for MP3 playback, making them suitable for swimming, running, and gym activities.</p>
	<p><u>Matrix Audio Element X2 Pure Music Streamer User Manual Setup, Features, Specifications</u></p> <p>Comprehensive user manual for the Matrix Audio Element X2 Pure music streamer. Learn about setup, connections, features like MQA and Roon Ready, technical specifications, and troubleshooting.</p>

[Playback Designs MPT-8 Music Playback Transport User Manual](#)

Comprehensive user manual for the Playback Designs MPT-8 Music Playback Transport, detailing setup, connections, operation, specifications, firmware updates, and the Stream-X2 option for audiophile-grade digital audio playback.