Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

LINSY HC718E4-02

LINSY HC718E4-02 Fluted Dresser Instruction Manual

Model: HC718E4-02 | Brand: LINSY

1. Product Overview

The LINSY HC718E4-02 Fluted Dresser is a versatile storage solution designed for bedrooms, living rooms, or entryways. It features a modern minimalist style with fluted drawer panels and gold metal handles.

Key Features:

- **Large Storage Capacity:** Measuring 15.7"D X 58.3"W X 34.7"H, this dresser provides ample space for clothing, accessories, and personal items. The wide top surface can display decorative items.
- **Modern Minimalist Style:** Features fluted drawer panels, rounded corners, a double-layer thickened top, wide gold metal handles, and a refined wood grain finish.
- **Durable Construction:** Crafted from premium materials with high-quality slide rails for smooth drawer operation, a thick back panel, and sturdy solid wood legs for enhanced stability.
- **Safety-Certified Design:** Meets ASTM 2057-2023 safety standards, includes smooth rounded edges, wide metal handles, and a secure anti-tip device.
- **Easy Assembly:** Designed for a hassle-free setup with clearly labeled parts and step-by-step instructions.



Figure 1: LINSY Fluted Dresser in a bedroom setting.



Figure 2: Product dimensions and weight capacity details.

2. Safety Information

To ensure safe use of your LINSY Fluted Dresser, please adhere to the following safety guidelines:

- This dresser meets ASTM 2057-2023 safety standards.
- Always use the provided anti-tip device to secure the dresser to a wall. Failure to do so can result in serious injury or death from tipping furniture.
- Ensure all parts are correctly assembled and fasteners are tightened before use.
- Do not allow children to climb on the dresser or open multiple drawers simultaneously.
- Place the dresser on a level surface to prevent wobbling.



Figure 3: Detail of the anti-toppling device and fluted panel design.



Figure 4: Important warning regarding the wall attachment device to prevent overturning.

3. Package Contents

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- Dresser panels (top, bottom, sides, back, dividers)
- 8 Drawer boxes with fluted fronts
- 8 Gold metal handles
- Drawer slide rails (pairs for each drawer)
- 4 Solid wood legs
- Anti-tip device kit
- Assembly hardware (screws, dowels, cam locks, brackets, etc.)
- Assembly tool (screwdriver/Allen wrench)

4. Assembly Instructions

Follow these step-by-step instructions carefully. It is recommended to assemble the dresser with two people.

Video Guide:

Video 1: Step-by-step installation guide for the LINSY Fluted Dresser. This video demonstrates the complete assembly process from unboxing to final setup, including attaching the anti-tip device.

Written Steps:

1. **Prepare the Workspace:** Clear a spacious, clean, and level area for assembly. Lay out all parts and hardware, matching them to the provided parts list.
2. **Assemble Drawer Slides:** Attach the drawer slide rails to the designated side panels of the dresser frame and the drawer boxes using the provided screws. Ensure they are securely fastened and aligned.
3. **Construct the Base:** Secure the solid wood legs to the bottom panel of the dresser using the provided brackets and screws.
4. **Assemble the Main Frame:** Connect the side panels, bottom panel, and internal dividers using dowels, cam locks, and screws. Ensure all connections are tight and the frame is stable.
5. **Attach the Top Panel:** Carefully place and secure the top panel to the assembled frame.
6. **Install the Back Panel:** Slide or nail the back panel into place, ensuring it fits snugly and adds rigidity to the structure.
7. **Assemble Drawer Boxes:** Construct each of the 8 drawer boxes by connecting the sides, front (fluted panel), and bottom. Attach the gold metal handles to the front of each drawer.
8. **Insert Drawers:** Carefully slide each assembled drawer into its respective slot in the dresser frame. Test for smooth operation.
9. **Install Anti-Tip Device:** Following the instructions provided with the anti-tip kit, securely attach the device to the back of the dresser and to a wall stud. This is a critical safety step.



Figure 5: Detail of solid wood leg attachment.

5. Operating Instructions

The LINSY Fluted Dresser is designed for straightforward use.

- **Opening/Closing Drawers:** Gently pull the gold metal handles to open drawers and push to close. The high-quality slide rails ensure smooth operation.
- **Weight Capacity:** Each drawer is designed to hold up to 30 lbs (13.6 kg). The top surface can support up to 150 lbs (68 kg). Do not exceed these limits to prevent damage or instability.
- **Storage:** Utilize the ample storage space for organizing clothes, linens, and other personal items. Consider using drawer organizers for optimal tidiness.




Figure 6: Illustration of smooth sliding drawers and internal organization.

6. Maintenance

Proper care will extend the life and appearance of your dresser.

- **Cleaning:** The engineered wood surface is waterproof and easy to clean. Wipe with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Dusting:** Regularly dust the surface with a dry, soft cloth.
- **Spills:** Immediately wipe up any spills to prevent staining or damage to the wood finish.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration.




Figure 7: Detail of the thick tabletop and drawer construction.

7. Troubleshooting

If you encounter any issues with your dresser, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Drawers do not slide smoothly.	Misaligned drawer slides or loose screws.	Check alignment of drawer slides and tighten all screws on the slides and drawer boxes.
Dresser wobbles.	Uneven floor or loose leg attachments.	Ensure the dresser is on a level surface. Check and tighten all leg attachment screws.
Dresser feels unstable.	Anti-tip device not installed or improperly secured.	Install or re-secure the anti-tip device to a wall stud as per instructions.

Problem	Possible Cause	Solution
Gap between drawer and frame.	Drawer front or frame panels are not aligned correctly.	Loosen and readjust the screws connecting the drawer front to the drawer box, or check frame assembly.

8. Specifications

Feature	Detail
Brand	LINSY
Model Number	HC718E4-02
Number of Drawers	8
Dimensions (D x W x H)	15.7"D x 47"W x 43.6"H
Item Weight	134 Pounds
Color	Walnut
Material Type	Engineered Wood
Mounting Type	Floor Mount (with wall attachment recommended)
Required Assembly	Yes
Safety Standard	ASTM 2057-2023 Compliant

9. Warranty and Support

For any questions, concerns, or assistance with your LINSY Fluted Dresser, please contact our customer support team. We are committed to providing a solution within 24 hours.
Please retain your purchase receipt for warranty claims. Specific warranty details may vary; refer to your purchase documentation or contact customer support for more information.
Contact Information: Refer to your product packaging or the retailer's website for the most current customer support contact details.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FMFZHVPB

More documents and user manuals: **https://manuals.plus/**