

## Spacekey JY-MF01

# Spacekey Milk Frother JY-MF01 Instruction Manual

Model: JY-MF01 | Brand: Spacekey

### INTRODUCTION

The Spacekey Milk Frother JY-MF01 is a versatile 4-in-1 electric appliance designed to enhance your coffee and beverage experience. It quickly produces smooth, velvety milk foam and can also warm milk for various drinks. This manual provides essential information for safe and effective operation, maintenance, and troubleshooting.



Image: The Spacekey Milk Frother JY-MF01 in blue, showcasing its compact design and control panel.

## IMPORTANT SAFETY INFORMATION

- Always use fresh whole milk (fat content >3%) for optimal foaming results. Cold milk generally froths better.
- The maximum heating temperature range of this milk frother is  $140\pm 41^{\circ}\text{F}$ .
- Do not re-froth or re-heat milk that has already been whisked or frothed.
- Pour out heated or frothed milk promptly for best results and to prevent residue buildup.
- Clean the frother immediately after each use to prevent milk residue from burning onto the interior during subsequent uses.
- **Do Not Immerse the Power Base in Water.** The pitcher bottom and power base should be kept away from water to prevent damage.
- Hand wash only. This appliance is not dishwasher safe.

- The built-in heating paddle and non-stick inner coating are designed to prevent burning or overheating.
- Keep out of reach of children.

## WHAT'S IN THE BOX

Your Spacekey Milk Frother package includes the following components:

- 1x Pitcher (Frother unit)
- 1x Power Supply Base
- 1x Spring Paddle (for frothing)
- 1x Cleaning Brush
- 1x User Manual



## SETUP

---

1. **Unpack:** Carefully remove all components from the packaging.
2. **Clean Before First Use:** Wash the interior of the frother pitcher and the spring paddle with warm, soapy water using the provided cleaning brush. Rinse thoroughly and dry completely. Do not immerse the power base in water.
3. **Assemble:** Place the spring paddle onto the shaft at the bottom of the frother pitcher. Ensure it is securely seated.
4. **Position:** Place the frother pitcher onto the power supply base.
5. **Connect Power:** Plug the power supply base into a standard electrical outlet.

# Reduce Effort

Bring **higher** productivity & **free** hands of long time handhold



Image: The frother unit placed on its power base, ready for use.

## OPERATING INSTRUCTIONS

The Spacekey Milk Frother offers 4 distinct functions, accessible via the control panel:

### Control Panel Overview:



# Silky & Velvety Foam

Indulge in pleasant with every sip



**Hot Dense  
Foam**



**Hot Airy  
Foam**



**Cold  
Foam**



**Milk  
Warm up**



Image: Close-up of the frother's control panel with illuminated icons for different functions.

- **Power Button (Bottom):** Press to turn on/off and cycle through modes.
- **Hot Dense Foam (Top Left):** Ideal for cappuccinos.
- **Hot Airy Foam (Top Right):** Perfect for lattes.
- **Milk Heating (Bottom Left):** For hot chocolate or warm milk.
- **Cold Foam (Bottom Right):** For iced coffee or other cold beverages.

## Steps for Use:

1. **Add Milk:** Pour milk into the frother pitcher. Observe the MAX and MIN fill lines indicated inside the pitcher.
  - For frothing (Hot Dense, Hot Airy, Cold Foam): Do not exceed the lower MAX line (approx. 150 ml / 5 oz).

- For heating (Milk Heating): Do not exceed the upper MAX line (approx. 300 ml / 10.1 oz).
2. **Select Function:** Place the lid on the frother. Press the Power Button repeatedly to cycle through the available modes until the desired function's icon illuminates.
  3. **Start Operation:** The frother will automatically begin operation once a mode is selected. It will automatically shut off when the process is complete (typically 1-2 minutes).
  4. **Mute Mode:** To activate "Mute" mode (silent operation), press and hold the power button for 3 seconds. Repeat to turn sounds back on.
  5. **Serve:** Carefully remove the lid and pour the frothed or heated milk into your beverage.

Your browser does not support the video tag.

Video: Demonstration of the Spacekey Milk Frother's 4-in-1 functions, including mute mode and milk preparation.

## MAINTENANCE AND CLEANING

Proper cleaning ensures the longevity and optimal performance of your Spacekey Milk Frother.

1. **Unplug:** Always unplug the power base from the electrical outlet before cleaning.
2. **Remove Paddle:** Carefully remove the spring paddle from the bottom of the frother pitcher.
3. **Hand Wash Pitcher:** Wash the interior of the frother pitcher and the spring paddle with warm, soapy water using the provided cleaning brush. The non-stick interior coating makes cleaning easy.
4. **Rinse and Dry:** Rinse all washed parts thoroughly with clean water and dry completely with a soft cloth.
5. **Clean Exterior:** Wipe the exterior of the frother pitcher and the power base with a damp cloth.
6. **Important:**
  - **Do Not Immerse the Power Base in Water.**
  - **Do Not Rinse the Pitcher Bottom and Control Panel directly under water.**
  - **The frother is Not Dishwasher Safe.**



Image: Visual guide for cleaning the frother, showing hand washing and areas to avoid immersing in water.

## TROUBLESHOOTING

If you encounter issues with your Spacekey Milk Frother, consider the following tips:

- **Poor Foaming:**
  - Ensure you are using fresh whole milk (fat content >3%). Some milk alternatives (e.g., almond, oat milk) may not foam as effectively.
  - Cold milk generally produces better foam.
  - Do not re-froth milk that has already been frothed.
  - Check that the spring paddle is correctly installed.
- **Milk Burnt On:**
  - Clean the frother immediately after each use to prevent milk residue from drying and burning onto the non-stick surface.
  - Ensure milk levels are within the MAX/MIN lines.
- **Frother Not Starting:**
  - Ensure the power base is securely plugged into a working outlet.
  - Ensure the frother pitcher is correctly seated on the power base.
  - Press the power button firmly to select a function.

For further assistance, refer to the user manual or contact customer support.

SPECIFICATIONS

Brand	Spacekey
Model Name	JY-MF01
Special Features	Auto Shut-Off, Detachable Base, Non-Stick, Quiet Function, Variable Froth Setting
Color	Blue
Material	Plastic, Stainless Steel
Product Dimensions	4.2"W x 8"H
Capacity	300 Milliliters (10.1 oz) for heating, 150 Milliliters (5 oz) for frothing
Item Weight	1.5 Pounds
Power Source	Corded Electric

WARRANTY AND SUPPORT

Spacekey is committed to customer satisfaction. The product comes with:





- Lifelong technical consultation.
- 24-hour quality service.
- 2 Years No Cost Replace.
- 30 Day Free Returns.

For any questions or concerns, please do not hesitate to reach out to Spacekey customer service.



Image: Graphic detailing customer service, replacement, returns, and technical support.

Related Documents - JY-MF01

	<p><a href="#">GRICAFE Milk Frother Operation Tips and Instructions</a></p> <p>Detailed operation tips for the GRICAFE Milk Frother, covering correct battery installation, button usage, troubleshooting speed issues, battery removal methods, and power source requirements. Essential guide for optimal use.</p>
	<p><a href="#">ProBreeze PB-MF01 Automatic Milk Frother Instruction Manual</a></p> <p>Detailed instruction manual for the ProBreeze PB-MF01 Automatic Milk Frother, covering safety, specifications, getting started, cleaning, storage, and recycling.</p>

