

[Manuals.plus](#) /

› [Fanttik](#) /

› Fanttik B10 Pro Max Electric Air Duster & S1 Pro 3.7V Electric Screwdriver User Manual

Fanttik B10 Pro Max & S1 Pro

Fanttik B10 Pro Max Electric Air Duster & S1 Pro 3.7V Electric Screwdriver User Manual

Model: B10 Pro Max (Air Duster) & S1 Pro (Electric Screwdriver)

Brand: Fanttik

1. INTRODUCTION

Thank you for choosing the Fanttik B10 Pro Max Electric Air Duster and S1 Pro 3.7V Electric Screwdriver. This comprehensive manual provides detailed instructions for the safe and efficient use, setup, operation, and maintenance of both devices. Please read this manual thoroughly before use and retain it for future reference.



This image displays the Fanttik B10 Pro Max Electric Air Duster and the Fanttik S1 Pro Electric Screwdriver. The air duster is compact and grey, while the screwdriver is cylindrical and dark grey with yellow branding.

2. SAFETY INFORMATION

To ensure safe operation and prevent damage, please observe the following safety precautions:

- Keep both devices away from water and other liquids.
- Do not operate the devices in explosive atmospheres, such as in the presence of flammable liquids, gases, or dust.
- Store devices out of reach of children.
- Do not attempt to disassemble, repair, or modify the devices. Contact authorized service personnel for assistance.
- Use only the charging cable provided or a certified Type-C cable with appropriate voltage (5V/2A) for charging.
- Avoid pointing the air duster directly at people or animals.
- Ensure the screwdriver bits are securely inserted before operation.
- Do not over-tighten screws with the electric screwdriver; use appropriate torque settings.

3. PACKAGE CONTENTS

Verify that all items are present in your package:

- Fanttik B10 Pro Max Electric Air Duster
- Fanttik S1 Pro 3.7V Electric Screwdriver
- Various Nozzles for Air Duster (Short, Long, Round, Slim)
- 16-piece S2 Steel Bit Set for Screwdriver
- Type-C Charging Cable
- User Manual

4. PRODUCT OVERVIEW

4.1. Fanttik B10 Pro Max Electric Air Duster

The B10 Pro Max is a compact, powerful electric air duster designed for efficient cleaning of electronics and various surfaces.

POWERFUL PERFORMANCE



Brushless
Motor



130000
RPM



65m/s
Wind Speed



An exploded view of the Fanttik B10 Pro Max Electric Air Duster, illustrating its internal brushless motor, 130,000 RPM capability, and 65 m/s wind speed for powerful cleaning performance.

- **Brushless Motor:** Provides high performance and durability.
- **6 Speed Levels:** Adjustable airflow from gentle dusting to high-speed cleaning.
- **Interchangeable Nozzles:** Designed for various applications (e.g., short, long, round, slim).
- **Type-C Charging Port:** For convenient recharging.

LONG-LASTING BATTERY



This image highlights the long-lasting battery of the Fanttik B10 Pro Max Electric Air Duster, featuring two 4000 mAh lithium batteries, 5V/2A Type-C charging, and up to 210 minutes of runtime. A note indicates the blower function cannot be used while charging.

4.2. Fanttik S1 Pro 3.7V Electric Screwdriver

The S1 Pro is a versatile electric screwdriver with adjustable torque settings, suitable for precision tasks and general assembly.

TOP-NOTCH PERFORMANCE



reddot winner 2024

Maximum
Electric Torque

6.0 N.m

Minimum
Electric Torque

1.5 N.m



*Precise torque gear, when the built-in smart chip recognizes that the torque reaches a fixed value, the machine will disengage immediately to prevent damage to precision instruments or fragile materials caused by excessive screw tightening.

The Fanttik S1 Pro Electric Screwdriver's top-notch performance is depicted, highlighting its adjustable electric torque range from a minimum of 1.5 N.m to a maximum of 6.0 N.m. A note explains the precise torque gear disengages to prevent damage.

- **Magnastrom Motor:** Delivers reliable power for various tasks.
- **3 Torque Settings:** Adjustable electric torque (1.5, 3, 4.2 N.m) with a maximum hard torque of 6 N.m and 8 N.m manual torque.
- **Magnetic Design:** Securely holds bits and collects screws.
- **16-in-1 Metal Bits:** A comprehensive set of S2 hardened steel bits for diverse applications.

RELIABLE MAGNETIC DESIGN



reddot winner 2024



The reliable magnetic design of the Fanttik S1 Pro Electric Screwdriver is shown, featuring a magnetic bit holder and the ability to magnetically collect screws, enhancing convenience during use.

5. SETUP

5.1. Initial Charging



Before first use, fully charge both the Air Duster and the Electric Screwdriver.

1. Connect the provided Type-C charging cable to the charging port on each device.
2. Plug the other end of the cable into a compatible 5V/2A USB power adapter (not included).
3. The charging indicator will show the charging status. Once fully charged, disconnect the cable.

5.2. Fanttik B10 Pro Max Air Duster Nozzle Attachment

Select the appropriate nozzle for your cleaning task and attach it firmly to the air outlet of the duster.

WIDE APPLICATION



The Fanttik B10 Pro Max Electric Air Duster is shown with different nozzles for wide applications: a short nozzle for car interiors, a long

nozzle for desk setups, a round nozzle for air beds, and a slim nozzle for swimming rings.

5.3. Fanttik S1 Pro Screwdriver Bit Installation

Choose the required bit from the 16-piece set and insert it into the magnetic bit holder of the screwdriver until it clicks into place.

16 PCS S2 STEEL BITS

2" Bits Fit for 1/4" Hex Shank


⊕ PH0/PH1/PH2

⊖ SL3.0 / SL4.0 / SL5.0

⊛ TR10 / TR15 / TR20 / TR25

○ S1.0 / S2.0

○ H3.0 / H4.0 / H5.0 / H6.0



A comprehensive set of 16 S2 steel bits is displayed, designed to fit the 1/4" hex shank of the Fanttik S1 Pro Electric Screwdriver. The bits include various types such as PH0/PH1/PH2, SL3.0/SL4.0/SL5.0, TR10/TR15/TR20/TR25, S1.0/S2.0, and H3.0/H4.0/H5.0/H6.0.

6. OPERATING INSTRUCTIONS

6.1. Fanttik B10 Pro Max Electric Air Duster

1. **Power On/Off:** Press and hold the power button to turn the duster on or off.
2. **Adjust Speed:** Briefly press the power button to cycle through the 6 speed levels (30,000 RPM to 130,000 RPM). Select the appropriate speed for your task.
3. **Usage:** Point the attached nozzle towards the area to be cleaned and activate the duster.



This image illustrates the 6-gear high-speed wind settings of the Fanttik B10 Pro Max Electric Air Duster, ranging from 30,000 RPM to a maximum of 130,000 RPM, suitable for various cleaning tasks.


6.2. Fanttik S1 Pro 3.7V Electric Screwdriver

1. **Power On/Off:** The screwdriver typically activates upon pressing the forward or reverse button.
2. **Select Torque:** Rotate the torque adjustment ring to select one of the three electric torque settings: 1.5 N.m, 3.0 N.m, or 4.2 N.m.
3. **Forward/Reverse:** Press the appropriate button for tightening (forward) or loosening (reverse) screws.
4. **Manual Mode:** For higher torque requirements, the screwdriver can be used manually up to 8 N.m.

THREE TORQUE LEVEL



red dot winner 2024



This image demonstrates the three torque levels of the Fanttik S1 Pro Electric Screwdriver (1.5 N.m, 3.0 N.m, and 4.2 N.m, with a max of 6 N.m) being applied to different assembly and repair tasks, such as computer and furniture work.

7. MAINTENANCE

7.1. Cleaning

- Ensure both devices are powered off and disconnected from charging before cleaning.

- Wipe the exterior of the devices with a soft, dry cloth.
- Do not use abrasive cleaners, solvents, or immerse the devices in water.
- For the air duster, ensure the air intake and outlet are free from obstructions.

7.2. Storage

- Store the devices in a cool, dry place, away from direct sunlight and extreme temperatures.
- Keep the nozzles and screwdriver bits organized to prevent loss.
- For prolonged storage, charge the devices periodically to maintain battery health.

8. TROUBLESHOOTING

If you encounter issues, refer to the following common problems and solutions:

- **Device not turning on:** Ensure the device is fully charged. Check the power button for proper engagement.
- **Low power/performance:** Recharge the device. Ensure no obstructions are blocking the air duster's intake/outlet or the screwdriver bit's rotation.
- **Air duster not blowing strongly:** Check for blockages in the nozzle or air intake. Ensure the battery is adequately charged.
- **Screwdriver not turning:** Verify the bit is correctly inserted. Ensure the torque setting is appropriate for the task. Check battery level.
- **Charging issues:** Ensure the Type-C cable and power adapter are functioning correctly. Try a different cable or adapter.

If the problem persists, please contact Fanttik customer support for further assistance.

9. SPECIFICATIONS

9.1. Fanttik B10 Pro Max Electric Air Duster

Feature	Specification
Motor	Brushless Motor
Max RPM	130,000 RPM
Wind Speed	Up to 65 m/s
Battery Capacity	2 x 4000 mAh Lithium Batteries
Run Time	Up to 210 minutes (on lowest setting)
Charging Port	Type-C (5V/2A)
Dimensions	5.6 × 3.0 × 1.6 inches

9.2. Fanttik S1 Pro 3.7V Electric Screwdriver

Feature	Specification
Motor	Magnastrom Motor (220 RPM)
Electric Torque Settings	1.5 N.m, 3.0 N.m, 4.2 N.m
Max Hard Torque	6 N.m

Feature	Specification
Manual Torque	8 N.m
Bits Material	S2 Hardened Steel
Number of Bits	16 pieces (1/4" Hex Shank)

10. WARRANTY AND SUPPORT

Fanttik products are designed and manufactured to the highest quality standards. For information regarding warranty coverage, technical support, or service inquiries, please refer to the warranty card included with your product or visit the official Fanttik website. Please have your product model and purchase date available when contacting support.

© 2025 Fanttik. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question