

[Manuals.plus](#) /

› [RALGEND](#) /

› RALGEND 75-inch L-Shaped Computer Desk with LED Light & Power Outlets Instruction Manual

RALGEND 6201DNUDBB

RALGEND 75-inch L-Shaped Computer Desk with LED Light & Power Outlets Instruction Manual

Model: 6201DNUDBB

INTRODUCTION

This manual provides detailed instructions for the assembly, operation, and maintenance of your RALGEND 75-inch L-Shaped Computer Desk. Please read this manual thoroughly before assembly and use to ensure proper function and longevity of your product. Keep this manual for future reference.

IMPORTANT SAFETY INFORMATION

Please read and follow all safety instructions carefully to prevent injury or damage to the product.

- Follow the assembly steps outlined in the instruction manual provided with the product packaging.
- Before use, secure the desk to the wall with the included anti-tip kit to prevent accidental tipping.
- Keep the computer desk away from water and fire sources to prevent damage and ensure safety.
- Do not overload shelves or drawers beyond their stated weight capacity.
- Ensure all connections for electrical components (LED lights, power outlets) are secure and correctly installed.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- L-Shaped Desk Frame (Metal)
- Desktop Panels (Engineered Wood)
- 5-Tier Storage Shelves
- 4 Fabric Drawers
- Monitor Stand
- Printer Stand
- Headphone Hooks
- Built-in Power Outlet Unit (3 AC outlets, 2 USB ports)
- RGB LED Strip with Remote Control

- Assembly Hardware (screws, bolts, etc.)
- Anti-Tip Kit
- Assembly Tools (e.g., Allen wrench, screwdriver)
- Instruction Manual (this document)

SPECIFICATIONS

Feature	Detail
Brand	RALGEND
Model Number	6201DNUDBB
Product Dimensions (D x W x H)	47.2" x 72.8" x 60.2" (120cm x 185cm x 153cm)
Color	Black
Material	Engineered Wood (Desktop), Metal (Frame)
Number of Shelves	5
Number of Drawers	4 (Fabric)
Power Outlet	3 AC Outlets (125V/12A), 2 USB Ports (5V/2A)
Power Cord Length	4.9 feet
LED Light Strip	RGB, 20 Colors, 21 Dynamic Modes, 8 Brightness Levels
Assembly Required	Yes (All tools included)

For detailed dimensions, refer to the product size diagram below.

PRODUCT SIZE




Figure 1: Detailed product dimensions and drawer sizes.

ASSEMBLY INSTRUCTIONS

Your RALGEND L-Shaped Computer Desk requires assembly. A detailed assembly guide, all necessary tools, and clearly labeled parts are provided in the product packaging. Please follow the step-by-step instructions carefully.

- Unpack and Identify Parts:** Lay out all components and hardware. Compare them against the parts list in your included assembly manual.
- Assemble the Frame:** Begin by connecting the metal frame components as instructed. Ensure all screws are tightened securely but do not overtighten until the entire frame is assembled.
- Attach Desktop Panels:** Secure the engineered wood desktop panels to the assembled frame.
- Install Shelves and Drawers:** Integrate the 5-tier shelves and install the 4 fabric drawers into their designated compartments.
- Mount Monitor Stand and Accessories:** Attach the monitor stand, printer stand, and headphone hooks as shown in the diagrams.

6. **Install Power Outlet and LED Lighting:** Secure the built-in power outlet unit and attach the RGB LED strip.
7. **Final Tightening and Anti-Tip Kit:** Once all components are in place, go back and securely tighten all screws. Finally, install the anti-tip kit to anchor the desk to a wall for stability.

For a visual overview of the desk's features and components, please watch the video below:

Your browser does not support the video tag.

Video 1: Overview of the RALGEND 75-inch L-Shaped Computer Desk features and design.



Figure 2: Fully assembled RALGEND L-Shaped Computer Desk, showcasing its layout and features.

OPERATING INSTRUCTIONS

1. Using the Built-in Power Outlets

The desk is equipped with a convenient power outlet unit to power your devices directly from your workspace.

- **AC Outlets:** Plug your computer, monitor, or other AC-powered devices into the 3 standard 125V/12A AC outlets.

- **USB Ports:** Use the 2 USB ports (5V/2A) to charge smartphones, tablets, or other USB-powered accessories.

Ensure the desk's main power cord is securely plugged into a wall outlet.



-3 AC Outlets-
125V/12A



-2 USB Ports-
5V/2A



-Power Cord-
4.9-Foot

Figure 3: Built-in power outlet with 3 AC outlets and 2 USB ports for convenient device charging.

2. Controlling the LED Light Strip

The integrated RGB LED strip allows you to customize the ambiance of your workspace.

- **Power On/Off:** Use the provided remote control to turn the LED strip on or off.
- **Color Selection:** Choose from 20 different colors to match your preference or mood.
- **Dynamic Modes:** Select from 21 dynamic lighting modes for various effects.
- **Brightness Adjustment:** Adjust the light intensity using the 8 brightness levels available on the remote.



Figure 4: RGB LED light strip features, including color options, modes, and brightness levels.

3. Utilizing Storage and Ergonomic Features

The desk is designed with multiple storage solutions and ergonomic considerations.

- **Monitor Stand:** The elevated monitor stand helps promote a correct posture and reduces neck and spine strain. Place your monitors directly on the stand.
- **Storage Shelves:** Use the 5-tier shelves for books, decor, or other office supplies.
- **Fabric Drawers:** The 4 fabric drawers provide enclosed storage for documents, stationery, and personal items. The dedicated file drawers are suitable for A4/letter-size documents.
- **Pegboard:** The 45.5-inch pegboard allows for customizable organization of accessories like headphones, controllers, or small tools using compatible hooks (not included unless specified in package contents).



Ergonomic Monitor Stand

Promotes proper posture, neck-friendly design, and optimized space utilization.




Figure 5: The ergonomic monitor stand helps maintain proper posture while working.

- **45.5" Pegboard** - unleash your creativity to DIY your work or gaming zone.
- **5 Multi-Sized Storage Compartments**- meet various organizational needs.



Figure 6: The 45.5-inch pegboard and various storage compartments offer versatile organization.

DIVERSE STORAGE OPTIONS



1 Open Compartment

2 Drawers

2-Tier Open Shelving



Printer Stand

File Drawer

Large Drawers



Figure 7: Fabric drawers provide enclosed storage for files and other items.

MAINTENANCE

Regular maintenance will help preserve the appearance and functionality of your desk.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that could damage the finish.
- **Dusting:** Regularly dust all surfaces, including shelves and the pegboard, to prevent buildup.
- **Hardware Check:** Periodically check all screws and bolts to ensure they remain tight. Retighten if necessary to maintain stability.
- **Electrical Components:** Ensure the power outlet unit and LED strip are free from dust and debris. Do not attempt to repair electrical components yourself; contact a qualified technician if issues arise.
- **Fabric Drawers:** Spot clean fabric drawers with a mild detergent and damp cloth. Allow to air dry completely.

TROUBLESHOOTING

If you encounter issues with your RALGEND L-Shaped Computer Desk, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Desk is wobbly or unstable.	Loose screws or uneven floor.	Ensure all assembly screws are tightened. Adjust leveling feet if present, or place shims under legs on uneven surfaces. Verify anti-tip kit is installed correctly.
LED light strip is not working.	Power connection issue, remote control battery, or faulty strip.	Check if the LED strip is properly connected to its power source and the desk's main power. Replace remote control batteries. If issues persist, contact customer support.
Power outlets/USB ports are not functioning.	Desk's main power cord unplugged, circuit breaker tripped, or faulty unit.	Ensure the desk's main power cord is securely plugged into a working wall outlet. Check your home's circuit breaker. Test with another device. If still not working, contact customer support.
Drawers do not slide smoothly.	Obstruction or improper installation.	Check for any items obstructing the drawer's path. Ensure drawers are inserted correctly and not overloaded.

WARRANTY AND CUSTOMER SUPPORT

For warranty information, please refer to the documentation included with your purchase or visit the official RALGEND website. If you require assistance with assembly, missing parts, or troubleshooting that is not covered in this manual, please contact RALGEND customer support through their official channels or the retailer where the product was purchased.

RALGEND Official Store: [Visit RALGEND Store on Amazon](#)

© 2025 RALGEND. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FMK4J1V2>

More documents and user manuals: <https://manuals.plus/>