

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [Fanttik](#) /
- › [Fanttik Slim V10 Lite Cordless Handheld Vacuum Instruction Manual](#)

## Fanttik Slim V10 Lite

# Fanttik Slim V10 Lite Cordless Handheld Vacuum Instruction Manual

Model: Slim V10 Lite

<a href="#">Introduction</a>	<a href="#">What's in the Box</a>	<a href="#">Setup</a>	<a href="#">Operating Instructions</a>	<a href="#">Maintenance</a>	<a href="#">Specifications</a>
		<a href="#">Troubleshooting</a>	<a href="#">Warranty &amp; Support</a>		

## 1. INTRODUCTION

---

The Fanttik Slim V10 Lite is a compact and portable cordless handheld vacuum designed for quick cleanups in various environments such as car interiors, kitchen tables, and keyboards. Its lightweight design, powerful brushless motor, and smart LED display make it an efficient tool for everyday messes.

This manual provides detailed instructions for the safe and effective use, maintenance, and troubleshooting of your Fanttik Slim V10 Lite vacuum cleaner. Please read it thoroughly before first use and retain it for future reference.

## 2. WHAT'S IN THE BOX

---

Carefully unpack all components and check against the list below. If any items are missing or damaged, please contact customer support.

- Fanttik Slim V10 Lite Handheld Vacuum
- Storage Base
- Crevice Nozzle
- Push-in Brush
- Cleaning Brush
- Type-C Charging Cable
- User Manual (this document)

# LIGHTWEIGHT DESIGN

easy to carry and use



0.98lb



Image: All components included in the Fanttik Slim V10 Lite package.

Video: An unboxing demonstration showing all items included with the Fanttik Slim V10 Lite vacuum cleaner.

## 3. SETUP

### 3.1 Initial Charging

Before first use, the lithium-ion battery must be fully charged. Connect the Type-C charging cable to the vacuum's charging port and a suitable USB power adapter (not included). The smart LED display will indicate charging status.

- Charging Time: Approximately 2.5-3 hours for a full charge.
- Ensure the device temperature is stable between 32°F (0°C) and 104°F (40°C) after full discharge in high speed before charging to prevent overheating.

## HOW TO CLEAN THE FILTERS



1 Unlock the dust cup latch



2 One click to dump the trash



3 Pull out the filter system



4 Clean the HEPA filter with cleaning brush



5 Wash the dust cup and filters



6 Dry the filters completely before use

Image: The vacuum being charged via its universal Type-C port, with the LED display showing charging progress.

Video: Demonstration of the LED display showing battery level and suction mode, including charging indication.

### 3.2 Assembling Attachments

The vacuum comes with a storage base that neatly holds the crevice nozzle and push-in brush. To attach an accessory, simply push it firmly onto the vacuum's suction opening until it clicks into place.



Image: The Fanttik Slim V10 Lite vacuum and its integrated storage base, designed for easy access to accessories.

Video: A demonstration of attaching and detaching the crevice nozzle and push-in brush to the Slim V10 Lite vacuum.

## 4. OPERATING INSTRUCTIONS

---

### 4.1 Power On/Off and Suction Modes

Press the power button to turn the vacuum on. The smart LED display will show the current battery level and suction mode. Press the power button again to cycle between Low (L) and High (H) suction modes. Press and hold the power button to turn the vacuum off.

- **Low Mode (L):** Provides 12AW suction (7kPa) for lighter debris, offering up to 30 minutes of runtime.
- **High Mode (H):** Provides 25AW suction (12kPa) for tougher messes, offering up to 15 minutes of runtime.

# SMART LED DISPLAY



Image: The smart LED display clearly indicating battery level and the two available suction modes.

## 4.2 Using Attachments

Select the appropriate attachment for your cleaning task:

- **Crevice Nozzle:** Ideal for reaching tight spaces, corners, and car crevices.
- **Push-in Brush:** Effective for dusting surfaces, cleaning keyboards, and removing pet hair from upholstery.



Image: The vacuum in use, demonstrating its versatility for cleaning different areas with its attachments.

Video: A user demonstrating the lightweight design and ease of operation of the Fanttik Slim V10 Lite vacuum for various cleaning tasks.

## 5. MAINTENANCE

---

Regular maintenance ensures optimal performance and extends the lifespan of your vacuum cleaner.

### 5.1 Emptying the Dust Cup

To empty the dust cup, locate the release latch and press it to open the dust cup. Dispose of the collected debris into a trash bin. The one-key empty design simplifies this process.

# ONE-KEY EMPTY



Image: The one-key empty feature in action, showing how to quickly dispose of collected debris.

## 5.2 Cleaning the Filters

The Fanttik Slim V10 Lite features washable HEPA filters for longer service life. After emptying the dust cup, pull out the filter system. Use the included cleaning brush to remove dust from the HEPA filter. Wash the dust cup and filters with water, then ensure they are completely dry before reassembling and using the vacuum.

# WHAT'S IN THE BOX?




Image: Visual instructions for disassembling, cleaning, and drying the vacuum's filters and dust cup.

## 6. SPECIFICATIONS

Feature	Detail
Brand	Fanttik
Model Name	Slim V10 Lite
Item Weight	0.98 lb (0.45 kg)
Item Dimensions (L x W x H)	12.8"L x 2.5"W x 2.1"H
Power Source	Battery Powered
Filter Type	HEPA Filter
Suction Power	12kPa (High Mode), 7kPa (Low Mode)
Dust Cup Capacity	120 Milliliters
Runtime	Up to 15 minutes (High Mode), Up to 30 minutes (Low Mode)
Charging Time	2.5-3 hours (Type-C)
Motor Type	Brushless Motor (70W)
Special Features	Compact, Cordless, Lightweight, Portable, Smart LED Display, All-in-One Storage Base

## 7. TROUBLESHOOTING

If you encounter issues with your Fanttik Slim V10 Lite, please refer to the following common solutions:

- **Vacuum not turning on:** Ensure the battery is fully charged. Connect the vacuum to the Type-C charger and check the LED indicator.
- **Reduced suction power:** Check if the dust cup is full and needs emptying. Inspect the filters for blockage and clean them as described in the Maintenance section. Ensure all attachments are securely fitted.

- **Short runtime:** The battery may not be fully charged. Ensure the vacuum is charged for the recommended 2.5-3 hours. Runtime varies by suction mode (15 mins on High, 30 mins on Low).
- **Overheating:** If the device feels excessively warm, turn it off and allow it to cool down. Ensure the device temperature is stable between 32°F (0°C) and 104°F (40°C) after full discharge in high speed before charging.

If the problem persists after trying these steps, please contact customer support.

## 8. WARRANTY & SUPPORT

---

Fanttik products are designed for quality and reliability. For warranty information, product registration, or technical support, please refer to the official Fanttik website or contact their customer service directly. Keep your purchase receipt as proof of purchase for warranty claims.