

Manuals.plus /

› ROMP /

› ROMP Spin Vibrator Sex Toy Instruction Manual

ROMP RPKS1SGZ

ROMP Spin Vibrator Sex Toy Instruction Manual

Model: RPKS1SGZ

INTRODUCTION

The ROMP Spin is a compact clitoral stimulator designed for personal pleasure. It features Pleasure Air Technology, multiple intensity levels, and a discreet, travel-friendly design. This manual provides essential information for the safe and effective use, care, and maintenance of your ROMP Spin device.

PRODUCT FEATURES

- **Pleasure Air Technology:** Provides gentle yet intense clitoral suction stimulation.
- **10 Intensity Levels & 3 Patterns:** Offers a wide range of customizable sensations.
- **Travel-Friendly Design:** Compact with a built-in case for discretion and protection.
- **Body-Safe Silicone Material:** Made from non-porous, hygienic, and skin-friendly silicone.
- **Rechargeable & IPX7 Water-Resistant:** Enjoy 45 minutes of continuous use on a full charge and easy cleaning.

PACKAGE CONTENTS

- 1 x ROMP Spin Vibrator
- 1 x USB Charging Cable
- 1 x User Manual (this document)

SAFETY INFORMATION

Please read all safety instructions before using the ROMP Spin. This device is intended for external clitoral stimulation only. Do not use if you have any medical conditions that may be aggravated by vibration or suction. Consult a healthcare professional if you have concerns. Discontinue use if irritation or discomfort occurs. Keep out of reach of children. The device is made from body-safe silicone. Clean thoroughly before and after each use.

GETTING STARTED (SETUP)

Initial Charge


Before first use, fully charge your ROMP Spin. Connect the USB charging cable to the charging port on the device and plug the other end into a USB power source. The indicator light will show charging status. A full charge typically takes approximately 2 hours and provides up to 45 minutes of use at the highest intensity.



The ROMP Spin device displayed alongside its retail packaging, illustrating the charging port location.

Preparation for Use

Ensure the device is clean before each use. For optimal comfort and sensation, it is recommended to apply a water-based lubricant to the stimulation head and the area of application.



Step 1: Apply water-based lubricant to the stimulation head for comfortable use.

OPERATION


Opening and Closing the Device

The ROMP Spin features a unique twist mechanism to open and close the device, protecting the stimulation head and ensuring discretion.

Your browser does not support the video tag.

Video demonstrating the 'spin to open' and 'spin to close' mechanism of the ROMP Spin device.

RO MP



An instructional diagram detailing the 'spin to open' and 'spin to close' mechanism, along with the 'On/Increase intensity' and 'Off/Decrease intensity' buttons and the stimulation head.



Step 2: Spin the cover around until it clicks into the open position.

Power On/Off and Intensity Control

- To turn on, hold the + button for 2 seconds.
- To increase intensity, press the + button. There are 10 intensity levels.
- To decrease intensity, press the - button.
- To cycle through 3 rhythmic patterns, press the + button after reaching the highest intensity level.
- To turn off, hold the - button for 2 seconds.

ROMP



Pleasure Air Technology



Travel size



10 intensity levels




USB rechargeable

The ROMP Spin device, featuring its ergonomic design, stimulation head, and control buttons.

Usage

Once the device is open and lubricated, place the stimulation head on the desired area. Adjust the intensity and pattern to your preference using the + and - buttons.



Step 3: Place the stimulation head on the desired area and adjust intensity using the control buttons.

MAINTENANCE AND CARE

Cleaning

The ROMP Spin is IPX7 water-resistant, making it easy to clean. After each use, wash the device with warm water and a mild, toy-friendly soap. Rinse thoroughly and allow it to air dry completely before storing.

ROMP



The ROMP Spin device shown partially submerged in water, emphasizing its IPX7 water-resistant design for easy cleaning.

Storage

Store your ROMP Spin in its closed, travel-friendly state in a clean, dry place away from direct sunlight and extreme temperatures. Avoid storing with other toys made of different materials to prevent material degradation.

TROUBLESHOOTING

- **Device not turning on:** Ensure the device is fully charged. Hold the+ button for 2 seconds to power on.
- **Device not charging:** Check if the USB cable is securely connected to both the device and the power source. Try a different USB port or adapter.
- **Weak sensation:** Ensure the stimulation head is properly positioned. Experiment with different intensity levels and patterns.
- **Device not closing properly:** Ensure the device is aligned correctly before spinning to close. Apply gentle pressure to engage the locking mechanism.

SPECIFICATIONS

Model Number	RPKS1SGZ
Dimensions (L x W x H)	4.92 x 3.98 x 2.36 inches
Weight	5.29 ounces
Material	Body-safe Silicone, Acrylonitrile Butadiene Styrene (ABS)
Battery	1 Nonstandard Battery (included), Rechargeable
Water Resistance	IPX7 (Waterproof)
Manufacturer	WOW Tech

WARRANTY AND SUPPORT

The ROMP Spin Vibrator comes with a **2-year warranty** from the date of purchase, covering manufacturing defects. Please retain your proof of purchase for warranty claims.

For technical support, warranty inquiries, or any questions regarding your ROMP Spin, please contact the manufacturer, WOW Tech, through their official support channels. Refer to the product packaging or the brand's official website for contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FMKJT68V>

More documents and user manuals: <https://manuals.plus/>