Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

onerbl A1362 ETOE-Seal-Pro

Onerbl AC-DC Adapter for ETOE A1362 ETOE-Seal-Pro Projector - User Manual

1. Introduction

Thank you for choosing the Onerbl AC-DC Adapter. This adapter is designed to provide reliable power to your compatible devices, specifically the ETOE A1362 and ETOE-Seal-Pro 1080P Google TV Projector. It converts standard AC wall power into the DC power required by your device, ensuring stable operation and efficient charging. This manual provides essential information for safe setup, operation, maintenance, and troubleshooting.

Product Compatibility: This AC-DC adapter is compatible with the ETOE A1362 ETOE-Seal-Pro 1080P Google TV Projector, Movie Projector, and Home Theater systems requiring 24VDC, 24volt, or 24.0 Volts switching power supply.

2. Safety Information

Please read and understand all safety instructions before using this product. Failure to follow these instructions may result in electric shock, fire, or damage to the product or connected devices.

- **Indoor Use Only:** This adapter is designed for indoor use. Do not expose it to rain, moisture, or extreme temperatures.
- **Proper Voltage:** Ensure the wall outlet voltage matches the input voltage specified on the adapter (110 Volts AC).
- **Avoid Overloading:** Do not overload the power outlet or extension cords.
- **Cable Care:** Do not place heavy objects on the power cord. Avoid bending, twisting, or pulling the cord excessively.
- **Ventilation:** Ensure adequate ventilation around the adapter. Do not cover it or place it in an enclosed space that could restrict airflow.
- **Disconnect When Not in Use:** Unplug the adapter from the power outlet when not in use for extended periods.
- **No User Serviceable Parts:** Do not attempt to open or repair the adapter. Refer all servicing to qualified personnel.
- **Protection Features:** This adapter includes Over Voltage Protection and Over Heat Protection for enhanced safety.

3. Product Overview

The Onerbl AC-DC Adapter is a compact and efficient power supply unit. Below are images illustrating its components and dimensions.



Figure 3.1: General view of the Onerbl AC-DC Adapter, showing the main power brick and connected cables.




Figure 3.2: Detailed dimensions of the AC-DC adapter, including the power brick (4.2 inches long, 1.8 inches wide), DC output cable (44.3 inches), and AC input cable (79.3 inches). The total cable length is approximately 127.8 inches.



Figure 3.3: The detachable AC power cord, featuring a standard two-prong plug for wall outlets and a C7 connector for the adapter's power brick.

4. Setup

4.1 Connecting the Adapter

1. **Connect AC Power Cord:** Insert the C7 connector end of the AC power cord into the corresponding port on the Onerbl AC-DC Adapter power brick.
2. **Connect DC Output:** Plug the barrel connector of the DC output cable into the power input port of your ETOE A1362 or ETOE-Seal-Pro Projector. Ensure a firm connection.
3. **Plug into Wall Outlet:** Insert the two-prong plug of the AC power cord into a standard 110V AC wall outlet.

Once connected, the adapter's indicator light (if present) may illuminate, signifying that power is being supplied.



Figure 4.1: The AC-DC adapter properly connected to a wall outlet and powering a device, indicated by a blue LED light on the adapter unit.

5. Operating Instructions

After successful setup, the Onerbl AC-DC Adapter will continuously supply power to your connected device. To operate

your projector:

- Ensure the adapter is securely plugged into both the wall outlet and your projector.
- Turn on your ETOE A1362 or ETOE-Seal-Pro Projector using its dedicated power button.
- The adapter will provide the necessary power for the projector's operation and battery charging (if applicable).

To power off your device, use the device's power button. To completely disconnect power from the adapter, unplug it from the wall outlet.

6. Maintenance

Proper maintenance ensures the longevity and optimal performance of your Onerbl AC-DC Adapter.

- **Cleaning:** Disconnect the adapter from all power sources before cleaning. Use a soft, dry cloth to wipe the exterior. Do not use liquid cleaners or aerosols.
- **Storage:** Store the adapter in a cool, dry place away from direct sunlight and extreme temperatures when not in use. Avoid tightly coiling the cables.
- **Inspection:** Periodically inspect the power cord and adapter for any signs of damage, such as frayed wires, cracks, or loose connections. If damage is found, discontinue use immediately and replace the adapter.

7. Troubleshooting

If you encounter issues with your Onerbl AC-DC Adapter, refer to the following table for common problems and solutions.

Problem	Possible Cause	Solution
Device not powering on.	Adapter not receiving power.	Ensure the AC power cord is securely plugged into both the wall outlet and the adapter. Test the wall outlet with another device.
Device not powering on.	DC output not connected properly.	Verify the barrel connector is fully inserted into the projector's power input.
Adapter feels excessively hot.	Poor ventilation or overload.	Ensure the adapter is in a well-ventilated area. Do not cover it. If the issue persists, disconnect and contact support.
Visible damage to cables or adapter.	Physical damage.	Discontinue use immediately. Replace the adapter.

If the problem persists after trying these solutions, please contact customer support.

8. Specifications

Technical specifications for the Onerbl AC-DC Adapter:

Feature	Specification
Brand	onerbl
Manufacturer	Shenzhen Waweis Technology Co., Ltd
Input Voltage	110 Volts (AC)

Feature	Specification
Output Voltage	24 Volts (DC)
Connector Type	Barrel Connector
Compatible Devices	ETOE A1362 ETOE-Seal-Pro 1080P Google TV Projector Movie Projector Home Theater
Special Feature	Short Circuit Protection, Over Voltage Protection, Over Heat Protection
Color	Black
Unit Count	1.0 Count

9. Warranty and Support

This Onerbl AC-DC Adapter is manufactured with high-quality materials and undergoes rigorous testing to ensure performance and reliability. While specific warranty details are not provided in this manual, most electronic products come with a standard manufacturer's warranty against defects in materials and workmanship.

For warranty claims, technical support, or further assistance, please refer to the retailer where you purchased the product or visit the official Onerbl website for contact information. Please have your product model number (A1362 ETOE-Seal-Pro compatible adapter) and purchase details ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FMN5LHSG

More documents and user manuals: **https://manuals.plus/**