

[Manuals.plus](#) /

> [ZOVIMAX](#) /

> ZOVIMAX L6 Pro Bone Conduction Headphones User Manual

ZOVIMAX L6 Pro

ZOVIMAX L6 Pro Bone Conduction Headphones User Manual

Model: L6 Pro | Brand: ZOVIMAX

INTRODUCTION

Thank you for choosing the ZOVIMAX L6 Pro Bone Conduction Headphones. These open-ear wireless headphones are designed to provide a comfortable and secure audio experience while keeping you aware of your surroundings. Featuring Bluetooth 6.0, dual drivers, an LED display, dual device connectivity, and a gaming mode, they are suitable for various activities including sports and daily use. Please read this manual carefully before using the product to ensure proper operation and to maximize your listening experience.



PACKAGE CONTENTS

Please check the package for the following items:

- Bone Conduction Headphones x1
- Magnetic Charging Cable x1
- User Manual x1
- Adjustable Silicone Strap x1



Cosa c'è nella confezione?

Cuffie a Conduzione Ossea x1
Cavo di Ricarica Magnetico x1
Manuale di Istruzioni x1
Cordino Regolabile in Silicone x1

Image: All items included in the ZOVIMAX L6 Pro package, neatly arranged.

PRODUCT OVERVIEW

The ZOVIMAX L6 Pro headphones feature an ergonomic design for comfort and stability, incorporating advanced bone conduction technology and intuitive controls.

Key Features:

- **Open-Ear Design:** Ensures situational awareness.
- **Dual Drivers:** Delivers clear and balanced sound with enhanced bass.
- **Bluetooth 6.0:** For stable and efficient wireless connection.
- **LED Display:** Shows battery status and connection information.
- **Dual Device Connection:** Connects to two devices simultaneously.
- **Gaming Mode:** Reduces audio latency for improved synchronization.
- **Dual Microphones with Noise Cancellation:** For clear calls.
- **IPX7 Waterproof:** Protection against sweat and rain.
- **Lightweight (28g):** Flexible titanium frame with silicone coating for comfort.

Game & Bluetooth 6.0 Dual Modes

More stable connection, lower latency, one-tap Game Mode for smoother audio-visual synchronization.



Image: An internal diagram highlighting the dual driver system and bone conduction components for clear audio.

Controls and LED Display:

The headphones feature easy-to-use physical buttons and an integrated LED display for status updates.

Dual Drivers Tech, Game-Changing Sound

Dual Drivers, Rich Detail

ZOVIMAX Dual Pitch



Bone conduction

Clear highs and natural mids




Image: The ZOVIMAX L6 Pro headphones displaying the LED screen and the location of control buttons.

Comandi con Pulsanti Facili da Usare

I pulsanti intuitivi consentono di controllare facilmente musica, volume e chiamate.



Pulsante Accensione:

Accensione / Spegnimento
Rispondere / Riagganciare / Rifiutare le chiamate
Riproduzione / Pausa
Modalità Gioco / Modalità Musica



Pulsanti Volume + / - :

Volume +/-
Brano Successivo / Brano Precedente




Image: A detailed diagram explaining the functions of the power button and volume buttons on the headphones.

- **Power Button:**

- Press and hold: Power On/Off
- Single press: Answer/End Call, Play/Pause Music
- Double press: Reject Call
- Triple press: Switch between Gaming Mode and Music Mode

- **Volume +/- Buttons:**

- Single press: Adjust Volume Up/Down
- Press and hold: Next Track (Volume +), Previous Track (Volume -)

- **LED Display:** Shows battery percentage and Bluetooth connection status.

WEARING INSTRUCTIONS

For optimal sound quality and comfort, ensure the headphones are worn correctly.



Image: A visual guide demonstrating the three steps to correctly wear the headphones for a secure and comfortable fit.

1. Place the headphones over your head, with the transducers resting on your cheekbones, just in front of your ears.
2. Adjust the comfort and stability by gently rotating the headphones.
3. Ensure a stable fit by adjusting the frame size with the adjustable band at the back.

SETUP

1. Charging the Headphones

Before first use, fully charge the headphones. The LED display will show the battery percentage.

- Connect the magnetic charging cable to the charging port on the headphones.
- Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
- A full charge takes approximately 2 hours and provides up to 12 hours of playback time at 60% volume.



Open-Ear Audio Experience

Enjoy your favorite music while staying aware of your surroundings, without missing a beat.

ZOVIMAX
Dual Drivers Sound

Enhanced bass and immersive surround sound for energized movement.



Image: A person hiking while wearing the headphones, illustrating the extended 12-hour battery life.

**Batteria a Lunga Durata
con Display LED**

2 → 12
Ore Ore

Una ricarica rapida di sole 2 ore offre fino a 12 ore di ascolto.



Image: Close-up of the headphones' LED display showing battery percentage and the magnetic charging connection.

2. Bluetooth Pairing

1. **Power On:** Press and hold the Power Button until the LED display lights up and indicates "Bluetooth" or a pairing mode.
2. **Activate Bluetooth:** On your device (smartphone, tablet, computer), enable Bluetooth.
3. **Select Device:** In your device's Bluetooth settings, look for "ZOVIMAX L6 Pro" in the list of available devices and select it.
4. **Confirmation:** Once connected, the LED display on the headphones will show a stable Bluetooth icon, and you may hear an audible confirmation.

OPERATING INSTRUCTIONS

Basic Music Controls

- **Play/Pause:** Press the Power Button once.
- **Volume Up/Down:** Press the Volume + or Volume - button once.
- **Next Track:** Press and hold the Volume + button.
- **Previous Track:** Press and hold the Volume - button.

Call Management

The dual noise-cancelling microphones ensure clear communication during calls.

Chiamate Vocali Cristalline

I due microfoni con cancellazione del rumore riducono i rumori di fondo per garantire chiamate chiare e affidabili ogni volta.




Image: A visual representation of the clear voice call technology, showing sound waves being processed for optimal clarity.

- **Answer/End Call:** Press the Power Button once.
- **Reject Call:** Double press the Power Button.

Dual Device Connection

The headphones can connect to two Bluetooth devices simultaneously, allowing for seamless switching between them.




Image: The headphones connected to both a smartphone and a laptop, demonstrating dual device connectivity.

1. Pair the headphones with the first device as described in the "Bluetooth Pairing" section.
2. Disable Bluetooth on the first device. The headphones will enter pairing mode again.
3. Pair the headphones with the second device.
4. Re-enable Bluetooth on the first device. The headphones should automatically connect to both devices.
5. Audio will play from the device that is actively sending a signal.

Gaming Mode

Activate Gaming Mode to reduce audio latency, providing better synchronization between sound and image, ideal for gaming, videos, and interactive workouts.



Feather-Light, All-Day Comfort

Soft silicone layer ensures a secure, non-slip fit for comfortable, stable wear during workouts.



Reduced
Vibration



-16%
16% Optimized
Squeeze



L6 Pro



Ultra-Light
28g Design

Image: A person enjoying a mobile game with the headphones, highlighting the low-latency gaming mode.

- **Activate Gaming Mode:** Triple press the Power Button. The headphones will indicate the mode change.
- **Exit Gaming Mode:** Triple press the Power Button again to return to Music Mode.

MAINTENANCE

Cleaning

- Wipe the headphones with a soft, damp cloth.
- Do not use abrasive cleaners or solvents.
- Ensure the charging port is dry before charging.

Water Resistance (IPX7)

The ZOVIMAX L6 Pro headphones are IPX7 rated, meaning they are protected against the effects of temporary immersion in water (up to 1 meter for 30 minutes). They are resistant to sweat and rain, making them suitable for active

use.

Extended Playtime

12H Music Time (60% volume)



Quick Charge



12Hrs Playtime



110Hrs Standby



Image: A person running in the rain while wearing the headphones, demonstrating their IPX7 water resistance.

Important:

- Do not intentionally submerge the headphones for extended periods or beyond the specified depth.
- Ensure the charging port is completely dry before connecting the charging cable to prevent damage.

Storage

- Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid placing heavy objects on the headphones.

TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Headphones do not power on.	Low battery.	Charge the headphones fully.
Cannot pair with device.	Bluetooth not enabled on device; headphones not in pairing mode; device too far.	Ensure Bluetooth is on, headphones are in pairing mode, and devices are within 10 meters. Try restarting both devices.
No sound or low volume.	Volume too low; headphones not connected; audio source issue.	Adjust volume on both headphones and device. Reconnect Bluetooth. Check audio source.
Sound quality is poor.	Interference; improper fit.	Move closer to the connected device. Adjust headphone position on cheekbones.
Calls are unclear.	Microphone obstructed; environmental noise.	Ensure microphones are clear. Move to a quieter environment.

SPECIFICATIONS

Feature	Detail
Brand	ZOVIMAX
Model Name	L6 Pro
Connectivity Technology	Wireless (Bluetooth 6.0)
Form Factor	Neckband
Water Resistance	IPX7
Playtime	Up to 12 hours (at 60% volume)
Charging Time	Approx. 2 hours
Weight	28g
Microphones	Dual, with noise cancellation
Special Features	Open-Ear Design, Dual Drivers, LED Display, Dual Device Connection, Gaming Mode

WARRANTY AND SUPPORT

Warranty Information

The ZOVIMAX L6 Pro Bone Conduction Headphones come with a **2-year product warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the product meets its specified performance standards under normal use. Please retain your proof of purchase for warranty claims.

Customer Support

For any questions, technical assistance, or warranty claims, please contact ZOVIMAX customer support through the retailer where you purchased the product or visit the official ZOVIMAX website for contact information.

SAFETY INFORMATION

- Do not disassemble, repair, or modify the product.
- Keep the product away from extreme temperatures, humidity, and corrosive substances.
- Avoid listening at high volumes for extended periods to prevent hearing damage.
- Use caution when using headphones in situations requiring awareness of your surroundings, such as driving or cycling, even with the open-ear design.
- Keep out of reach of children and pets.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question