



Manuals.plus /

› Yusuuo /

› Yusuuo P05 Instant Print Camera for Kids Instruction Manual

## Yusuuo P05

# Yusuuo P05 Instant Print Camera for Kids Instruction Manual

Model: P05 | Brand: Yusuuo

## 1. INTRODUCTION

---

Thank you for choosing the Yusuuo P05 Instant Print Camera for Kids. This camera is designed to provide an engaging and creative experience, allowing children to capture moments and print them instantly. It features a large screen, 1080P video recording, various filters and stickers, and a durable, inkless printing mechanism. Please read this manual carefully to ensure proper use and maintenance of your device.



Image 1.1: Yusuuo P05 Instant Print Camera with included paper rolls, SD card, lanyard, and charging cable.

## 2. WHAT'S IN THE BOX

- 1 x Yusuuo P05 Instant Print Camera
- 3 x Print Paper Rolls (for approximately 372 prints)
- 1 x User Manual
- 1 x 32GB SD Card
- 1 x Lanyard
- 1 x Type-C Charging Cable

## 3. PRODUCT OVERVIEW

The Yusuuo P05 camera combines multiple functions to enhance the user experience:

- **Instant Printing:** Prints black and white photos instantly without ink. Color copies are saved digitally.
- **High-Resolution Capture:** Supports 1080P video recording and high-quality digital photos.

- **Creative Features:** Includes 15 filters and 16 stickers to personalize photos.
- **Entertainment:** Features built-in games and music playback (MP3s must be loaded onto the SD card).
- **Durable Design:** Made from soft, kid-safe, shockproof materials.
- **Long Battery Life:** Fast-charging with approximately 3 hours of continuous use.



Image 3.1: Visual representation of the camera's multi-functional capabilities.

## 4. SETUP

### 4.1 Charging the Camera

Before first use, fully charge the camera using the provided Type-C charging cable. Connect the cable to the camera's charging port and a compatible USB power source. The charging indicator light will show the charging status.

### 4.2 Installing the SD Card

The camera comes with a 32GB SD card for storing photos and videos. Locate the SD card slot on the side of the camera and gently insert the card until it clicks into place. Ensure the card is inserted correctly to avoid damage.

### 4.3 Loading Print Paper

The camera uses thermal paper for instant prints. Follow these steps to load a new paper roll:

1. Push up the part with the lens to open the paper slot.
2. Insert the printing paper roll in the correct direction. Ensure the paper feeds from the bottom of the roll.
3. Pull the paper out by approximately 1 inch before closing the two parts of the camera.
4. Close the camera securely. If prints are blank, rotate the paper roll 180 degrees and re-install.



Image 4.1: Step-by-step guide for installing the thermal paper roll.

## 5. OPERATING INSTRUCTIONS

### 5.1 Power On/Off

Press and hold the power button (usually marked with a power symbol) to turn the camera on or off.

### 5.2 Navigation

Use the directional buttons (up/down/left/right) to navigate through the menu options on the screen. Press the 'OK' button to select an option.

### 5.3 Taking Photos

Select the 'Photo' icon from the main menu. Frame your shot using the screen. Press the shutter button (often a dedicated button or the 'OK' button) to capture the image. The camera supports digital zoom and

has a built-in flash.

## 5.4 Recording Videos

Select the 'Video' icon from the main menu. Press the shutter button to start recording and press it again to stop. Videos are recorded in 1080P resolution.

## 5.5 Instant Printing

After taking a photo, you can choose to print it instantly. The camera prints in black and white. Color versions of photos are saved to the SD card. There are typically two printing modes: one that prints immediately after each photo, and another that allows you to select photos from the gallery to print.



Image 5.1: Instant photo printing and digital storage capabilities.

## 5.6 Filters and Stickers

Access the 'Filters' or 'Stickers' option in the menu to apply various creative effects to your photos before or after capturing them. The camera offers 15 filters and 16 stickers.

## 5.7 Playback and Gallery

Select the 'Playback' or 'Photos' icon to view your captured images and videos. Use the directional buttons to browse through your media.

## 5.8 Games and Music

The camera includes built-in games for entertainment. For music playback, ensure MP3 files are loaded onto the SD card. Select the 'Music' icon to access the player.

## 6. MEDIA INTEGRATION

### 6.1 Product Images

Below are additional images illustrating the camera's features and usage.

**Ultra HD 1080p Video**  
VideoRecord the wonderful childhood

00:02:00

REC

Instant Cameras

16X POWERFUL ZOOM  
HIGH DEFINITION CAMERA 2.4

4X 16X 8X

Image 6.1: The camera's 1080P video recording and 16X digital zoom functions.

# Safe & Cost-Effective

Take as many funny pictures as you want!

Our



- ✓ \$0.08 per paper
- ✓ 124 photos a Roll
- ✓ Clear Pictures
- ✓ Friendly material to store

Others



- ✗ So.9 per paper
- ✗ 20Inch IPS Screen
- ✗ 20 sheets a pack

Others



- ✗ Blurry images
- ✗ \$0.3 per paper
- ✗ 60 papers a roll
- ✗ Toxic paper and smelly

Image 6.2: Details on the cost-effectiveness and safety of the camera's inkless printing.

## 6.2 Official Product Videos

Watch these videos for a visual guide on setting up and using your Yusuuo P05 camera.

Your browser does not support the video tag.

Video 6.1: An overview of the instant printing camera, including unboxing and basic functions.

Your browser does not support the video tag.

Video 6.2: A detailed demonstration of the camera's features and printing process.

Your browser does not support the video tag.

Video 6.3: Highlighting the ease of use and quality of prints from the camera.

## 7. MAINTENANCE

- Keep the camera clean by wiping it with a soft, dry cloth.
- Avoid exposing the camera to extreme temperatures, direct sunlight, or moisture.
- Store unused paper rolls in a cool, dry place away from light.

## 8. TROUBLESHOOTING

- **Blank Prints:** Ensure the paper roll is inserted correctly with the printable side facing the print head. Try rotating the roll 180 degrees.
- **No Power:** Check if the battery is charged. Connect the camera to the charger and allow it to charge fully.
- **Camera Freezes:** Try turning the camera off and then on again. If the issue persists, contact customer support.
- **Poor Print Quality:** Ensure the paper roll is fresh and correctly installed.

## 9. SPECIFICATIONS

<b>Model Name</b>	P05
<b>Brand</b>	Yusuuo
<b>Item Weight</b>	13.9 ounces (0.4 Kilograms)
<b>Package Dimensions</b>	5.35 x 5.16 x 2.52 inches
<b>Batteries</b>	1 Lithium Ion battery (included)
<b>Film Format Type</b>	Instant (Thermal)
<b>Film Color</b>	Black and White
<b>Special Features</b>	1-Second Magic Camera, Creative Filters & Stickers, Safe & No-Mess Printing
<b>Manufacturer</b>	Shenzhen Yue Wu Tao Technology Co.,LTD
<b>UPC</b>	762744310585

## 10. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided by your retailer or visit the official Yusuuo website. Keep your proof of purchase for any warranty claims.