



RF3407

Generic RF3407 Replacement Remote Control User Manual

For S-Cape 300/500/700 1.0/+ and Prodigy 2/Comfort Elite Adjustable Bases

1. INTRODUCTION

This manual provides essential information for the proper setup and operation of your Generic RF3407 replacement remote control. This remote is designed for specific adjustable bed bases, including S-Cape 300/500/700 1.0/+ and Prodigy 2/Comfort Elite models.

Important Compatibility Note: This remote is model-specific. If your original remote control had a different appearance, or if you cannot match it with your existing remote or owner's manual, this replacement remote may not be compatible with your adjustable base. This replacement remote does not provide access to preset positions or traditional massage buttons. However, it offers a basic massage function as described in the operating instructions.

2. WHAT'S IN THE BOX

- Generic RF3407 Replacement Remote Control
- Pairing Steps (included with the remote)

3. SETUP AND PAIRING

To ensure proper functionality, the replacement remote control must be paired with your adjustable bed base. Detailed pairing instructions are provided on a separate sheet included with your remote control. Please refer to those instructions for the specific steps required to pair your RF3407 remote.



Figure 1: Generic RF3407 Replacement Remote Control. This image displays the overall design of the remote, featuring a black and white body with clearly labeled buttons.

4. OPERATING INSTRUCTIONS

The RF3407 remote control provides basic control over your adjustable bed base. It features three primary buttons for operation.



Figure 2: Close-up view of the RF3407 remote control buttons, showing the directional controls and central function buttons.

Basic Massage Function

While this remote does not have dedicated preset or traditional massage buttons, it offers a basic massage control:

- To activate or deactivate the massage function, **press and hold the left and right buttons simultaneously**. This action will toggle all massage functions on or off.

Adjusting Bed Position

Use the directional buttons (up/down arrows) to adjust the head and foot sections of your adjustable bed base. Refer to the specific layout of your remote for head and foot control indicators.

5. TROUBLESHOOTING

- **Remote Not Responding:** Ensure the batteries are correctly installed and have sufficient charge. Replace batteries if necessary.
- **Loss of Connection:** If the remote stops controlling the bed, try re-pairing it with the adjustable base. Refer to the pairing steps provided with your remote.
- **Interference:** Radio Frequency (RF) devices can sometimes experience interference. Ensure there are no strong RF-emitting devices nearby that could disrupt the signal.
- **Incorrect Functionality:** Double-check that this remote model (RF3407) is indeed compatible with your specific adjustable bed base model (S-Cape 300/500/700 1.0/+ or Prodigy 2/Comfort Elite).

6. SPECIFICATIONS

Brand	Generic
Model Number	RF3407
Model Name	Okin Remote
Color	Black
Compatible Devices	Massage Chair (S-Cape 300/500/700 1.0/+ or Prodigy 2/Comfort Elite)
Connectivity Technology	Radio Frequency
Number of Buttons	3
Controller Type	Button Control
Manufacturer	Mattress Firm Leggett and Platt Okin

7. WARRANTY INFORMATION

Specific warranty information for this Generic RF3407 replacement remote control is not provided in the product details. Please refer to the seller or manufacturer for any applicable warranty terms and conditions.

8. CUSTOMER SUPPORT

For technical assistance or further inquiries regarding your Generic RF3407 replacement remote control, please contact the seller or the manufacturer, Mattress Firm Leggett and Platt Okin. Contact details are typically available on your purchase receipt or the product packaging.

