Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Tevese X9

Tevese X9 Bone Conduction Swimming Headphones User Manual

Model: X9 | Brand: Tevese

Introduction
What's in the Box
Setup
Operating
Maintenance
Troubleshooting
Specifications
Warranty & Support

1. Introduction

Welcome to your Tevese X9 Bone Conduction Swimming Headphones. These headphones are engineered to deliver clear audio through bone conduction technology, featuring an IPX8 waterproof rating, 32GB internal MP3 storage, and Bluetooth 6.0 connectivity. This manual provides essential information for the proper setup, operation, and maintenance of your device.

Key Features:

- **Bone Conduction Technology:** Delivers sound through your cheekbones, keeping your ears open to surroundings.
- **IPX8 Waterproof Rating:** Designed for reliable performance during prolonged submersion in water.
- **32GB Built-In MP3 Player:** Stores over 9,000 songs for phone-free listening, especially underwater.
- **Bluetooth 6.0 Connectivity:** Provides stable, low-latency wireless audio for above-water activities.
- **Dual-Mode Functionality:** Seamlessly switch between Bluetooth (above water) and MP3 (underwater) modes.
- **Ergonomic & Lightweight Design:** Ensures a secure and comfortable fit, compatible with swim caps and goggles.
- **Long Battery Life:** Up to 10 hours of playback on a single charge.

2. What's in the Box

Please verify that all items are present in your package:

- Tevese X9 Bone Conduction Swimming Headphones
- Magnetic Charging Cable
- Waterproof Ear Tips
- User Manual (this document)



Image: The complete package contents, showing the Tevese X9 headphones, magnetic charging cable, waterproof ear tips, and the user manual.

3. Setup

3.1 Initial Charging

Before first use, fully charge your headphones. Connect the magnetic charging cable to the charging port on the headphones and plug the USB end into a power source (e.g., computer USB port or wall adapter). A full charge takes approximately 3 hours and provides up to 10 hours of playback.



Image: The magnetic charging connection for the Tevese X9 headphones, highlighting quick charging capabilities.

3.2 Power On/Off

- **Power On:** Press and hold the Power/Multi-function button for 3 seconds until the LED indicator flashes blue.

- **Power Off:** Press and hold the Power/Multi-function button for 5 seconds until the LED indicator flashes red and then turns off.

3.3 Bluetooth Pairing (Above Water Use)

To connect your headphones to a Bluetooth-enabled device (smartphone, tablet, laptop) for above-water use:

1. Ensure the headphones are powered off.
2. Press and hold the Power/Multi-function button for 5-7 seconds until the LED indicator flashes red and blue alternately, indicating pairing mode.
3. On your device, enable Bluetooth and search for available devices.
4. Select "Tevese X9" from the list. Once connected, the LED will flash blue slowly.



Image: A smartphone screen displaying a successful Bluetooth 6.0 connection to the Tevese X9 headphones.

3.4 MP3 Mode & File Transfer (Underwater Use)

For underwater listening, switch to MP3 mode as Bluetooth signals do not transmit effectively in water. The headphones have 32GB of built-in storage.

1. **Transferring Files:** Connect the headphones to your computer using the magnetic charging cable. The headphones will appear as a removable disk. Drag and drop your MP3 audio files into the headphone's storage.
2. **Switching to MP3 Mode:** While the headphones are on, press the Power/Multi-function button three times quickly to switch between Bluetooth and MP3 modes. The voice prompt will indicate the current mode.

Image: Visual representation of the 32GB internal storage, capable of holding over 9,000 songs.

4. Operating Instructions

4.1 Button Controls

The Tevese X9 headphones feature intuitive button controls for easy management of your audio:

Button/Action	Function

Button/Action	Function
Power/Multi-function Button (Long Press 3s)	Power On
Power/Multi-function Button (Long Press 5s)	Power Off
Power/Multi-function Button (Press 3 times quickly)	Switch between Bluetooth Mode and MP3 Mode
Volume + Button (Short Press)	Increase Volume
Volume - Button (Short Press)	Decrease Volume
Volume + Button (Long Press)	Next Track
Volume - Button (Long Press)	Previous Track
Play/Pause Button (Short Press)	Play/Pause Music
Play/Pause Button (Short Press during call)	Answer/End Call
Play/Pause Button (Long Press during call)	Reject Call



Image: A detailed view of the headphone controls, illustrating the functions of the volume and multi-function buttons.

4.2 Wearing the Headphones

Place the headphones around the back of your head, with the transducers resting on your cheekbones just in front of your ears. The open-ear design allows you to hear your surroundings while enjoying audio. The flexible band ensures a secure fit, even during vigorous activities. They are designed to be compatible with swim caps and goggles.



Image: A cyclist wearing the Tevese X9 headphones, illustrating the open-ear design that allows awareness of surroundings.

5. Maintenance

5.1 Cleaning

- After swimming or heavy sweating, rinse the headphones with clean fresh water.
- Wipe the headphones dry with a soft, clean cloth.
- Do not use abrasive cleaners or harsh chemicals.

5.2 Storage

- Store the headphones in a cool, dry place away from direct sunlight and extreme temperatures.
- Avoid placing heavy objects on the headphones.

5.3 Waterproof Care

- The IPX8 rating ensures protection against continuous immersion in water. However, always ensure the charging port is completely dry before connecting the magnetic charging cable to prevent damage.
- Do not attempt to charge wet headphones.



Image: A swimmer using the Tevese X9 headphones, emphasizing their IPX8 waterproof capability for intense water activities.

6. Troubleshooting

If you encounter issues with your Tevese X9 headphones, please refer to the following common solutions:

Problem	Solution
Headphones do not power on.	Ensure the headphones are fully charged. Connect to the magnetic charging cable and allow sufficient charging time.
No sound from headphones.	Check the volume level on both the headphones and your connected device. Ensure the correct mode (Bluetooth or MP3) is selected. For Bluetooth, verify successful pairing. For MP3, ensure audio files are loaded.
Bluetooth connection is unstable or disconnects.	Ensure you are using the headphones above water, as Bluetooth signals do not transmit underwater. Keep the headphones within 10 meters (33 feet) of your paired device. Reduce interference from other electronic devices.
MP3 files are not playing.	Confirm that the headphones are in MP3 mode. Verify that the audio files are in a compatible format (e.g., MP3) and have been successfully transferred to the headphone's internal storage.
Headphones are not recognized by computer for file transfer.	Ensure the magnetic charging cable is securely connected to both the headphones and the computer. Try a different USB port or cable. Restart your computer.
Sound quality is poor underwater.	Ensure you are in MP3 mode. Bone conduction audio quality can vary slightly based on individual ear anatomy and water conditions. Ensure a snug fit.

7. Specifications

Detailed technical specifications for the Tevese X9 Bone Conduction Swimming Headphones:

Feature	Detail
Brand	Tevese
Model Name	X9
Waterproof Rating	IPX8
Connectivity Technology	Bluetooth 6.0, Built-in MP3 Player
Internal Storage	32GB (stores 9,000+ songs)

Feature	Detail
Battery Life	Up to 10 hours
Battery Charge Time	Approximately 3 hours
Wireless Range	10 meters (33 feet)
Audio Driver Type	Bone Conduction Driver
Frequency Range	20 Hz - 20,000 Hz
Material	Acrylonitrile Butadiene Styrene (ABS)
Weight	Approximately 29g
Control Type	Button Control

8. Warranty & Support

8.1 Manufacturer's Warranty

The Tevese X9 Bone Conduction Swimming Headphones come with a**2-Year Manufacturer Warranty** from the date of purchase. This warranty covers defects in materials and workmanship under normal use. Please retain your proof of purchase for warranty claims.

8.2 Return Policy

A **30-Day Return Policy** is available for this product. Please refer to your retailer's specific return guidelines for details.

8.3 Customer Support

For any questions, technical assistance, or warranty inquiries, our customer support team is available to help. We offer**24-Hour Customer Support**.

- **Contact Information:** Please refer to the contact details provided on the product packaging or the official Tevese website.



Image: Summary of warranty and service terms, including extended warranty, return policy, and customer support availability.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FMPJ8JVN

More documents and user manuals: **https://manuals.plus/**