



[Manuals.plus](#) /

› [L.a.Z.-Boy](#) /

› L.a.Z.-Boy Air Lumbar Manager Office Chair User Manual Model 1782799

## L.a.Z.-Boy 1782799

# L.a.Z.-Boy Air Lumbar Manager Office Chair User Manual

Model: 1782799

## 1. INTRODUCTION

---

Thank you for choosing the L.a.Z.-Boy Air Lumbar Manager Office Chair. This manual provides essential information for the safe assembly, proper operation, and effective maintenance of your new office chair. Please read these instructions carefully before assembly and retain them for future reference.



*Image 1.1: The L.a.Z.-Boy Air Lumbar Manager Office Chair in an office setting.*

## 2. SAFETY INFORMATION

---

- Ensure all components are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Follow assembly instructions precisely. Improper assembly can lead to instability and injury.
- Do not stand on the chair. Use it only for seating.
- Do not exceed the maximum weight recommendation of 275 pounds.
- Keep children and pets away from the chair during assembly.
- Regularly check all bolts and screws to ensure they are tight. Retighten as necessary.

## 3. PARTS LIST

---

Before beginning assembly, verify that all the following components are included in your package:

- Backrest
- Seat Cushion with Seat Plate Mechanism

- Armrests (2)
- Gas Lift Cylinder
- 5-Star Base
- Casters (5)
- Hardware Pack (screws, washers, Allen wrench)

## 4. ASSEMBLY INSTRUCTIONS

---

Please follow these steps carefully for proper assembly:


1. **Attach Casters to Base:** Insert each of the five casters into the holes at the end of each leg of the 5-star base. Push firmly until they click into place.
2. **Insert Gas Lift Cylinder:** Place the larger end of the gas lift cylinder into the center hole of the assembled 5-star base.
3. **Attach Seat Plate to Seat Cushion:** Align the seat plate mechanism (pre-attached to the seat cushion) with the mounting holes on the underside of the seat cushion. Secure with the provided screws and Allen wrench. Ensure the front of the seat plate faces the front of the seat cushion.
4. **Attach Armrests:** Secure the armrests to the sides of the seat cushion using the provided screws. Ensure they are oriented correctly (left and right).
5. **Attach Backrest:** Connect the backrest to the seat assembly using the designated screws.
6. **Connect Seat Assembly to Base:** Carefully place the assembled seat and backrest onto the gas lift cylinder, ensuring the cylinder's top fits securely into the center hole of the seat plate mechanism.



Image 4.1: Diagram illustrating the chair's dimensions for reference during assembly and placement.

## 5. OPERATING INSTRUCTIONS

Your L.a.Z.-Boy Air Lumbar Manager Office Chair features several adjustable components designed for personalized comfort and support.



### **Padded Flip-Up Armrests**

Providing ergonomic support for your arms and wrists when down, the armrests flip-up and away to save space when not in use.

### **InfinityLock™ Seat Plate**

The InfinityLock™ seat plate let's you secure your recline angle lock at an infinite number of positions with the easy-to-reach control lever. Rotate the under-seat tension knob to adjust the ease of recline.

### **Pneumatic Height Adjustment**

Adjustable chair height features 3.75" of height adjustment range.

### **AIR Ergonomic Support Technology® Lumbar Zone**

Patented TrueWellness® AIR Ergonomic Support Technology® pivots with you for continuous lumbar support and comfort.

*Image 5.1: Visual guide to the chair's key adjustable features.*

## **5.1. Pneumatic Height Adjustment**

To adjust the chair's height, locate the lever on the right side, beneath the seat. While seated, pull the lever up to lower the chair. To raise the chair, stand up and pull the lever up. Release the lever at your desired height. The chair offers approximately 3.75 inches of height adjustment range.

## **5.2. InfinityLock Seat Plate (Recline and Tilt)**

The InfinityLock seat plate allows you to secure your recline angle at an infinite number of positions. To recline, pull the lever on the left side, beneath the seat, and lean back. Release the lever to lock the recline position. To adjust the tilt tension, rotate the round knob located at the front, beneath the seat. Turn clockwise to increase tension (making it harder to recline) and counter-clockwise to decrease tension (making it easier to recline).



*Image 5.2: Illustration of the chair's reclining capability.*

### **5.3. Padded Flip-Up Armrests**

The armrests are designed to flip up and away when not in use, providing flexibility and space. Simply lift the armrests upwards until they lock into the vertical position. To return them to the down position, gently pull them down. These armrests provide ergonomic support for your arms and wrists.



*Image 5.3: Front view demonstrating the flip-up armrest feature.*

#### **5.4. AIR Ergonomic Support Technology® Lumbar Zone**

The chair features patented TrueWellness® AIR Ergonomic Support Technology® which pivots with you for continuous lumbar support and comfort. This system automatically adjusts to your movements, providing dynamic support to your lower back.



*Image 5.4: Close-up view of the chair's lumbar support area.*

## 6. MAINTENANCE

---

Proper care will extend the life and appearance of your L.a.Z.-Boy office chair.

- **Cleaning:** The faux leather upholstery should be spot cleaned. Use a damp cloth with mild soap and water for spills or stains. Avoid harsh chemicals or abrasive cleaners.
- **Hardware Check:** Periodically check all screws and bolts to ensure they are tight. Retighten as needed to maintain stability.
- **Caster Care:** The dual-wheel 360° mobility casters are intended for use on carpet. For optimal performance, keep casters free of hair and debris. Not recommended for use on tile or hard wood floors.



### Signature Comfort Core® Plus with Memory Foam Seat Construction

Patented La-Z-Boy® seat construction provides unparalleled comfort and lasting support through a combination of multi-density foams and coils.



### PureSoft™ Upholstery

Upholstered in a soft yet durable PureSoft™ material that looks and feels great. Easily spot cleans with a damp cloth.



### Durable Construction with Nylon 5-Star Base

Durable construction and a heavy-duty nylon base ensure this chair is rated to support users up to 275 lbs. It's easy to assemble with no additional tools required.



### Dual-Wheel 360° Mobility Casters

Branded dual-wheel 360° mobility casters quietly roll over most carpet types. Casters are intended for use on carpet and not recommended for use on tile or hard wood floors.

Image 6.1: Diagram highlighting ComfortCore Plus, PureSoft Upholstery, Durable Construction, and Dual-Wheel 360° Mobility Casters.

## 7. TROUBLESHOOTING

If you encounter any issues with your chair, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chair does not adjust height	Gas lift cylinder malfunction or lever not engaged.	Ensure the height adjustment lever is fully pulled up. If the issue persists, the gas lift cylinder may need replacement.
Chair wobbles or is unstable	Loose screws or improper assembly.	Check all assembly screws and bolts, especially those connecting the seat plate, armrests, and backrest. Retighten as necessary. Ensure casters are fully inserted into the base.
Chair squeaks during movement	Loose connections or friction between parts.	Tighten all screws. Apply a small amount of silicone-based lubricant to moving parts or connection points if tightening does not resolve the issue.
Recline function not working	Recline lever not engaged or tilt tension too high.	Ensure the recline lever is fully pulled. Try adjusting the tilt tension knob counter-clockwise to reduce tension.

## 8. SPECIFICATIONS

Feature	Detail
Brand	L.a.Z.-Boy
Model Name	1782799

Feature	Detail
Product Dimensions (D x W x H)	18.75" x 22" x 23.5" (Seat Depth x Seat Width x Seat Height)
Overall Chair Dimensions (W x L x H)	28.75 in. x 29.5 in. x 45.5 in.
Maximum Weight Recommendation	275 Pounds
Seat Material	Faux Leather
Back Style	High Back
Special Features	Air Lumbar Support, ComfortCore Plus with Memory Foam, Padded Flip-Up Arms, InfinityLock Seat Plate, Pneumatic Height Adjustment
Reclining Position Count	2 (Recline and Tilt)
Casters	Dual-Wheel 360° Mobility Casters (for carpet use)
Item Weight	41.9 pounds

## 9. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the documentation provided at the point of purchase or contact the manufacturer directly. Keep your purchase receipt as proof of purchase.